

Programmable synthesizer /  
function generator 0.1 MHz – 50 MHz

**PM 5193**

9445 051 93001

Service manual

9499 455 00311

87 08 01

**I&E**

Industrial & Electro-acoustic Systems Division



**Industrial &  
Electro-acoustic Systems**

**PHILIPS**

Programmable synthesizer /  
function generator 0.1mHz – 50 MHz


# PM 5193

9445 051 93001

## Service manual

9499 455 00311

87 0801



# PHILIPS

**Please note**

In correspondence concerning this instrument, please quote the type number and serial number as given on the type plate.

**Bitte beachten**

Bei Schriftwechsel über dieses Gerät wird gebeten, die Typennummer und die Gerätenummer anzugeben. Diese befinden sich auf dem Typenschild an der Rückseite des Gerätes.

**Noter s. v. p.**

Dans votre correspondance et dans vos réclamations se rapportant à cet appareil, veuillez toujours indiquer le numéro de type et le numéro de série qui sont marqués sur la plaquette de caractéristiques.

**Important**

As the instrument is an electrical apparatus, it may be operated only by trained personnel. Maintenance and repairs may also be carried out only by qualified personnel.

**Wichtig**

Da das Gerät ein elektrisches Betriebsmittel ist, darf die Bedienung nur durch eingewiesenes Personal erfolgen. Wartung und Reparatur dürfen nur von geschultem, fach- und sachkundigem Personal durchgeführt werden.

**Important**

Comme l'instrument est un équipement électrique, le service doit être assuré par du personnel qualifié. De même, l'entretien et les réparations sont à confier aux personnes suffisamment qualifiées.

© Philips GmbH — Hamburg — Germany — 1987

All rights are strictly reserved.

Reproduction or divulcation in any form whatsoever is not permitted without written authority from the copyright owner.

Issued by Philips GmbH -Unternehmensbereich Elektronik für Wissenschaft und Industrie- Werk für Meßtechnik  
Printed in Germany

## CONTENTS

|           |                                                                                            |            |
|-----------|--------------------------------------------------------------------------------------------|------------|
| <b>1.</b> | <b>SAFETY INSTRUCTIONS</b>                                                                 | <b>1-1</b> |
| 1.1.      | Safety precautions                                                                         | 1-1        |
| 1.2.      | Caution and warning statements                                                             | 1-1        |
| 1.3.      | Symbols                                                                                    | 1-1        |
| 1.4.      | Impaired safety-protection                                                                 | 1-1        |
| 1.5.      | General clauses                                                                            | 1-1        |
| 1.6.      | Connections                                                                                | 1-2        |
| <b>2.</b> | <b>MAINS VOLTAGE SETTING AND FUSES</b>                                                     | <b>2-1</b> |
| <b>3.</b> | <b>OPERATING PRINCIPLE</b>                                                                 | <b>3-1</b> |
| 3.1.      | General operating principle                                                                | 3-1        |
| 3.2.      | Description of the blockdiagram                                                            | 3-1        |
| <b>4.</b> | <b>PERFORMANCE CHECK</b>                                                                   | <b>4-1</b> |
| 4.1.      | General information                                                                        | 4-1        |
| 4.2.      | Power-on selftest                                                                          | 4-1        |
| 4.3.      | General functional test                                                                    | 4-2        |
| <b>5.</b> | <b>DIAGNOSTIC-PROGRAM PM 5193</b>                                                          | <b>5-1</b> |
| <b>6.</b> | <b>CIRCUIT DESCRIPTIONS</b>                                                                | <b>6-1</b> |
| 6.1.      | Digital frequency synthesizer/U2                                                           | 6-1        |
| 6.2.      | PLL/U1                                                                                     | 6-8        |
| 6.3.      | Modulator/U1                                                                               | 6-12       |
| 6.4.      | Pulse generator/U1                                                                         | 6-16       |
| 6.5.      | Amplifier/U1                                                                               | 6-18       |
| 6.6.      | CPU/U2                                                                                     | 6-20       |
| 6.7.      | Keyboard display unit/U3                                                                   | 6-23       |
| <b>7.</b> | <b>ACCESS TO PARTS</b>                                                                     | <b>7-1</b> |
| 7.1.      | Top and bottom covers (dismantling the instrument)                                         | 7-1        |
| 7.2.      | Fuse, mains transformer                                                                    | 7-1        |
| 7.3.      | Unit 1 and unit 2                                                                          | 7-1        |
| 7.4.      | Front-panel edging                                                                         | 7-1        |
| 7.5.      | Text plate                                                                                 | 7-2        |
| 7.6.      | Unit 3 (keyboard and display)                                                              | 7-3        |
| 7.7.      | Carrying handle                                                                            | 7-3        |
| 7.8.      | Handle assembly for rack mounting                                                          | 7-4        |
| 7.9.      | View into the open instrument                                                              | 7-4        |
| <b>8.</b> | <b>CHECKING AND ADJUSTING</b>                                                              | <b>8-1</b> |
| 8.1.      | General Information                                                                        | 8-1        |
| 8.2.      | Recommended test equipment                                                                 | 8-1        |
| 8.3.      | Table of checks and adjustments                                                            | 8-2        |
| <b>9.</b> | <b>SAFETY INSPECTION AND TESTS AFTER REPAIR<br/>AND MAINTENANCE IN THE PRIMARY CIRCUIT</b> | <b>9-1</b> |
| 9.1.      | General directives                                                                         | 9-1        |
| 9.2.      | Safety components                                                                          | 9-1        |
| 9.3.      | Checking the protective earth connection                                                   | 9-1        |
| 9.4.      | Checking the insulation resistance                                                         | 9-1        |
| 9.5.      | Test after repair and maintenance                                                          | 9-1        |

|            |                             |             |
|------------|-----------------------------|-------------|
| <b>10.</b> | <b>SPARE PARTS</b>          | <b>10-1</b> |
| 10.1.      | General                     | 10-1        |
| 10.2.      | Static sensitive components | 10-1        |
| 10.3.      | Handling MOS devices        | 10-1        |
| 10.4.      | Soldering techniques        | 10-1        |
| 10.5.      | Parts list PM 5193          | 10-2        |

## **11. FIGURES 28 - 44**

|         |                                              |
|---------|----------------------------------------------|
| Fig. 28 | Unit 2, adjusting elements                   |
| Fig. 29 | Unit 1, adjusting elements                   |
| Fig. 30 | Block diagram                                |
| Fig. 31 | Front view                                   |
| Fig. 32 | Rear view                                    |
| Fig. 33 | Overall circuit diagram                      |
| Fig. 34 | Unit 1, component lay-out                    |
| Fig. 35 | Power supply                                 |
| Fig. 36 | Unit 1, pulse generator                      |
| Fig. 37 | Unit 1, PLL/VCO                              |
| Fig. 38 | Unit 1, output amplifier                     |
| Fig. 39 | Unit 1, modulator                            |
| Fig. 40 | Unit 2, component lay-out                    |
| Fig. 41 | Unit 2, CPU                                  |
| Fig. 42 | Unit 3, (keyboard/display) component lay-out |
| Fig. 43 | Unit 3, keyboard display                     |
| Fig. 44 | Unit 2, digital frequency synthesis (DFS)    |

## **12. CODING SYSTEM OF FAILURE REPORTING FOR QUALITY**

## **13. ADDRESSES FOR SALES AND SERVICE**

## 1. SAFETY INSTRUCTIONS

### WARNING:

These servicing instructions are for use by qualified personnel only. To reduce the risk of electric shock, do not perform any servicing other than that specified in the Operating Instructions unless you are fully qualified to do so.

Read these pages carefully before installation and use of the instrument.

The following clauses contain information, cautions and warnings which must be followed to ensure safe operation and to retain the instrument in a safe condition.

Adjustment, maintenance and repair to the instrument shall be carried out only by qualified personnel.

### 1.1. SAFETY PRECAUTIONS

For the correct and safe use of this instrument it is essential that both operating and servicing personnel follow generally-accepted safety procedures in addition to the safety precautions specified in this manual. Specific warning and caution statements, where they apply, will be found throughout the manual. Where necessary, the warning and caution statements and/or symbols are marked on the apparatus.

### 1.2. CAUTION AND WARNING STATEMENTS

#### CAUTION:

Is used to indicate correct operating or maintenance procedures in order to prevent damage to or destruction of the equipment or other property.

### WARNING:

Calls attention to a potential danger that requires correct procedures or practices in order to prevent personal injury.

### 1.3. SYMBOLS



Protective earth  
(grounding) terminal

(black symbol on yellow background or impressed,  
e. g. at the mains connector at the rear)

### 1.4. IMPAIRED SAFETY-PROTECTION

Whenever it is likely that safety-protection has been impaired, the instrument must be made inoperative and be secured against any unintended operation. The matter should then be referred to qualified technicians.

Safety protection is likely to be impaired if, for example, the instrument fails to perform the intended measurements or shows visible damage.

### 1.5. GENERAL CLAUSES

#### WARNING:

The opening of covers or removal of parts, except those to which access can be gained by hand, is likely to expose live parts and accessible terminals which can be dangerous to life.

The instrument shall be disconnected from all voltage sources before it is opened.

Bear in mind that capacitors inside the instrument can hold their charge even if the instrument has been separated from all voltage sources.

#### WARNING:

Any interruption of the protective earth conductor inside or outside the instrument, or disconnection of the protective earth terminal, is likely to make the instrument dangerous. Intentional interruption is prohibited.

Components which are important for the safety of the instrument may only be renewed by components obtained through your local Philips organisation (see also chapter 9).

After repair and maintenance in the primary circuit, safety inspection and tests, as mentioned in chapter 9 have to be performed.

## 1.6. CONNECTIONS

The circuit earth potential is applied to the external contacts of the BNC sockets and is connected to the cabinet by means of parallel-connected capacitors. By this means hum loops are avoided and a clear HF earthing is obtained.

If the circuit earth potential in a measurement set-up is different from the protective earth potential, it must be noticed,

- that the BNC sockets can be touched and that it must not be live, see the safety regulations on the subject (VDE 0411),
- that all sockets marked with the sign  $\perp$  are internally interconnected.

## 2. MAINS VOLTAGE SETTING AND FUSES

The safety instructions in previous chapters must be followed.

PM 5193: On delivery from the factory the instrument is set to 220 V – AC.  
 PM 5193 M (USA): On delivery from the factory the instrument is set to 120 V – AC up to ser. no. LO-05951 or to 120 V-AC from ser. no. LO-05951 onwards.



If the instrument is to be used on a different supply voltage the wiring must be altered; the main fuse should be replaced dependent on the mains voltage. The wiring for the fan must not be altered.

Proceed as follows:



- Loosen 2 cross-slotted screws at the rear side of the instrument (see also chapter 7.1.).
- Remove the top cover.
- Remove the isolating cover of the topside of the mains transformer, remove cable binder before.
- Alter the wiring of the mains transformer according to the connection diagram.
- Refit the isolating cover.
- If necessary, insert the advised fuse into the fuse holder instead of the fuse built-in. In this case change current label of the fuse holder.
- Change the mains voltage label at the rear of the instrument in accordance with the mains voltage selected.  
 The labels for the mains voltage, current and the fuse are enclosed in a plastic bag.
- Close the instrument.

Connection diagram

Up to series number LO-05951:



From series number LO-05951 onwards:





### 3. OPERATING PRINCIPLE, Fig. 30 (Block diagram)

#### 3.1. GENERAL OPERATING PRINCIPLE

The basic functional units, performing the generation, processing and conditioning of the generator output signals, are named

- |                                       |           |
|---------------------------------------|-----------|
| — DFS, Digital Frequency Synthesizer, | on unit 2 |
| — PLL, Phase Locked Loop,             | on unit 1 |
| — MODULATOR                           | on unit 1 |
| — PULSE GENERATOR                     | on unit 1 |
| — AMPLIFIER                           | on unit 1 |

These functional units are under control of the CPU (Central Processing Unit), consisting of a micro-processor and its peripheral components on unit 2. Primary control data for the CPU is derived from the front-end KEYBOARD & DISPLAY on unit 3 or from an external controller via the IEEE/IEC bus interface. The output-signal parameters are displayed numerically on a 7-segment-LED display. Key LEDs are provided for operating mode indication. Subsequently a brief description of the over-all block diagram (fig. 30) of the generator is given.

#### 3.2. DESCRIPTION OF THE BLOCK DIAGRAM

##### DFS

In the frequency range up to 2147 kHz the primary signals — sine, triangular, positive and negative sawtooth waves — are generated by direct digital signal synthesis.

Binary samples of the wave are created in the SIGNAL SYNTHESIZER section and converted to analogue voltages by a fast DAC at the clock rate  $f_c$ . The output frequency  $f_o$  is directly related to  $f_c$ , according to

$$f_o = 0.1 \cdot N \cdot 2^{-33} \cdot f_c = N \cdot 10^{-4} \text{ Hz}$$

where  $N$  is the decimal equivalent of the binary frequency word, routed to the SIGNAL SYNTHESIZER from the CPU via U2-CONTROL BUS.  $f_c$  is generated by an x-tal oscillator, the 8.59 MHz CLOCK. The AUTOMATIC SWITCH alternatively routes the external clock frequency to the SIGNAL SYNTHESIZER, if this is applied to the CLOCK INPUT. The DAC output signal is smoothed by the 3 MHz LPF, an anti-aliasing low-pass filter. The BURST CONTROL LOGIC section generates the carrier on/off keying control signals in the burst mode of the generator.

##### PLL

In the frequency range above 2147 kHz the primary sine wave is generated in the PLL. The PLL consists of a broad-band VCO, Voltage-Controlled Oscillator, — with a triangular-wave output signal fed to the SINE SHAPER — the FREQUENCY DIVIDER, the PHASE DETECTOR and the LOOP FILTER. By the PLL the PLL REF frequency — generated in the DFS — is multiplied by a factor of 4096 in FM mode and 32 otherwise. For fast phase-locking response the VCO is preset roughly by the DAC to the programmed frequency.

## MODULATOR

By the VOLTAGE CONDITIONER the DFS sawtooth wave or the sine wave — if haversine is selected — are halved in amplitude and shifted in dc, resulting in unipolar signals. The sine wave — if sine wave-form is programmed — and the triangular wave are routed without change through the VOLTAGE CONDITIONER. In the BURST-mode the output signal of the VOLTAGE CONDITIONER is keyed on/off by the DIODE SWITCH 1 and routed to the AMPLIFIER. In NON-BURST-mode the signal from DIODE SWITCH 1 is fed either directly or through the AMPLITUDE MODULATOR to the AMPLIFIER. In the frequency range above 2147 kHz the RF SINE wave is routed from the PLL to DIODE SWITCH 2 and to the AMPLITUDE MODULATOR or directly to the AMPLIFIER. Both diode switches are served by the SWITCH CONTROL, which evaluates the accurate control signal from the outputs SQUARE BURST and BURST for the DFS, the 2 MHz SWITCH control signal from the CPU and the GATE signal from the SWITCHING CIRCUITRY in the gate mode of the generator.

In internal GATE, AM or FM mode the modulating signal is derived from the MODULATION OSCILLATOR output. The output sine wave is scaled in amplitude by the AMPLITUDE CONTROLLER to give the accurate AM or FM modulation depth. The modulating sine wave is fed to the AMPLITUDE MODULATOR in AM mode or to the PLL in FM mode through the SWITCHING CIRCUITRY. Alternatively — in the external modulation modes — the modulating signal is supplied from the generator MODULATION INPUT.

## PULSE GENERATOR

The PULSE GENERATOR basically represents an electronical switching circuitry, creating a TTL signal and either a square wave or a positive respectively negative rectangular pulse train, each signal with a 50 % duty cycle. The instants of the positive and negative edges of these signals are determined by the zero-crossings of the reference input signal. In the frequency range up to 2147 kHz the DFS signal, e. g. a sine wave, fed to the ZERO CROSSING DETECTOR serves as reference. Above 2147 kHz the TTL output signal of the PLL, named RF TTL, directly determines the switching points.

By the CONTROL CIRCUITRY either the TTL output of the ZERO CROSSING DETECTOR or the RF TTL combined with one of the burst switching signals in burst mode — the POSITIVE PULSE BURST, the BURST or the SQUARE BURST — are routed to the switching output of the signal conditioners. The TTL OUTPUT STAGE and the SQUARE WAVE CONDITIONER are creating the TTL output voltage of the generator and the primary square wave with accurate amplitude and waveform. The PULSE TRAIN CONDITIONER generates a square wave with extra steep positive and negative edges and a programmable amplitude, controlled by the dc output of the DAC. At the generator output this square wave is shifted to unipolar positive or negative pulses by the DC GENERATOR in the AMPLIFIER.

## AMPLIFIER

The vernier setting of the generator output amplitude is performed by the AMPLITUDE CONTROLLER. After amplification by the POWER AMPLIFIER the signal either directly or after 20 dB respectively 40 dB attenuation by the STEP ATTENUATOR is routed to the OUTPUT socket. The DC GENERATOR adds the programmed dc voltage.

**CPU**

An 8-bit microprocessor (8031) and a 10 MHz clock are the constituents of the PROCESSOR & CLOCK. The PROGRAM MEMORY is a 16 Kbyte EPROM. In an external data memory, the 256 byte RAM, the 10 storage register contents of the generator are stored. By the CONTROL BUS DRIVER the required load capability of the U1- and U2 CONTROL BUS serial data line (SDA), and the clock line (SCL), is achieved. The device selecting strobe signals STR1...15 — used for CPU components and latching-data — shift registers in the various functional units controlled by the CPU — are derived from 4 ports of the PROCESSOR by the STROBE DECODER.

By the DIRECT PORT LATCH two output port signals — 2 MHz SWITCH and PLL CNTL — are derived from three address/data bus lines of the CPU. The SWEEP VOLTAGE DAC is generating a voltage ramp during a frequency sweep. The PEN LIFT SWITCH serves for lifting the writing pen of an x-y plotter during frequency sweep fly-backs.

The IEEE/IEC bus interface of the generator consists of the IEC BUS CONTROLLER, the DEVICE ADDRESS LATCH & SHIFT REGISTER and the 3-STATE GATE & LATCH.

## 4. PERFORMANCE CHECK

### 4.1. GENERAL INFORMATION

**WARNING:**

Before switching on, ensure that the instrument has been installed in accordance with the instructions outlined in Section 2 of the Operating Manual: Installation instructions.

This procedure is intended to:

- check the instrument
- be used for incoming inspection to determine the acceptability of newly-purchased instruments and/or recently-recalibrated instruments.

**ATTENTION:**

The procedure does not check every detail of the instrument's calibration; rather, it is concerned primarily with those parts of the instrument which are essential to measurement accuracy and correct operation. Removing the instrument covers is not necessary to perform this procedure. All checks are made from the front panel.

If this test is started within a short period after switching on, bear in mind that steps may be out of specification, due to insufficient warming-up time. To avoid this situation, allow the specified warming-up time of 30 min.

### 4.2. POWER-ON SELFTEST

Immediately after power on a selftest routine is started with which PROM and RAM are tested. If an error is detected one of the following error messages appears:

|       |      |                                                                      |
|-------|------|----------------------------------------------------------------------|
| ERR 1 | PROM | checksum error                                                       |
| ERR 2 | RAM  | (processor) checksum error                                           |
| ERR 3 | RAM  | checksum error; operation possible but memory contents is destroyed. |

In case of no error in PROMs/RAMs all LEDs and all segments of the displays are then switched on for appr. 3s after the software version has been indicated in the 'LEVEL'-sector of the display. The instrument must then be in the on-state which is indicated by a zero in each of the display sections and the LEDs in the keys SINE, START, OFF and Vpp switched on.

## 4.3. GENERAL FUNCTIONAL TEST

The function of the synthesizer can now be checked with the help of the following examples:

amplitude = 5 Vpp; offset = 0 Vdc

terminate the output with 50  $\Omega$  and connect an oscilloscope.

| Wave form        | start frequency | stop frequency | modulation |            |                                             | defective unit in case of faulty function |
|------------------|-----------------|----------------|------------|------------|---------------------------------------------|-------------------------------------------|
|                  |                 |                | -mode      | -frequency | -depth, -deviation sweep time, no of cycles |                                           |
| 1) triangle      | 50 kHz          | —              | —          | —          | —                                           | DFS                                       |
| 2) sine          | 500 kHz         | —              | AM         | 1 kHz      | 50 % depth                                  | modulator                                 |
| 3) pos. pulse    | 5 MHz           | —              | FM         | 1 kHz      | 100 kHz dev.                                | modulator, PLL pulse generator            |
| 4) pos. sawtooth | 1 MHz           | 10 MHz         | Sweep Lin. | —          | 5 sec. sweep time                           | CPU, DFS                                  |
| 5) triangle      | 10 kHz          | —              | Gate*      | 1 kHz      | —                                           | modulator                                 |
| 6) square        | 800 Hz          | —              | Burst      | —          | 2 on-, 3 off cycles                         | modulator, DFS pulse generator            |

\* it is advisable to trigger the oscilloscope with the 'MODULATION OUTPUT'-signal

If one of the functions doesn't work, the diagnostic program can be a help to distinguish whether the defect is in the unit in question or in the CPU with its C-bus drivers/decoders. By selecting TEST 4 (strobe test) it is possible to check the data communication lines and the decoders of the subunits.

In case that all functions are o. k. this test must be continued by checking the output signals:

**TTL OUT:** This output shows always a square wave voltage with TTL-level and signal-frequency.

**INT CLOCK:** This output contains the clock-signal of the internal digital frequency synthesizer with TTL-level and a frequency of 8.58993 MHz.

**MODULATION:** This output shows a sinewave signal with an amplitude of max. 1 Vrms depending on modulation depth/deviation and modulation frequency.

**PEN LIFT:** In the continuous sweep mode this output shows a sequence of pulses. The frequency corresponds to the sweep repetition rate, amplitude is 20 Vpp.

**SWEEP:** During continuous sweep operation this output shows a sawtooth voltage with an amplitude of 10 Vpp.

## 5. DIAGNOSTIC-PROGRAM PM 5193

This test program contains 5 submodules:

- TEST 1: Display and LED test
- TEST 2: Keyboard test
- TEST 3: Storage register test
- TEST 4: Strobe test (test of the internal interfaces)
- TEST 5: Test of the IEEE/IEC-BUS interface

To activate this test program, press the key MODULATION OFF while power is switched on and keep it pressed for about 3 seconds.

The return to the main operating mode is only possible by switching power OFF and ON again.

When the test program is activated, the display shows "TEST x" where 'x' is a number from 1 to 5. This number changes continuously and slowly, and by pressing the key MODULATION OFF at the right moment, the respective test-submodule will be started.

To leave the test submodules, press the key MODULATION OFF for about 2 seconds.

### TEST 1: Display and LED test

#### Step 1: 7-segment-display

All display segments and LEDs are switched on for about 2 seconds.

After this the program starts to switch on one segment after the other for four display positions simultaneously. Finally, the decimal points of these four positions remain lit and the program starts to do the same with the next four display positions.

After the last four digits were tested, the program switches on all segments and LEDs and remain in this state until the key MODULATION OFF was pressed once again.

#### Step 2: LEDs


All LEDs will be switched on sequentially, one after the other, for approx. 0.5 seconds beginning with the uppermost left one (inside the key sine wave). When the last LED was switched on the indication "End" appears at the display until the key MODULATION OFF was pressed. Then the program returns to the test-menu.

### TEST 2: Keyboard test

The display shows the indication: 1 - 01 - - - -

Now you must press the first key of the first row: 1 - 01 - - - -  
(row 1) - (column 1)

#### Keyboard



When the right key was pressed, the display shows

1 - 01 1 1 1

for about 1 second and changes then to

1 - 02 - - - -

as a request to press the second key in the first row. In case of a failure, the display would show

Err 1 - 01 x - xx

where x - xx indicates the wrong code (row and column). This error indication will only be reset by pressing the requested key - in case of a hardware failure at the keyboard unit it would not be possible to get the right code and thus to reset the error message.

When the last key was pressed, the keyboard test is finished and the display indicates "End". To leave this diagnostic submodule and to get back to the test menu, the key MODULATION OFF must be pressed.

### TEST 3: Storage register test

#### Attention:

This memory test damages the register contents. When the instrument is switched on after the storage register test was executed, the display indicates "Err 3" which means that there are now no parameters in the storage register - the complete contents (parameters) are destroyed.

The display indicates

MEMO 1 -

and the program starts to write a test pattern into each location of memory chip 1, reads it again, and checks this value for correctness. When no failure was detected, the same will be done with a second pattern. In case that there is no failure, the display shows

MEMO 1 - 1

and in case of a failure

MEMO 1 - 0

Now the program waits until the key MODULATION OFF is pressed and starts then to check the memory chip 2 in the same way as described above. When this is terminated successfully, the display indicates

MEMO 2 - 1

or in case of a failure

MEMO 2 - 0

With MODULATION OFF the program returns to the test menu.

**TEST 4 : Strobe test**

The display indicates

STRO x

where x is a number from 6 to 15. This number changes continuously and slowly. By pressing the key "MODULATION OFF" at the right moment the required strobe line will be selected. The display shows then e.g.:

STRO 08 - 1

which means that the output lines of the shift registers controlled by strobe line 8 show a specific bit-pattern. If MODULATION OFF was pressed once for a short moment all output lines of the shift registers change their state. Now the display shows:

STRO 08 - 0

Each time the MODULATION OFF-key is pressed for a short moment, the states of these output lines will be inverted. If MODULATION OFF is pressed for longer than about 1 second, this subprogram will be left and the display shows again:

STRO x

If the key MODULATION OFF is pressed again for longer than about 1 second, the program will return to the test menu.

This strobe test serves fault finding in the internal C-bus system. Measuring points, positions of ICs and measuring values are given in the following tables.

By strobe lines controlled ICs show the following bit patterns during STROBE-test:

| Bit pattern ICs HEF 4094 |   |   |   |   |    |    |    |    |
|--------------------------|---|---|---|---|----|----|----|----|
| Pin no.                  | 4 | 5 | 6 | 7 | 14 | 13 | 12 | 11 |
| Strobe 'x' - 0           | 0 | 1 | 0 | 1 | 0  | 1  | 0  | 1  |
| Strobe 'x' - 1           | 1 | 0 | 1 | 0 | 1  | 0  | 1  | 0  |

Association of these ICs:

| Strobe line | Controlled ICs (Pos. no.) | Location                                    |
|-------------|---------------------------|---------------------------------------------|
| Strobe 6    | 362, 370, 371             | "DFS/BURST", unit 2                         |
| Strobe 7    | 307, 308, 309, 310, 311   | "DFS", unit 2                               |
| Strobe 8    | 302, 306, 312             | "Output Amplifier", unit 1                  |
| Strobe 9    | 302, 313, 316             | "Modulator", unit 1                         |
| Strobe 10   | 304                       | "Pulse Generator", unit 1                   |
| Strobe 11   | 301                       | "PLL", unit 1                               |
| Strobe 13   | 321                       | "SWEEP" CPU, unit 2                         |
| Strobe 15   | 311                       | "IEC-bus, function and address" CPU, unit 2 |



| Bit pattern IC N74LS175 |   |   |
|-------------------------|---|---|
| Pin no.                 | 2 | 7 |
| Strobe 'x' — 0          | 1 | 0 |
| Strobe 'x' — 1          | 0 | 1 |

Association of this IC

| Strobe line | Controlled IC (Pos. no.) | Location                  |
|-------------|--------------------------|---------------------------|
| Strobe 12   | 313                      | "Direct port" CPU, unit 2 |

| Bit pattern IC HEF 40373 |   |   |   |   |    |    |    |    |
|--------------------------|---|---|---|---|----|----|----|----|
| Pin no.                  | 2 | 5 | 6 | 9 | 12 | 15 | 16 | 19 |
| Strobe 'x' — 0           | 0 | 1 | 0 | 1 | 0  | 1  | 0  | 1  |
| Strobe 'x' — 1           | 1 | 0 | 1 | 0 | 1  | 0  | 1  | 0  |

Association of this IC

| Strobe line | Controlled IC (Pos. no.) | Location                  |
|-------------|--------------------------|---------------------------|
| Strobe 14   | 308                      | "IEC-bus out" CPU, unit 2 |

#### TEST 5: IEC-bus test

The display shows the indication

IEC BUS

Each character sent from the controller via the IEC (IEEE)-bus will be decoded and displayed with its hexadecimal code, e. g.

ASCII 'A' indication 41 H

ASCII '3' indication 33 H

etc.

The device address of the PM 5193 is fixed to 20.

With the key MODULATION OFF the program returns to the test menu.


## 6. CIRCUIT DESCRIPTIONS

### 6.1. DIGITAL FREQUENCY SYNTHESIZER/U2

#### Signal Synthesizer

The primary signal of PM 5193 in the frequency range up to 2.147 MHz is generated in the digital frequency synthesizer (DFS). At the output of the digital section of the DFS the signal is presented as a sequence of 9 bit binary numbers. The digital samples of the signal are then converted to analogue voltages by means of a fast DAC.


The frequency of the DFS is determined by a 40 bit frequency word which is sent to the shift registers 307 - 311 from the CPU. The bit parallel shift register outputs are connected with the phase accumulator inputs. The phase accumulator is clocked by 8.5899 MHz from the clock generator. With each clock pulse the 9 bit-phase-accumulator output is incremented by the value of the frequency word. The resulting sequence of binary numbers represents a periodic sawtooth wave. By intermittent one's complementing (complementer 1) the signal is converted to a triangular wave. The samples of this signal are used as addresses for reading out a sine table ROM. The output is representing sine wave values for the first quarter period (4). By intermittent one's complementing in complementer 2 this signal is converted to a full sine wave (7).



The phase accumulator is functionally divided into two parts. The upper part consists of the adders 312 - 319 and the D-registers 322 - 326 for the frequency range 1 mHz - 2.147 MHz. Frequency values for this range are sent in the 1 - 2 - 4 - 8 code. The lower part consists of the adders 320 and 321, the NOR gate 305 and the D-register 326 and covers the range 0.1 - 1 mHz. For this range the frequency values are applied in the Excess - 3 code.

The upper part of the phase accumulator generates a sequence of 33 bit binary numbers from 0 to  $2^{33} - 1$ . With each clock pulse the output is incremented by the value of the input frequency word. When reaching the upper limit the accumulator output is reset and starts again with incrementing. This results in a cyclic sequence of binary numbers which have a sawtooth wave form character. The frequency is  $f_g = 1/T = \delta \cdot f_c \cdot 2^{-L}$  where  $\delta$  is the value of the frequency word,  $f_c$  the clock frequency (8.5899 MHz) and  $L$  the length of the phase accumulator (33 bit).

The upper 10 bit of the phase accumulator are used for subsequent signal processing. The samples of the lower 8 bit of them represent a sawtooth wave with the period  $T/4$  (1A). The upper two of the 10 bit accumulator output (signum bit (2), quadrant bit (3)) determine the quadrant in which the vector of the DFS output signal (7) is actually located. In complementer 1 (exclusiv - or gates 331, 332) the 8 bit output is inverted during the second and fourth quarter period. The resulting signal (5) is fed to the sine/triangle selector (ICs 336, 337) and parallel to the address lines of the sine-ROM in which the sine wave values for the first quarter period ( $0 - \pi/2$ ) are deposited.




For generating the wave form triangle the output of complementer 1 is fed directly to the sine/triangle selector by-passing the sine ROM. Thus the sawtooth signal (5) applied to complementer 2 results in the wave form (6A).

For sine wave the output data of the sine ROM (4) is picked up by the sine/triangle selector and routed to complementer 2 resulting in wave form (6b). By adding the inverted signum bit (2) as the 9th bit, it results in wave form 7.

When generating positive or negative sawtooths the value of the binary frequency word at the phase accumulator input is halved — thus the sawtooth period at the phase accumulator output is doubled. For positive ramps control signal "a" is low. Therefore bit 0 — 7 are routed through complement 1 without inversion to buffer 333 and 334. After passing sine triangle selector 336/337, the buffer 338/339 and complement 2 without inversion ( $b = 0$ ) the signal is latched to the output by the D — FFs 342/343. The ninth bit at output 2/342 is directly derived from bit 8 of the phase accumulator through MUX 347 and the buffers 333 and 338 (= signal c).


For negative going ramps one difference is that control signal "a" is high. Therefore the signal (bit 0 — 7) is inverted by complement 1. The second difference is that the ninth output bit (= c) is inverted by exclusive — or gate 327 (pins 8, 9, 10) at input pin 2 of MUX 347.

With 'low' at the reset input the phase accumulator output can be set to zero. After reset is switched back to 'high', the signal generation is started and performed in the way as described before. The starting conditions are shown in the picture below.



These starting conditions are relevant for the Burst function. As depicted above the start phase of Haversine is different from that of the sine wave.

For Haversine the lower 8 bits (0 — 7) of the phase accumulator output are intermittently inverted in complement 1 controlled by the inverted bit 8 of the phase accumulator (a). The resulting output of complement 1 is depicted as signal (3'). The sine ROM converts this signal to (4'). With complement 2 the signal is then converted to (6'). Control signal 'd' for complement 2 is depicted as signal (5') and represents the exclusively ored bit 8 and 9 of the phase accumulator. By adding the ninth bit 'c' (= 7') the full Haversine (8') is resulting. 'C' corresponds to the inverted control bit 'd' of complement 2. It is derived from the exclusive or gate 327 (pin 4, 5, 6) through MUX 347 and the buffers 333 and 338.




## DAC

The binary signal coming from complementer 2 via buffers 342, 343 is converted to an analog voltage in the DAC.


At the DAC inputs the drivers 344, 345 are located which are controlling the current switching differential transistor stages 427 — 428, 424 — 425, ... The DC-currents (each 5.85 mA = 10) are generated by individual circuitries. The MSB (bit 8) — current source for instance includes transistor 427 and one OP of IC 346. The bit 7 — current source includes transistor 424 and the other OP of IC 346. The remaining current sources use also this second OP of IC 346. The individual currents — if switched on — are routed to the corresponding nodes N0 — N8 of the  $R \sim 2 R$  ladder shown below. The input impedance of each node is  $2 R/3$ , where  $R$  is 619 ohm ( $2 R/3 = 412, 67$  ohm). Therefore each current — if switched on — is building up the same voltage at the related node ( $I_0 \times 2 R/3 = 2.41$  V). The transformation to the output depends on the node position in the ladder. Generally from node  $n$  to node  $n+1$  the voltage is divided by two. Thus for instance the bit 3 — node N3 voltage is transformed to the output node N8 by the factor  $2^{-(8-3)} = 1/32$ . The output voltage of the ladder at node N8 is filtered by the anti alias low pass filter 803, 804, 559 — 562. By this filter with a passband of about 3 MHz especially the spectral contents at both sides of the clock frequency (8.5899 MHz) are suppressed. The output signal is buffered with the transistors 430, 431.

For deglitching purposes of the DAC the current switching point of bit 8 can slightly be shifted with the trimpot 689 versus the current switching points of bits 0 - 7. The latter switching points are set with trimpot 676. By iterative calibration procedure with these both trimpots the sine wave distortion is minimized.



### Burst Control Section

The basic block diagram of the burst control section is shown below



The basic task of the BURST CONTROL SECTION is to derive the control signals BURST and SQUARE BURST from DFS input-signals when burst-mode is selected. BURST is routed to the modulator section and inhibits the AC output-signal when being 'high'. This is the situation before the burst-function is triggered. After triggering BURST is going 'low', thus switching on the generator output signal. After NON periods of the signal BURST again returns to 'high' inhibiting the AC output-signal. For cont-burst BURST remains 'high' during NOFF signal periods. The SQUARE BURST control signal is responsible for controlling the square wave generator during the burst function. When being 'high' the square or pulse waves of the generator are output.

For other operation modes than burst the signal BURST is always 'low'. This is achieved by BURST DISABLE at 'low'-level. When programming burst-mode the signal BURST DISABLE is switched 'high' by the count control logic (IC 362/11 via 376/11). Additionally the burst on- and off-cycles numbers — each minus one — are transferred to NON shift-register 370 and NOFF shift-register 371. The control signal 1st LOAD is shortly switched low from the count control logic. By this action the signal COUNTER LOAD is shortly going 'low' and the content of the NON shift-register is loaded into the down counter via the NON/NOFF selector. The selector is controlled by the signal SELECT (= BURST) from the output logic.

By the various actions described above the burst control function is prepared for being started. The trigger pulse is derived either from the SINGLE- or CONT-key at the front panel or from the modulation input MOD IN. At the output of the control logic START is going 'low' switching BURST also to 'low'. Additionally COUNT ENABLE is going 'low' enabling gates 365/1, 2, 3 and 365/11, 12, 13 for passing the count pulses for the MUX 361. Depending on the selected wave form and frequency either count pulses 1 or 2 are routed to the count-gate. For sine- or triangle waves and if the frequency is above 8.388 kHz the count pulses are generated by the zero detector. For all other conditions the count pulses are directly picked up as TTL-signals from the signal synthesizer section.

The count pulses are decrementing the down-counter. After  $\text{NON} - 1$  low/high transitions of the count pulses BURST END is going 'low'. By this the output FF (372) in the output logic is enabled to toggle. Additionally COUNTER LOAD is shortly going to 'low' thus the down-counter is loaded with  $\text{NOFF} - 1$ . With the next high/low transition of the count pulse the FF-state changes thus setting BURST to 'high'.

For single burst a short count stop high-pulse is generated (IC 378/12) which sets  $\overline{\text{SBE}}$  'low'.  $\overline{\text{SBE}}$  is received from the CPU which effects START to go 'low' (via 362/13) and the output logic to generate a short 'low' pulse COUNTER LOAD. By this the down counter is loaded with  $\text{NON} - 1$  again.

Now the initial state for burst-mode is set again. For frequencies below 8.388 kHz at the end of a single burst, the output logic sets DFS STOP to 'high'. By this a short reset-pulse (306/8) is generated in the signal synthesizer section setting the phase-accumulator output to the zero start condition. Furthermore the phase accumulator clock is disabled (305/2 = 'high') thus stopping the synthesizer action.

For cont burst mode the CPU isn't involved in the process of generating the control signals after first burst was started. This means that all control functions are performed by the output logic. As described in the sections above shortly before the end of the first burst the down counter is loaded with  $\text{NOFF} - 1$ , therefore subsequently the counter is decrementing  $\text{NOFF} - 1$  times until the signal BURST switches to 'low' again (by output FF 372), thus initiating the next cont burst cycle.




## 6.2. PLL / U1

In the frequency range above 2.147 MHz the primary signal is generated in the PLL. The PLL consists of a wide-band VCO, frequency divider, phase detector with loop filter and sine shaper.

## DAC

Frequency coarse adjustment in the range above 2.147 MHz is achieved with the DAC which gets the information from the CPU via the C-Bus, fine adjustment takes place via the PLL-loop by comparing the reference signal from the DFS with the VCO output divided by either 32 (= FM off) or 4096 (= FM on).



## Phase Detector

The phase detector IC 309 compares the signals PLLREF and VCO output and generates a DC-signal which value depends on the phase difference between them.

The integration circuit following the phase detector consists of the integrated circuit 312, the 10 k $\Omega$  resistor 619 and the capacitors 516, 521 and 522. The purpose of the integrator is to filter spikes and short deviations in order to prevent disturbances of the PLL control loop. Time constant for FM off mode is 47  $\mu$ s (619, 516), with FM on it is 0.5 s (619, 521, 522). Switching FM on and off is achieved with control signal PLL CNTL and switch 313/1, 2, 15. With FM-off the capacitors 521, 522 are continuously charged with OP-amp 311 according to the level at input 3 of the integrator. This effects a short lock-in time when FM is switched on, because the capacitors 521, 522 are always charged to the level according to the momentary frequency. The output of the integrator is passed via solder switch S6 and resistor 608 to the current summing point of the VCO.


The DAC for frequency coarse adjustment consists of the shift register IC 301 and the digital-analog converting circuit IC 302. The serial information from the CPU is received from the shift register, formed to a parallel information and fed to the parallel inputs of IC 302. The output of this circuit is buffered with OP-amp 303 and then passed via resistor 607 to the current summing point.

The last signal which is fed to the current summing point is generated in the modulator and passed via resistor 606. This FM MOD signal effects an amplitude modulation of the integrator — and DAC output signals at the current summing point, whereby the influences of these three signals in the summing point are weighted by the different values of the resistors 606, 607, 608. Lower resistance values effect a higher current going into the summing point thus giving a higher influence for the VCO. The highest current is delivered from the DAC via 607 (= 10K) followed by the phase detector output via 608 (= 75K) and the modulation signal FM MOD via 606 (= 365K).

### VCO

The VCO consists of the input buffer 304, a current mirror with two current sources 306, 307, 351, 353, 354 and 356 an amplifier 361, 362, 363, 380 and a comparator 364, 366, 367 and 368.

The two current sources generate the currents 'I' and '2I', whereby the value of 'I' depends on the current in the summing point, the relation between the two currents is exactly 1 : 2. The current '2I' is going via transistor 356 to the transistors 357, 358 which are controlled from the comparator output. During the rising ramp (a) transistor 358 is open and feeds the current '2I' to the capacitors and to the transistor 359 which draws the current 'I' from this point, thus the two capacitors 526, 527 are charged with the current 'I'. During the falling ramp (b) transistor 357 is open and leads the current of '2I' to ground. Because the second current source draws the current 'I' continuously from the two capacitors 526 and 527, they are now discharged until the negative threshold is reached.



The stage following the triangular wave generator is the sense amplifier consisting of the transistors 361, 362, 363 and 380. This amplifier has a very high input impedance ( $> 1 \text{ G}\Omega$ ), a total gain of 1 and supplies the inputs of comparator and sine shaper. The signals at these inputs have precisely the same phase as the signal at the capacitors 526, 527 and an amplitude of 2 Vpp.

The comparator consists of the differential stage 364, 366 and the TTL switching circuit 367, 368. The two signals to be compared are fed to the bases of the transistors 364 and 366. The collectors of these transistors are controlling the bases of the transistors 367 and 368 thus generating a square wave signal which is connected to the base of transistor 366 via resistor 655. This effects the comparing of the positive ramp of the triangular wave with the positive half cycle of the square wave and of the negative ramp with the negative half cycle.

When the positive ramp of the triangular wave at the base of transistor 364 reaches the upper threshold determined by the level of the square wave at the base of transistor 366, the comparator switches and with this the collector of transistor 364 becomes more negative. This effects the switching of transistor 357 to the conducting state. Thus the current  $I_1$  is drawn to ground, the capacitors 526 and 527 are discharged with the current  $I_1$  and the triangular signal turns over to the negative ramp.

The RFTTL output is supplied from the TTL switching circuit in the VCO (367, 368) via decoupling transistor 379. This signal is then formed in the signal conditioner 369, 371 and fed to the output via the two buffers 314/1, 2, 3 and 314/11, 12, 13.


#### Frequency divider

The frequency divider of the PLL is also supplied from the TTL-output of the VCO (IC 314/3). This circuit serves the purpose to divide the VCO output frequency by the factor 32 for FM off and 4096 for FM on. Dividing takes place in four steps with the two dividing circuits 316 and 317, the divided value is available at pin 6 of IC 318 (a) and fed to input 1 of phase detector IC 309. Switching over from dividing factor 32 to 4096 is achieved via the gates 318/1, 2, 3 and 318/8, 9, 10 with the signal PLL CNTL (b) which is 'low' for FM on and 'high' for FM off.

#### Sine shaper

With the sine shaper-consisting of the transistor array 320 and the transistors 372, 373 the triangular wave from the VCO is formed to a sine wave and fed to the output RF-SINE via the sine wave amplifier (transistors 374 - 378).

The triangular wave is attenuated with the resistors 696 and 697 to 0.4 V<sub>pp</sub> at the base of transistor 320/9, 10, 11. The base of the second transistor of this differential stage (320/6, 7, 8) is fixed to a constant level which is defined with potmeter 709 and resistors 707, 708. Because the operating point for this stage is adjusted such that the stage is overdriven with the tops of the triangular wave, the collectors (pins 11, 8) show a sine wave signal (see picture).



This principle of forming the triangular wave to a sine wave requires a stable and exactly defined operating point. Temperature drifts in the crystal of IC 320 effect a drift of the base-emitter voltages and with this a drift of the operating point which effects then a higher distortion of the sine wave signal at the output RF SINE.

In order to keep the crystal temperature of IC 320 constant, there is a temperature control circuit in the sine shaper which consists of the transistors 372, 373 and three transistors in IC 320. With potmeter 684 a base current is adjusted for transistor 320/12, 13, 14. The collector of this transistor controls the two parallel connected 'heating transistors' 320/1, 2, 3 and 320/3, 4, 5 — which produce a heating power of together approx. 0.3 W — via transistors 373 and 372.

In case of increasing crystal temperature in IC 320, the current through transistor 320/12, 13, 14 will also increase and reduce the heating power of transistors 320/1, 2, 3 and 320/3, 4, 5 via the transistors 373 and 372.

In this way there is a closed control loop which effects a crystal temperature of approx. 80 — 85° C remaining absolutely constant — this is essential for a proper sine wave forming.

The output signals of the differential amplifier 320/9, 10, 11 and 320/6, 7, 8 are fed to the bases of transistors 374 and 376. After amplification in this sine output amplifier the output amplitude is adjusted with potmeter 721 and passed to the modulator via output RF SINE.

### 6.3. MODULATOR/U1

#### Voltage Conditioner


The DFS-signals (sine, triangle, rising sawtooth, falling sawtooth) are routed via the voltage conditioner to be conditioned to the final signals e.g. from the bipolar rising sawtooth to the unipolar positive sawtooth signal.

The resistance network of this voltage conditioner and its analogue multiplexer (301) build up a voltage divider combination with selectable attenuation and dc-shifting. The path a1 (fig. b) is switched on at sinewave and triangular wave, path a2 at negative sawtooth and path a3 at haversine or positive sawtooth waveforms respectively (due to the inverting OUTPUT AMPLIFIER/U1 the polarities of the signals in the MODULATOR are invers with respect to the generator output signals).

The attenuations of a2 and a3 are double of that of a1, their positive or negative dc-shifting, respectively, comes to half the value of the resulting amplitudes of the signals. Both these facts result in unipolar sawtooth and haversine signals and in equal zero to peak amplitudes of all signals derived from the DFS waveforms.

#### Diode Switches

The principle of operation of the DIODE SWITCHES 1 and 2 is shown in the figure below (fig. a)



$V_i$  = input signal voltage  
 $V_o$  = output signal voltage  
 $V_d$  = diode forward voltage  
 $V_{SW}$  = switching voltage

fig. a

If  $V_{SW}$  is negative, D5 and D6 are open and the bridge diodes are closed.  $R_o$  pulls the output voltage to 0 volts.

If  $V_{SW}$  is positive, diodes D5 and D6 are closed, the diode bridge D1 ... D4 is open, and the voltage relations are


$$\begin{aligned}
 V_{d1} + V_i &= V_{d2} + V_o \\
 \text{and } V_i - V_{d3} &= V_o - V_{d4}
 \end{aligned}$$

So the output voltage  $V_o$  is

$$\begin{aligned}
 V_o &= V_i + V_{d1} - V_{d2} = V_i + V_{d4} - V_{d3} \\
 \underline{V_o} &= \underline{V_i} \quad (\text{if } V_{d1} = V_{d2} \text{ and } V_{d3} = V_{d4})
 \end{aligned}$$

Differences of the diode voltages can cause an offset which is compensated at the general offset adjustment of the generator. The load resistance for the signal voltage source ( $V_i$ ) is  $R_o$  shunted by  $R_p$  and  $R_n$ .

Besides the selection of the right signal paths the DIODE SWITCHES perform the signal keying at BURST mode (SWITCH 1 only) and GATING mode. DIODE SWITCH 1 is driven by a balanced, non saturated differential driver (358, 360) which ensures extreme short delay required for the phase coherent signal keying at BURST mode. DIODE SWITCH 2 is driven by two coupled transistor switches operating in opposite directions (362, 364 and 363, 366).



MODULATOR/U1

### Switch control

Both the DIODE SWITCHES are controlled by logical control signals and the BURST or GATING signals, all them logically linked in the SWITCH CONTROL circuit, a combination of NOR-gates. The linkage of the control signals is explained by the equivalent logical equations below (+ = OR, x = AND):

$$\begin{aligned} \text{GATE1} &= (2 \text{ MHz SWITCH} + \text{ SQUARE}) \times (\text{INT GATE} + \text{int. gating sign.}) \times \text{ext. gating sign.} \times \text{BURST} \\ \text{GATE1} &= 2 \text{ MHz SWITCH} \times \text{ SQUARE} \times (\text{INT GATE} + \text{int. gating sign.}) \times \text{ext. gating sign.} \end{aligned}$$

Represented as a combination of contacts:




fig. c

#### Symbols:

- 2 MHz SWITCH: HIGH (ON) if frequencies < 2.147 MHz (control line).  
 SQUARE: HIGH (ON) if SQUARE waveform selected (output pin 14 of shift register 302).  
 INT GATE: HIGH (ON) if any other modulation mode is selected than INTERNAL GATING (output pin 7 of shift register 318).  
 int. gating sign.: H and L (ON and OFF) change with the internal gating signal (square wave output of the modulation generator).  
 ext. gating sign.: H and L (OFF and ON) change with the external gating signal. Kept LOW (ON) if external gating mode is switched off.  
 BURST: H and L (ON and OFF) changes with the internal burst cycles. Kept HIGH (ON) if BURST mode is switched off. It is the inversion of the control line: BURST.  
 GATE1/2: Driving signals for the DIODE SWITCHES 1 and 2 (= output signals of the SWITCH CONTROL circuit, see fig. b). HIGH: SWITCH ON, LOW: SWITCH OFF.

### Amplitude Modulator

AM is performed by multiplication. The multiplier module (305) multiplies the carrier signal (any generator signal except pulses) by the internal or external modulation signal. The modulation signal is superposed by a dc-component (pin 8). The level of this dc-"offset" with respect to the ac input amplitudes (pin 9 and pin 4) determines the proportion between the amplitudes of carrier and both the sidebands. At 0 volts dc the carrier would be suppressed (balanced modulation).

The function of the complete AMPLITUDE MODULATOR circuit is represented by the following equation (for sinusoidal voltages):

$$u_{\text{out}} = k \times (E_c \cos \omega_c t \times (V_{dc} + E_m \cos \omega_m t))$$

- Symbols:  $u_{\text{out}}$  = modulated output signal  
 $E_c \cos \omega_c t$  = carrier signal  
 $E_m \cos \omega_m t$  = modulation signal }  $E$  = amplitude  
 $V_{dc}$  = dc voltage (at pin 8)  
 $k$  = scaling factor, resulting from the parameters of the complete AM-modulator circuitry

Evaluated:

$$u_{out} = k \times (E_c V_{dc} \cos \omega_c t \times E_m E_m (\cos \omega_c t \times \cos \omega_m t))$$

$$= k \times E_c (V_{dc} \cos \omega_c t + E_m \times 0.5 (\cos(\omega_c - \omega_m)t + \cos(\omega_c + \omega_m)t))$$

carrier                      lower sideband                      upper sideband

The right relations between  $k$ ,  $V$  and  $E$ , obtained by suitable dimensioning and proper calibration, result in

$$u_{out} = 0.5 E_c (\cos \omega_c t + 0.5 m (\cos(\omega_c - \omega_m)t + \cos(\omega_c + \omega_m)t))$$

( $m = E_m/E_m \text{ max} = \text{depth of modulation}$ )

### Modulation Oscillator

The main unit of the MODULATION OSCILLATOR is the function generator module (310) with adjustable frequencies by changing load capacities and/or the load current ( $f \sim 1/C$ ). Two relays (815, 816) switch the frequency ranges: from six capacitors they can select three different combinations as frequency determining capacities. Within the range selected the frequency fine setting is permitted by an active DAC (308). This DAC operates as digitally controllable current sink which sets directly the frequency determining current.

The sinewave output signal is routed via a buffer amplifier (309 (1)), which gives also possibilities for amplitude and offset calibrations, to the AMPLITUDE CONTROLLER, a circuit consisting of a DAC and an operational amplifier (311, 309 (2)). The DAC is applied as controllable feedback resistor network for the operational amplifier.

The rectangular voltage output of the function generator (pin 11) is connected to the SWITCH CONTROL circuit. It is active as internal gating signal if the INTERNAL GATING mode is switched on.

### Control of the Modulator Unit

Four 8-STAGE SHIFT-AND-STORE BUS REGISTERS, joint in cascade (302 → 316 → 313 → 307; see fig. 39), distribute the control messages of the CPU (SDA) — 32 bits serial, coming in via register module 302 — to the corresponding switches and control modules respectively. With strobe STR9 going HIGH that string of bits clocked in by the serial clock (SCL) is transferred to the outputs of the register modules in parallel (latched) and, thereby, to the switches, multiplexers, gates etc.

Register modules 307 and 313 hand over the control bits for fine setting of frequency and amplitude of the modulation oscillator. Register modules 302 and 316 hand over the control bits for selection of the different signal paths, modulation modes and modulation frequency ranges (see tables below):

| 4 | 5 | 6 | 7 | 14 | 13 | 12 | 11 |                              |
|---|---|---|---|----|----|----|----|------------------------------|
|   |   |   |   |    | 1  |    |    | BURST mode ON                |
|   |   |   |   | 0  | 1  |    |    | BURST mode AND neg. PULSE ON |
| 0 | 1 | 0 | 1 | 0  | 1  |    |    | or                           |
| 0 | 1 | 1 | 0 | 1  | 1  |    |    | or                           |
| 0 | 0 | 1 | 1 | 0  | 1  |    |    | or                           |
| 1 | 1 | 1 | 1 | 0  | 1  |    |    | or                           |
| 0 | 1 | 1 | 0 | 0  | 1  |    |    | or                           |

Shift register 302

| 4 | 5 | 6 | 7 | 14 | 13 | 12 | 11 |                          |
|---|---|---|---|----|----|----|----|--------------------------|
|   |   |   |   |    | 1  | 1  |    | range 10 Hz... 1 kHz*    |
|   |   |   |   |    | 0  | 1  |    | range 1 kHz... 10 kHz*   |
|   |   |   |   |    | 0  | 0  |    | range 10 kHz... 200 kHz* |
| 1 | 1 | 1 | 1 | 1  | 1  | 1  |    | MODULATION OFF           |
| 0 | 0 | 1 | 1 | 1  | 1  | 1  |    | internal AM              |
| 1 | 1 | 0 | 1 | 1  | 1  | 1  |    | internal FM              |
| 1 | 1 | 1 | 0 | 1  | 1  | 1  |    | internal GATING          |
| 0 | 0 | 1 | 1 | 1  | 1  | 0  |    | external AM              |
| 1 | 1 | 0 | 1 | 1  | 1  | 0  |    | external FM              |
| 1 | 1 | 1 | 1 | 0  | 0  | 0  |    | external GATING          |

\* modulation frequency

Shift register 316



## 6.4. PULSE GENERATOR/U1

### 1. Square wave generator

According to fig. 30 (over-all block diagram) and fig. 36 (circuit diagram) the section of the PULSE GENERATOR, which generates the primary square wave, fed to the AMPLIFIER, comprises the following subsections:

- ZERO CROSSING DETECTOR, IC 301,
- CONTROL CIRCUITRY, IC 302, 303, 305, Transistor 351,
- SQUARE WAVE CONDITIONER, Transistors 352 . . . 355.

#### Zero crossing detector

By resistor 602, 605, 698 a slight hysteresis is implemented for accurate transitions without glitches at the zero crossings of the DFS input signal. A L (= low) level "SQUARE BURST" control signal at pin 5 inactivates IC 301, i.e., the output is set H (= high), but this function is only used in the BURST mode.

#### Control circuitry

Control signal states:

"2MHz SWITCH", IC 303-pin 1:

H, if frequency  $\leq 2.147$  MHz

L, if frequency  $> 2.147$  MHz

"POSITIVE PULSE BURST",

IC 305-pin 2:

H for non-BURST mode

"PULSE SEL":

L for rectangular waveform

H else

"BURST"

IC 302-pin 1, IC 304-pin 11:

L for non-BURST mode

H for rectangular waveforms

L else

Exclusive OR gate IC 302/1, 2, 3 is routing the ZERO CROSSING OUTPUT signal inverted, if a rectangular waveform is selected, to the MUX, IC 303. The MUX is controlled by the "2MHz SWITCH" control signal at pin 1.

Functional table of IC 303/SN 74S258N:

| Pin 1 | Pin 2,5 | Pin 3,6 | Pin 4,7 |
|-------|---------|---------|---------|
| L     | X       | L       | H       |
| L     | X       | H       | L       |
| H     | L       | X       | H       |
| H     | H       | X       | L       |

From this table and the "2 MHz SWITCH" definition results, that up to 2.147 MHz the signal from IC 302/pin 3 or above 2.147 MHz the "RF TTL" signal from the PLL is passed inversely through the MUX to IC 305/pin 1. There it is handed with (PULSE SEL) + (BURST) = L at pin 2. The NAND gate output is handed with "POS PULSE BURST" = H. The resulting signal at pin 6 is fed to the SQUARE WAVE CONDITIONER.

The various internal signals in the generator square wave BURST mode ( $N = 2$ ) are depicted in the BURST mode pulse diagram. Leading positive spikes of the IC 305/pin 6 output signal, respectively negative spikes of the generator output bursts are set to zero by adjusting trimmer 603. By this trimmer the switch-over points of the ZERO CROSSING DETECTOR with respect to the zero-crossings of the sine-wave input signal can be time shifted. Trailing spikes of the output bursts are avoided by the function of the "SQUARE BURST" control signal at IC 301/pin 5: By the "SQUARE BURST" L pulse the duration of the coinciding ZERO DETECTOR OUTPUT H pulse is slightly increased, thus ensuring that at the generator output the SQUARE WAVE burst stops with a positive going transition to zero.

The SQUARE WAVE CONDITIONER converts the TTL signal at IC 305/pin 8 to a square wave, accurately in shape and amplitude (about 2,8 Vpp). Trimpots 624 and 627 are adjusted for accurate positive and negative amplitudes at the generator output.

## 2. Rectangular pulse wave generation

The signal processings in the ZERO CROSSING DETECTOR and the CONTROL CIRCUITRY sections are the same as in the square wave mode with the exceptions, depicted in the pulse diagram table, for negative PULSE BURSTS.

The IC 305/pin 6 output TTL signal is routed to the PULSE TRAIN CONDITIONER, which converts this signal to a square wave output current ( $\approx 3\text{ns SQUARE}$ ) shaped accurately. The amplitude of this square wave is determined by the dc collector currents of transistors 363 and 364, which are controlled by shift register IC 304 via DAC IC 306 and operational amplifiers 307, 308 and 309.

The dc current range is about 10 mA, corresponding to a 1 Vpp open-loop output amplitude, to 100 mA, corresponding to 10 Vpp. By the DC GENERATOR in the AMPLIFIER section the resulting square wave output voltage is shifted to a unipolar positive or negative rectangular pulse train, depending on the selected waveform pos. pulses or neg. pulses.

## 3. TTL output voltage generation

The output voltage of IC 305/pin 11 is fed to the TTL VOLTAGE CONDITIONER stage with the transistors 356, 357, 358. The TTL OUTPUT signal is a continuous wave also in the generator BURST mode, this signal is not affected by the transistor 351 output.

## 6.5. AMPLIFIER / U1

As depicted in the over-all block diagram, fig. 30, the **AMPLIFIER** comprises the sub-sections **AMPLITUDE CONTROLLER**, **POWER AMPLIFIER**, **STEP ATTENUATOR** and **DC GENERATOR**.

**Amplitude controller**

Corresponding to fig. a, the input voltage is 1.4 Vpp. for sine, triangle and square waves, 0.7 Vpp for the other wave forms.

The ac currents fed into the emitters of 365 and 368, representing current sinks, are proportional to the total effective conductance between buffer output and current sinks. There are  $2 \times 7$  conductances, namely  $y_1, y_2, \dots, y_7$  and  $y_1', y_2', \dots, y_7'$  with binary weights 1, 2, 4, ..., 64. Two additional conductances  $y_8$  and  $y_8'$ , weighted 83, complete the switched conductance ladder. Depending on the programmed voltage pp, some of the conductance pairs  $y, y'$  are connected by the switches  $S_1 \dots S_8$  and  $S_1' \dots S_8'$  with the current sinks.

**Example:**

for 10 Vpp, switches  $S_3, S_6, S_7$  and  $S_3', S_6', S_7'$  are closed. The effective conductance is then about  $y = 1/(134 \text{ ohm})$ . If 20 Vpp is programmed. All switches excl.  $S_2, S_4$  and  $S_2', S_4'$  are closed, resulting in  $y = 1/(67.2 \text{ ohm})$ . The generator open loop output voltage is  $V_0 = ayV_i$  where  $a = 960 \text{ ohm}$  in the 2.1 to 20 Vpp range.

Thus  $y_0 \approx 20 \text{ Vpp}$ , if  $y = 1/(67.2 \text{ ohm})$ .

Resistor 632 is lowering the input impedance of the emitter current sinks, thus improving the amplitude-controller linearity.

In the real circuitry, see fig. 38, the switches are realized by the diodes 424 ... 439. In the switch-off state, the diodes are biased reversely to about 1.3 V by transistors, e. g., diode 424 by transistor 333. Primary control is performed by shift register 302 via CMOS switches 314, 315.




fig. a

### Power amplifier

As depicted in fig. b, the **POWER AMPLIFIER** is a complementary collector-output type. At frequencies above some hundred Hz the ac input voltage is passed through the input buffer and C536, C 537 directly to the base of transistors 378 and 381, converted to ac currents by 378 ... 383 and fed through 385, 386, 387 and 390, 391, 392 respectively to the internal 50 Ohm output resistor, made up by the resistors 781 ... 786.

For high dc stability, the difference of the emitter dc currents (378, 379, 380 vs 381, 382, 383), which is about zero, is kept constant by an automatic control loop including OP 303 and transistor 377.

This loop is forcing  $i_1 = i_2$  in the frequency range from dc to some hundred Hz. Trimmer 700 is adjusted for flat amplitude response in the take-over range of the direct drive via C536 and C537.





fig. b

### DC generator


Primary control of the **DC GENERATOR** is performed by the DAC, Pos. 307. The DAC is set by shift register 306 to output currents  $I_0$  from 0 to about  $200 \cdot I_{ref}/255 = 0.884$  mA proportional to the decimal equivalents 0 ... 200 of the shift register binary output. If the decimal equivalent is 100, i. e. DC = 0V,  $I_0 = 0.442$  mA is compensated by the current through resistors 770, 771. 771 is adjusted for DC = 0V at the generator output. Hence, in this situation no current is drawn from the input (pin 6 of OP 308) of the dc generating circuitry. If the shift register output is 0 or 200, i. e. DC = -10 V or +10 V respectively, the asymmetry of the emitter voltages (transistors 394, 395 vs 397, 398 is  $U = I_{0max} R/4 = 5.5$  V ( $I_0 = 0.884$  mA,  $R = 24.9$  kOhm; resistors 777 ... 780), giving a dc voltage at the generator output of  $4 \cdot U \cdot RL/r = 10$  V absolute. ( $RL = 50$  Ohm,  $r = 110$  Ohm; resistors 868, 869 etc.). The corresponding output current of the DC GENERATOR is  $4 \cdot U/r = 200$  mA.

The multiplexed address/data bus (AD0 ~ AD7) of the processor 318 supplies the address inputs A0 ~ A7 of the PROM-memory 315 via the address latch 314 (74LS363), the inputs A8 ~ A13 are supplied directly from the processor (P20 ~ P25). Data from the PROM is fed from the outputs 0<sub>0</sub> ~ 0<sub>7</sub> via the lines AD0 ~ AD7 directly to the processor, this transfer is controlled with the output PSEN from the processor driving the input OE of the PROM.

The memory circuits 324 and 325 serve the storing of the parameter sets (store function). Communication with them takes place via the internal serial I<sup>2</sup>C bus which consists of a data line SDA and a clock line SCL. The principle of the data transfer between processor and the RAM-memories is shown in the following diagram.




The line SDA and the line SCL for the C-bus (output T x d of the processor) serve the communication with the remaining units. The data information of the line SDA is clocked into the shift register of each unit, the according strobe signal following this data sequence latches the data information in the selected shift register and presents the transmitted information in parallel form at the output lines of this circuit. The required strobe signals are generated with the strobe-decoder 312 which is controlled again from the processor via the lines P20 – P23 and the signal  $\overline{WR}$ .




Internal communication via  
I<sup>2</sup>C - and C-bus

Converting the serial information to a parallel one the parallel output presents the decoded commands.



The clock signals for processor and IEC controller as well as a 100 kHz signal for the internal timer are generated in the 'clock generator' circuitry. This part of the CPU consists of the crystal 801, the inverter 317 and the decimal counter 319. The 10 MHz clock from the inverting buffer is fed to input XTAL 1 of the processor, furthermore divided by 5 with the decimal counter 319 and then fed to the IEC-controller 306. After further dividing by 20 the output 7 of the counter delivers the 100 kHz signal T0 for the timer.



IC 319 = Decimal counter

clock generation


Remote control of the PM 5193 follows via the IEC-interface which consists of the controller 306, the bus drivers 301 - 304, the buffers 307, 308 and the shift registers 309 - 311. Input data (control commands) from the IEC-bus connector are fed to the data bus AD0 - AD7 via the bidirectional bus drivers 303 and 304 and buffer 307. Output data (learn- and identification mode) are accordingly fed to the IEC-bus via buffer 308 and the bus drivers 303 and 304. Data direction and enable of the buffers are controlled by the IEC-bus controller 306 via the output Ota (other talk address) and by the processor with the signal 'strobe 14'.



## 6.7. KEYBOARD DISPLAY UNIT / U3

Unit 3 of the synthesizer PM 5193 contains LEDs keys and display elements with their concerning driver/decoder circuits. Data transfer from the CPU to the keyboard/display unit takes place via the C-bus (SDA, SCL, Strobe 1 — 5), input data from the keyboard is sent as a sequence of 12 pulses from the keyboard encoder 353 via the line SKC to the CPU. The key 'LOCAL' is directly led to the IEEE/IEC interface on unit 2 via line GTL.


Display data are sent in 34 bit data blocks via the C-bus to the according part of the display unit, selection (= addressing) of this part is done with one of the strobe signals STROBE 1 — STROBE 5. During the data transfer from the CPU to the keyboard/display unit the according strobe line is set and a 34-bit data block is loaded into the shift register with the clock signal SCL. The last bit of the data input shifts the complete data set into the latch register and therewith to the display elements/LEDs via the buffer stage.



Each of the five strobe lines controls the data transfer to one of the display groups:

- STROBE 1 display circuit 408 for amplitude, Vdc, address and the LEDs in the keys 'Vrms' and 'ADDRESS'
- STROBE 2 display circuit 407 for modulation parameters and the LEDs in the keys 'FREQ (kHz)' and 'TIME(s)'
- STROBE 3 display circuit 406 for frequency display (right part) and the LEDs in the keys 'START' and 'STOP'
- STROBE 4 display circuit 405 for frequency displays (left part)
- STROBE 5 LED driver circuit 352

Voltage supply for the LEDs and displays comes from the + 5 V which is reduced to + 3 V (= VL) by means of the transistor 301 and the resistors 602 and 603




the transistor 301 is placed behind the front plate at a spacing piece beside the socket TTL OUT.



Brightness of the LEDs/displays is adjusted with a reference voltage at the inputs BC (= brightness control) of the driver circuits. These reference voltages are derived from the + 20 V supply by means of the resistors 604 – 608 feeding currents into the BC-inputs.

Input from the keyboard takes place with the help of the keyboard encoder IC 353 (= SAA 3007) which controls the 8 x 8 keyboard matrix and sends the keycode in serial form from the output REMO via line SKC to the CPU. During the rest condition the sense lines SEN0 – SEN6 are 'high', the drive lines of the matrix DRV0 – DRV6 are 'low', the last drive line is fixed to ground.

When a key is pressed the according sense line is forced to 'low', the internal logic of the encoder starts the scan of the matrix and transmits a sequence of 12 pulses whereby the distance between two pulses means binary "0" or "1".




Each time a key is pressed such a bit sequence must be measurable at line SKC (= pin 10 of the CIS connector). The toggle bits of this message are incremented by 1 each time when a key is pressed. Thus it is possible to distinguish between a key being pressed several times or once for a longer time.

The device address is fixed to "000" and the last 6 bits show the following pattern by pressing the corresponding key

| Key       | Connection between | Key code | Key     | Connection between | Key code |
|-----------|--------------------|----------|---------|--------------------|----------|
| ↖         | DRV0 - SEN0        | 000000   | LIN     | DRV1 - SEN3        | 011001   |
| ↗         | DRV0 - SEN1        | 001000   | LOG     | DRV1 - SEN4        | 100001   |
| ↘         | DRV0 - SEN2        | 010000   | TIME(s) | DRV1 - SEN5        | 101001   |
| ↙         | DRV1 - SEN0        | 000001   | SINGLE  | DRV2 - SEN3        | 011010   |
| ↘         | DRV1 - SEN1        | 001001   | CONT    | DRV2 - SEN4        | 100010   |
| ↙         | DRV1 - SEN2        | 010001   | HOLD    | DRV2 - SEN5        | 101010   |
| ↖         | DRV2 - SEN0        | 000010   | Vdc     | DRV3 - SEN3        | 011011   |
| ↗         | DRV2 - SEN1        | 001010   | Vpp     | DRV3 - SEN4        | 100011   |
| ↘         | DRV2 - SEN2        | 010010   | ΔLEVEL  | DRV3 - SEN5        | 101011   |
| AC OFF    |                    |          |         |                    |          |
| START     | DRV3 - SEN0        | 000011   | +/-     | DRV4 - SEN3        | 011100   |
| Hz/kHz    | DRV3 - SEN1        | 001011   | dBm     | DRV4 - SEN4        | 100100   |
| -STEP     | DRV3 - SEN2        | 010011   | -STEP   | DRV4 - SEN5        | 101100   |
| STOP      | DRV4 - SEN0        | 000100   | ADDRESS | DRV5 - SEN3        | 011101   |
| ΔFREQ     | DRV4 - SEN1        | 001100   | Vrms    | DRV5 - SEN4        | 100101   |
| +STEP     | DRV4 - SEN2        | 010100   | +STEP   | DRV5 - SEN5        | 101101   |
| OFF       | DRV5 - SEN0        | 000101   | STO1-9  | ↓ - SEN7           | 111111   |
| INT       | DRV5 - SEN1        | 001101   | RCL0-9  | DRV6 - SEN7        | 111110   |
| EXT       | DRV5 - SEN2        | 010101   | RUBOUT  | DRV4 - SEN7        | 111100   |
| GATE      | DRV6 - SEN0        | 000110   | 0       | DRV0 - SEN6        | 110000   |
| AM        | DRV6 - SEN1        | 001110   | 1       | DRV1 - SEN6        | 110001   |
| FM        | DRV6 - SEN2        | 010110   | 2       | DRV2 - SEN6        | 110010   |
|           |                    |          | 3       | DRV3 - SEN6        | 110011   |
| FREQ(kHz) | ↓ - SEN0           | 000111   | 4       | DRV4 - SEN6        | 110100   |
| %         | ↓ - SEN1           | 001111   | 5       | DRV5 - SEN6        | 110101   |
| DEV(kHz)  | ↓ - SEN2           | 010111   | 6       | DRV6 - SEN6        | 110110   |
|           |                    |          | 7       | ↓ - SEN6           | 110111   |
| BURST     | DRV0 - SEN3        | 011000   | 8       | DRV0 - SEN7        | 111000   |
| ON cycl.  | DRV0 - SEN4        | 100000   | 9       | DRV1 - SEN7        | 111001   |
| OFF cycl. | DRV0 - SEN5        | 101000   | "•"     | DRV2 - SEN7        | 111010   |
|           |                    |          | ENTER   | DRV3 - SEN7        | 111011   |

The clock for the keyboard encoder is generated with the ceramic resonator 860. During the rest condition — i. e. no key is pressed — there is no signal at input 11 or 12 of the keyboard encoder. When any key — except LOCAL — is pressed, the clock supply will be activated and a signal with a frequency of 455 kHz and an amplitude of 4,5 Vpp can be measured at pin 11 or 12. By pressing a key only once for a short moment the clock will be switched on for approx. 170 ms., pressing a key for longer will keep the clock supply switched on as long as the key is pressed.

The line ENK (enable keyboard) at pin 4 of the CIS-connector has a special meaning for the keyboard input. During a running sweep it is not possible to press any key except MOD OFF, SINGLE, CONT or HOLD. These keys contain one more switch contact which is commonly connected to line ENK, only this line is supervised by the processor during a running sweep.



When operating one of these keys the line ENK and the according sense line are forced to 'Low' which effects the keyboard encoder to scan the matrix and to send the key code via the line SKC to the CPU. Only when the processor has recognized via ENK that one of the four keys was pressed, the normal keyboard input via line SKC is started.

## 7. ACCESS TO PARTS

### 7.1. TOP AND BOTTOM COVERS (DISMANTLING THE INSTRUMENT)

Before opening the instrument unplug mains connector, take note of chapter 1.5..

- Loosen the cross-slotted screws (A) (Fig. 7-1) at the rear
- Pull top cover (B) as shown in figure 7-1.
- The procedure to remove the bottom cover (C) is the same as above.




Fig. 7-1

### 7.2. FUSE, MAINS TRANSFORMER

For mains voltage setting and fuses and the assigned safety instructions see chapter 2.

### 7.3. UNIT 1 AND UNIT 2

For access to the upper side of unit 2 and the bottom side of unit 1 it is only necessary to remove the top cover respectively the bottom cover of the instrument (see chapter 7.1.).

To reach the upper side of unit 1 and the bottom side of unit 2 proceed as follows:

- Unplug the connector (G) (Fig. 7-5) on the right hand side of unit 2.
- Remove 2 screws (A) (Fig. 7-5) at the sides of the instrument.
- Lift the pcb as arrow (C) shows in Fig. 7-5. (If it is heavy to move the pcb, loosen the screws at the pivot a little bit.).
- Fixing unit 2 in an upright position insert screw (A) in position (H) (Fig. 7-5).
- The other steps shown in fig. 7-5 are not necessary to reach unit 1 + 2.

### 7.4. FRONT-PANEL EDGING

- Remove covers (chapt. 7.1.).
- Lift the profile ornament (A) (Fig. 7-2) with a small screw driver.
- Remove the screws (B) (Fig. 7-2).
- Remove the edging (C) (Fig. 7-2).
- For the bottom side the same procedure applies.




Fig. 7-2

- Remove screws (B) (Fig. 7-3)
- Remove side pieces (A) (Fig. 7-3)




Fig. 7-3

## 7.5.

## TEXT PLATE

The text plate (A) (Fig. 7-4) is fixed by three parts of double-sided adhesive tape (B) (Fig. 7-4)

- To remove the text plate insert carefully a screwdriver near the tapes and move the screwdriver as shown in Fig. 7-4.
- Steps described in chapters 7.1 and 7.4. are necessary before.





Fig. 7-4

## 7.6. UNIT 3 (KEYBOARD AND DISPLAY)

At first steps described in chapters 7.1., 7.4. and 7.5. must be done

- Unplug connector (C) (Fig. 7-5)
- Loosen all screws (F) (Fig. 7-5) at the front of the instrument
- Pull carefully frontplate (E) (Fig. 7-5) forwards, take care of the wires of the BNC-connectors and the main switch
- Remove unit 3 (D) (Fig. 7-5)
- The other steps shown in this figure are not necessary to reach unit 3.



## 7.7. CARRYING HANDLE

- Lift the carrying handle.
- Prise off carefully both plastic profile strips next to the handle in the similar way as the profile ornament of the front-panel edging shown in Figure 7-2.
- Loosen cross-slotted screws of the holder for handle.

## 7.8. HANDLE ASSEMBLY FOR RACK MOUNTING

- Remove top and bottom covers as described in chapter 7.1.
- Loosen screws (B) (Fig. 7-6).
- Remove side piece (C).
- Fit handle (A), refit screws (B).
- For the right hand side the same procedure applies.
- Close the instrument





Fig. 7-6

## 7.9. VIEW INTO THE OPEN INSTRUMENT



PM 5193 without top cover

## 8. CHECKING AND ADJUSTING

### 8.1. GENERAL INFORMATION

The following information provides the complete check and adjustment procedure for the instrument. As various control functions are interdependent, a certain order of adjustment is often necessary. The procedure is, therefore, presented in a sequence which is best suited to this order, cross-reference being made to any circuit which may affect a particular adjustment.

Before any check, the instrument must attain its normal operating temperature.

- Warm-up time under average conditions is 30 minutes.
- Adjustments should be made after 2 hours
- Ambient temperature ( $23 \pm 1$ )°C
- Mains voltage, nominal values  $\pm 10\%$
- The cabinet must be closed.\*
- Where possible, instrument performance should be checked before an adjustment is made.
- All limits and tolerances given in this chapter are calibration guides, and should not be interpreted as instrument specifications unless they are also published in chapter 1.2. of the Operating Manual.
- Tolerances are given for the instrument under test and do not include test equipment error.
- If not explicitly stated otherwise, the voltage potentials refer to the relevant contact measured against measuring earth.

### 8.2. RECOMMENDED TEST EQUIPMENT

The following instruments are necessary to provide check and adjustment of the PM 5193

- 50  $\Omega$  termination resistor PM 9581 (1 W)
- wide band oscilloscope ( $t_r \leq 1$  ns)
- DC-voltmeter: resolution  $\leq 100 \mu\text{V}$  e. g. PM 2528
- counter 50 MHz, interval-measurements, 8 digits resolution, e. g. PM 6665
- spectrum analyzer e. g. Takeda Riken 4132
- rms voltmeter: resolution 1 mV,  $f_{\text{max}} = 3$  MHz e. g. Fluke 8920 A; the connection cable together with the termination resistor must have an impedance of exactly 50  $\Omega$
- distortion meter e. g. PM 6309
- power meter e. g. HP438A with probes HP8482A and HP8484A
- modulation meter e. g. Rhode + Schwarz FAM
- service kit  
consisting of notch filter 100 kHz, low pass filter 5 kHz, adjustment covers and two adapter cables; to be ordered from SC Hamburg without service code number


- \* For adjustments special covers with holes for the adjusting elements are required. This parts part are included in the service kit.



8.3. TABLE OF CHECKS AND ADJUSTMENTS


| Step                           | Objective                           | check<br>= = = | operation parameters<br>settings                                             | adjusting elements    | measured value,<br>value to be adjusted | test point, output<br>measuring instruments | open<br>output/<br>50Ω term. | comment                                                                                                                                |
|--------------------------------|-------------------------------------|----------------|------------------------------------------------------------------------------|-----------------------|-----------------------------------------|---------------------------------------------|------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| <b>POWER SUPPLY ADJUSTMENT</b> |                                     |                |                                                                              |                       |                                         |                                             |                              |                                                                                                                                        |
| 1                              | +5 V supply                         | c              | ~1kHz/10Vpp                                                                  | —                     | 5 ±0.25 V                               | T1/6, DC-voltmeter (DVM)                    | —                            |                                                                                                                                        |
| 2                              | +10V supply                         | c(a)           | ~1kHz/10Vpp                                                                  | 612/615, power supply | ±10 ±0.1 V                              | T1/1, 2, DC-voltmeter (DVM)                 | —                            |                                                                                                                                        |
| 3                              | +20V supply                         | c(a)           | ~1kHz/10Vpp                                                                  | 604/609, power supply | ±20 ±0.2 V                              | T1/3, 4, DC-voltmeter (DVM)                 | —                            |                                                                                                                                        |
| <b>DFS ADJUSTMENT</b>          |                                     |                |                                                                              |                       |                                         |                                             |                              |                                                                                                                                        |
| 4                              | Frequency adjustment                | a              | f <sub>0</sub> /1MHz/5Vpp                                                    | 505, DFS unit 2       | 1 MHz ±0.3 Hz                           | OUTPUT connector, counter                   | 50 Ohm                       |                                                                                                                                        |
| 5                              | DFS-glitches                        | a              | ~100kHz/10Vpp<br>see comment                                                 | 676/689, DFS unit 2   | minimum AC level                        | OUTPUT connector, notch filter              | 50 Ohm                       | the generator frequency must be exactly the same as the frequency of the notch filter                                                  |
| <b>DC-ADJUSTMENT</b>           |                                     |                |                                                                              |                       |                                         |                                             |                              |                                                                                                                                        |
| 6                              | DFS DC-offset                       | a              | ~1kHz/10Vpp                                                                  | 693, DFS unit 2       | 0 ±1 mV                                 | T20 unit 1, DC-voltmeter                    | —                            |                                                                                                                                        |
| 7                              | DC-generator voltage                | a              | ~1kHz/10Vpp/+10VDC/AC OFF                                                    | 771, amplifier unit 1 | +9.9 V±5 mV                             | OUTPUT connector, DC-voltmeter              | open                         |                                                                                                                                        |
| 8                              | DC-generator voltage                | a              | ~1kHz/10Vpp/0VDC/AC DEF                                                      | 769, amplifier unit 1 | 0 ±5 mV                                 | OUTPUT connector, DC-voltmeter              | open                         |                                                                                                                                        |
| 9                              | offset, amplifier preliminary stage | a              | ~1kHz/10Vpp/Burst not triggered                                              | 809, amplifier unit 1 | 0 ±1 mV                                 | T14 amplifier, DC-voltmeter                 | —                            |                                                                                                                                        |
| 10                             | offset difference                   | a              | ~1kHz/3, 2Vpp/Burst not triggered                                            | 874, amplifier unit 1 | } < 2 mVpp                              | T17 amplifier, oscilloscope                 | —                            | these two AC-amplitudes must be switched alternately and very fast (e.g., with an IEC-bus controller) in order to get a visible signal |
| 11                             | offset difference                   | a              | ~1kHz/6, 4 Vpp/—                                                             | —                     |                                         |                                             |                              |                                                                                                                                        |
| 12                             | output offset                       | a              | ~1kHz/5Vpp/Burst not triggered                                               | 666, amplifier unit 1 | 0 ±10 mV                                | OUTPUT connector, DC-voltmeter              | open                         |                                                                                                                                        |
| 13                             | output offset                       | c              | ~1kHz/Burst not triggered step output level from 3Vpp-20Vpp, step width 1Vpp | —                     | 0 ±40 mV                                | OUTPUT connector, DC-voltmeter              | open                         | if the offset value is outside the limit of ±40 mV, steps 10 and 11 must be repeated                                                   |
| 14                             | output offset difference            | a              | ~1kHz/Burst not triggered/MOD OFF/5Vpp                                       | 627, modulator unit 1 | < 10 mV                                 | OUTPUT connector, DC-voltmeter              | open                         |                                                                                                                                        |

a = adjustment  
c = check












| Step                                                                                                                                                                       | Objective                 | operation parameters settings                       | adjusting elements    | measured value, value to be adjusted                                              | test point, output measuring instruments | open output/50 Ohm | comment                                                |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------|-----------------------------------------------------|-----------------------|-----------------------------------------------------------------------------------|------------------------------------------|--------------------|--------------------------------------------------------|
| <u>LF-AMPLITUDE, DISTORTION</u>                                                                                                                                            |                           |                                                     |                       |                                                                                   |                                          |                    |                                                        |
| 15                                                                                                                                                                         | LF-amplitude              | a ~10 kHz/10 Vpp                                    | 613, modulator unit 1 | 1,76±0,001 Vrms                                                                   | OUTPUT connector, rms-voltmeter          | 50 Ohm             | if necessary 517 and/or 519 (modulator) may be altered |
| 16                                                                                                                                                                         | LF-amplitude              | c ~10 kHz/1 Vpp                                     | —                     | 177±3,5 mVrms                                                                     | OUTPUT connector, rms-voltmeter          | 50 Ohm             |                                                        |
| 17                                                                                                                                                                         | LF-amplitude              | c ~10 kHz/0,1 Vpp                                   | —                     | 17,7±0,5 mVrms                                                                    | OUTPUT connector, rms-voltmeter          | 50 Ohm             |                                                        |
| 18                                                                                                                                                                         | amplitudes difference     | a ~100 Hz, 10 kHz/10 Vpp                            | 700, amplifier unit 1 | $\Delta U < 0,02$ dB                                                              | OUTPUT connector, rms-voltmeter          | 50 Ohm             |                                                        |
| 19                                                                                                                                                                         | distortion                | c ~1 kHz/17 Vpp, 20 Vpp                             | —                     | $< 0,35$ %, $< 0,45$ %                                                            | OUTPUT connector, distort.-meter         | 50 Ohm             |                                                        |
| 20                                                                                                                                                                         | DFS-frequency response    | c ~10 kHz, 1,8 MHz/10 Vpp                           | —                     | ±0,3 dB                                                                           | OUTPUT connector, rms-voltmeter          | 50 Ohm             |                                                        |
| 21                                                                                                                                                                         | DFS-frequency response    | c ~10 kHz, 2.147 MHz/10 Vpp                         | —                     | ±0,3 dB                                                                           | OUTPUT connector, rms-voltmeter          | 50 Ohm             |                                                        |
| <u>SARWIDTH ADJUSTMENT</u>                                                                                                                                                 |                           |                                                     |                       |                                                                                   |                                          |                    |                                                        |
| 22                                                                                                                                                                         | offset                    | a ~1 kHz/1:1 Burst cont./10 Vpp                     | 607, modulator unit 1 |  | OUTPUT connector, oscilloscope           | 50 Ohm             | the transition regions must be free of voltage jumps   |
| 23                                                                                                                                                                         | offset                    | a ~1 kHz/1:1 Burst cont./10 Vpp                     | 602, modulator unit 1 | —                                                                                 | OUTPUT connector, oscilloscope           | 50 Ohm             |                                                        |
| 24                                                                                                                                                                         | rms-value                 | c ~1 kHz/10 Vpp                                     | —                     | 1,443 ±0,025 Vrms                                                                 | OUTPUT connector, rms-voltmeter          | 50 Ohm             |                                                        |
| <u>PLL-ADJUSTMENT</u>                                                                                                                                                      |                           |                                                     |                       |                                                                                   |                                          |                    |                                                        |
| 25                                                                                                                                                                         | amplitude triangular wave | a ~1/3 MHz/10 Vpp                                   | 636, PLL unit 1       | 12,3±0,1 mVrms                                                                    | T10, rms voltmeter                       | —                  | T10 must be terminated with 50 Ohm!                    |
| 26                                                                                                                                                                         | offset                    | c ~1/3 MHz/10 Vpp                                   | —                     | -550 ±150 mV                                                                      | T10, DC-voltmeter                        | —                  |                                                        |
| 27                                                                                                                                                                         | 2nd harmonic              | a ~1/4.5 MHz/10 Vpp                                 | 611, PLL unit 1       | minimum, $< -31$ dB                                                               | T10, spectrum analyser                   | —                  |                                                        |
| 28                                                                                                                                                                         | 2nd harmonic              | a ~1/2,5 MHz/10 Vpp                                 | 614, PLL unit 1       | minimum, $< -36$ dB                                                               | T10, spectrum analyser                   | —                  |                                                        |
| 29                                                                                                                                                                         | PLL control voltage       | a ~1/2,5 ~50 MHz/1lin.sweep cont./Ts=0.02sec./10Vpp | 536(526), PLL unit 1  | $ A  \approx  B  < 3$ V                                                           | T22, oscilloscope                        | —                  |                                                        |
| Set trimming capacitor 526 to minimum and use it only if there are problems to adjust the required value with only 526. The steps in the diagram above must be horizontal. |                           |                                                     |                       |                                                                                   |                                          |                    |                                                        |
| 30                                                                                                                                                                         | DC-level                  | a ~1/5 MHz/10 Vpp                                   | 684, PLL unit 1       | 700 ±20 mV                                                                        | T11-T12, DC-voltmeter                    | —                  | DC-level between T 11 and T 12.                        |





check  
a = adjustment  
c = check

| Step | Objective               | check<br>a = adjustment<br>c = check | operation parameters<br>settings               | adjusting elements                        | measured value,<br>value to be adjusted                                           | test point, output<br>measuring instruments             | open<br>output/<br>shorten. | comment                                                                                                                                            |
|------|-------------------------|--------------------------------------|------------------------------------------------|-------------------------------------------|-----------------------------------------------------------------------------------|---------------------------------------------------------|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| 31   | 2nd and 3rd harmonics   | a                                    | ~5 MHz / 10 Vpp                                | 706, 709, PLL unit 1                      | minimum, < -43 dB                                                                 | OUTPUT connector, spectrum analyser                     | 50 Ohm                      |                                                                                                                                                    |
| 32   | 2nd and 3rd harmonics   | c                                    | ~10 MHz / 20 Vpp                               | —                                         | minimum, < -34 dB                                                                 | OUTPUT connector, spectrum analyser                     | 50 Ohm                      |                                                                                                                                                    |
| 33   | 2nd and 3rd harmonics   | c                                    | ~72.5 - 50 MHz / 10V sweep cont./1s=2sec/20Vpp | —                                         | minimum, < -30 dB                                                                 | OUTPUT connector, spectrum analyser                     | 50 Ohm                      |                                                                                                                                                    |
| 34   | output level difference | a                                    | ~10kHz, 3MHz/10Vpp                             | 721, PLL unit 1                           | Δ Us < 0.03 dB                                                                    | OUTPUT connector, rms-voltmeter                         | 50 Ohm                      |                                                                                                                                                    |
| 35   | DC-level difference     | a                                    | ~3kHz, 3MHz/5Vpp                               | 624, modulator unit 1                     | < 10 mV                                                                           | OUTPUT connector, DC-voltmeter                          | open                        |                                                                                                                                                    |
| 36   | output level difference | a                                    | ~3MHz, 50kHz/10Vpp                             | 503, modulator unit 1                     | +0,4 ± 0,1 dB                                                                     | OUTPUT connector, power meter                           | 50 Ohm                      | if the output level is too low, charge capacitor 501 in the modulator to another one (27 pF); if the level is too high, increase resistor 714 PLL. |
| 37   | output level difference | c                                    | ~3MHz, 30kHz/10Vpp                             | —                                         | +0,1 ± 0,3 dB                                                                     | OUTPUT connector, power meter                           | 50 Ohm                      |                                                                                                                                                    |
| 38   | DC-level difference     | a                                    | ~5MHz/10Vpp                                    | 621, PLL unit 1                           | < 0,2 mV                                                                          | 16, 17, DC-voltmeter                                    | —                           |                                                                                                                                                    |
| 8.4  |                         |                                      |                                                |                                           |                                                                                   |                                                         |                             |                                                                                                                                                    |
| 39   | SQUARE WAVE ADJUSTMENT  |                                      |                                                |                                           |                                                                                   |                                                         |                             |                                                                                                                                                    |
| 39   | square burst pre-shot   | a                                    | 1kHz/BURST 1:1 cont./10Vpp                     | 603/pulse generator unit 1                |  | OUTPUT connector, oscilloscope                          | 50 Ohm                      | the first needle must be suppressed                                                                                                                |
| 40   | positive half cycle     | a                                    | 1kHz/10Vpp                                     | 603/pulse generator unit 1                | Tx + 2 μs.                                                                        | OUTPUT connector, interval counter                      | 50 Ohm                      | Tx = half cycle resulting from step 39                                                                                                             |
| 41   | positive half cycle: T  | c(a)                                 | 1kHz/10Vpp                                     | —                                         | 500 μs ≤ T ≤ 510 μs                                                               | OUTPUT connector, interval counter                      | 50 Ohm                      | if < 500 μs adjust with 603 to 500 μs; if > 500 μs check step 6 - DC adjustment                                                                    |
| 42   | positive amplitude      | a                                    | 0.05Hz/10Vpp                                   | 627/pulse generator unit 1                | +4,95 ± 0,02 V                                                                    | OUTPUT connector, DC voltmeter                          | open                        |                                                                                                                                                    |
| 43   | negative amplitude      | a                                    | 0.05Hz/10Vpp                                   | 624/pulse generator unit 1                | -4,95 ± 0,02 V                                                                    | OUTPUT connector, DC voltmeter                          | open                        |                                                                                                                                                    |
| 44   | rms-value               | c                                    | 10kHz/10Vpp                                    | —                                         | 2,540,02Vrms                                                                      | OUTPUT connector, rms-voltmeter                         | 50 Ohm                      | if this value is not correct, repeat 41 and 42                                                                                                     |
| 45   | signalform              | a                                    | 10kHz/10Vpp                                    | 505/modulator unit 1 (513/output amplif.) | adjust minimum rise-time without overshoot                                        | OUTPUT connector, wide band oscilloscope (tr ≤ 1 nsec)  | 50 Ohm                      | if 513 must be adjusted, the steps 36 and 37/PLL adjustment) are to be repeated                                                                    |
| 46   | duty cycle              | c(a)                                 | 20kHz/20Vpp                                    | (614, pulse generator unit 1)             | 50 ± 5 %                                                                          | OUTPUT connector, wide band oscilloscope (tr ≤ 1 nsec.) | 50 Ohm                      | use potentiometer 614 only in case of exceeded limits and adjust it until the limit is reached.                                                    |

check  
adjustment

| Step | Objective                                             | check<br>adjustment | operation parameters<br>settings                                                                                          | adjusting elements                | measured value,<br>value to be adjusted             | test point, output<br>measuring instruments               | open<br>output/<br>system | comment                                                                                                                                                                               |
|------|-------------------------------------------------------|---------------------|---------------------------------------------------------------------------------------------------------------------------|-----------------------------------|-----------------------------------------------------|-----------------------------------------------------------|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 47   | rise-/falltime                                        | c                   |  10kHz/10Vpp                           | —                                 | < 10,5 nsec                                         | OUTPUT connector, wide band<br>oscilloscope (tr < 1 nsec) | 50 Ohm                    |                                                                                                                                                                                       |
| 48   | overshoots (overshoot<br>etc.)                        | c                   |  10kHz/10Vpp                           | —                                 | < 2 %                                               | OUTPUT connector, wide band<br>oscilloscope (tr < 1 nsec) | 50 Ohm                    | aberrations related to the<br>amplitude 0 - p.                                                                                                                                        |
| 49   | <u>PULSE ADJUSTMENT</u><br>pulse suppression          | a                   |  10kHz/10Vpp                           | 659/662/pulse<br>generator unit 1 | pulse amplitude < 45 mV                             | OUTPUT connector, oscilloscope                            | 50 Ohm                    | square wave pulses stepping<br>out of the quiescent<br>potential 45 mV                                                                                                                |
| 50   | DC-offset                                             | a                   |  10kHz/10Vpp                           | 686/pulse generator<br>unit 1     | 0 ± 10 mV                                           | OUTPUT connector, DC-voltmeter                            | open                      |                                                                                                                                                                                       |
| 51   | pulse-amplitude                                       | a                   |  10kHz/10Vpp                           | 654/pulse generator<br>unit 1     | 2,5 ± 0,01 Vrms                                     | OUTPUT connector, rms-voltmeter                           | 50 Ohm                    |                                                                                                                                                                                       |
| 52   | pulse-form                                            | a                   |  30kHz/5Vpp                            | 537,538/pulse<br>generator unit 1 | adjust minimum rise-<br>time without over-<br>shoot | OUTPUT connector, wide band<br>oscilloscope (tr < 1 nsec) | 50 Ohm                    |                                                                                                                                                                                       |
| 53   | pulse form                                            | c                   |  1kHz/2Vpp                             | —                                 | check the pulse form                                | OUTPUT connector, oscilloscope                            | 50 Ohm                    |                                                                                                                                                                                       |
| 54   | duty cycle                                            | c(a)                |  30kHz/5Vpp                            | 664/pulse generator<br>unit 1     | 50 ± 5 %                                            | OUTPUT connector, wide band<br>oscilloscope (tr < 1 nsec) | 50 Ohm                    | potmeter 664 is used to<br>adjust rise and fall time<br>and the duty cycle. When<br>adjusting them, more care<br>must be taken to read the<br>amplitude and the rise<br>and fall time |
| 55   | rise/fall time, duty<br>cycle                         | c(b)                |  50kHz/10Vpp                           | 664/pulse generator<br>unit 1     | < 4,5 nsec.                                         | OUTPUT connector, wide band<br>oscilloscope (tr < 1 nsec) | 50 Ohm                    |                                                                                                                                                                                       |
| 56   | <u>AM- AND FM ADJUSTMENTS</u><br>modulation frequency | a                   |  10kHz/AM1M/50 %<br>fm = 0,9kHz/20Vpp  | 696/modulator unit 1              | 900 ± 1 Hz                                          | MOD-OUT connector, counter                                | -                         |                                                                                                                                                                                       |
| 57   | modulation frequency                                  | a                   |  10kHz/AM1M/50 %<br>fm = 0,05kHz/20Vpp | 699/modulator unit 1              | 50 ± 0,1 Hz                                         | MOD-OUT connector, counter                                | -                         | iterate this adjustment<br>with step 55                                                                                                                                               |

check  
adjustment

| Step | Objective                                        | a = check<br>c = adjustment | operation parameters<br>settings                                                               | adjusting elements         | measured value,<br>value to be adjusted | test point, output<br>measuring instruments                   | open<br>output/<br>system | comment                                                                                                                               |
|------|--------------------------------------------------|-----------------------------|------------------------------------------------------------------------------------------------|----------------------------|-----------------------------------------|---------------------------------------------------------------|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
| 58   | modulation frequency                             | a                           | $\sim 1/10\text{kHz}/\text{AM}/50\%$<br>$f_m = 50\text{kHz}/20\text{Vpp}$                      | 524/modulator unit 1       | 50 $\pm 0.03$ kHz                       | MUD OUT connector, counter                                    | -                         |                                                                                                                                       |
| 59   | distortion                                       | a                           | $\sim 1/10\text{kHz}/\text{AM}/50\%$<br>$f_m = 5\text{ kHz}/20\text{ Vpp}$                     | 700, 702/modulator<br>unit | minimum distortion<br>( $< 0.5\%$ )     | MUD OUT connector, distortion<br>meter                        | -                         |                                                                                                                                       |
| 60   | DC offset                                        | a                           | $\sim 1/10\text{kHz}/\text{AM}/50\%$<br>$f_m = 5\text{ kHz}/20\text{ Vpp}$                     | 709/modulator unit 1       | $\pm 100 \pm 50$ mV                     | 121, DC-voltmeter                                             | -                         |                                                                                                                                       |
| 61   | unwanted frequency<br>deviation rms              | a                           | $\sim 1/5\text{MHz}/\text{FM}/\text{EXT}$ , MUD<br>OFF/10Vpp                                   | 620/PLL unit 1             | minimum ( $< 500$ Hz)                   | OUTPUT connector, modulation<br>meter                         | 50 Ohm                    | LF-band width<br>10 Hz - 20 kHz                                                                                                       |
| 62   | DC frequency<br>deviation (average)              | a                           | $\sim 1/5, 10, \dots, 35\text{MHz}/\text{FM}/\text{INT}/$<br>$200\text{kHz}$ DCV/fm=5kHz/10Vpp | 707/modulator unit 1       | 200 $\pm 3$ kHz                         | OUTPUT connector, modulation<br>meter                         | 50 Ohm                    | $\pm 3$ kHz is the average<br>value over 1000<br>failures over the<br>range of 5-35 MHz, single<br>failures can exceed this<br>limit. |
| 63   | AC-amplitude rms                                 | a                           | $\sim 1/10\text{kHz}/\text{AM}/\text{INT}/0\%$<br>$f_m = 5\text{kHz}/20\text{Vpp}$             | 684/modulator unit 1       | 1.767 $\pm 0.01$ Vrms                   | OUTPUT connector, rms-voltmeter                               | 50 Ohm                    | 8 - 6                                                                                                                                 |
| 64   | modulation depth<br>AM                           | a                           | $\sim 1/10\text{kHz}/\text{AM}/\text{INT}/50\%$<br>$f_m = 5\text{kHz}/20\text{Vpp}$            | 686/modulator unit 1       | 50 $\pm 0.2\%$                          | OUTPUT connector, modulation<br>meter                         | 50 Ohm                    | LF bandwidth 10Hz-20kHz                                                                                                               |
| 65   | LF-suppression                                   | a                           | $\sim 1/10\text{kHz}/\text{AM}/\text{INT}/50\%$<br>$f_m = 5\text{kHz}/20\text{Vpp}$            | 663/modulator unit 1       | minimum level                           | OUTPUT connector, rms-voltmeter<br>with low pass filter 5 kHz | 50 Ohm                    |                                                                                                                                       |
| 66   | DC-difference                                    | a                           | $\sim 1/5\text{kHz}/\text{AM}/\text{INT}/\text{MUD}/\text{OFF}/$<br>$0\%$ fm=5kHz/10Vpp        | 681/modulator unit 1       | $< 10$ mV                               | OUTPUT connector, DC-voltmeter                                | open                      |                                                                                                                                       |
| 67   | level difference                                 | a                           | $\sim 1/10\text{kHz}$ , 40kHz/AM INT/<br>$0\%$ fm = 5 kHz/20 Vpp                               | 511/modulator unit 1       | -0.2 $\pm 1$ dB                         | OUTPUT connector, power meter                                 | 50 Ohm                    |                                                                                                                                       |
| 58   | BURST ADJUSTMENT<br>start-stop phase of<br>burst | a                           | $\sim 1/10\text{kHz}/\text{Burst}$ (cont.)<br>Non = Noiff = 1/10Vpp                            | 701/DP's unit 2            | minimum glitches                        | OUTPUT connector, oscilloscope                                | 50 Ohm                    | <br>these glitches must be<br>adjusted to minimum     |
| 69   | start-stop phase of<br>burst                     | c                           | $\sim 1/20\text{kHz}/\text{Burst}$ (cont.)<br>Non = Noiff = 1/10Vpp                            | —                          | aberrations $< 20\%$                    | OUTPUT connector, oscilloscope                                | 50 Ohm                    | <br>IB1 / A < 0.2<br>IC1 / A < 0.2                    |

Check  
adjustment

| Step | Objective           | Check<br>adjustment | operation parameters<br>settings                                                  | adjusting elements   | measured value,<br>value to be adjusted  | test point, output<br>measuring instruments                    | open<br>output<br>SUTera. | comment                                                                                                                      |
|------|---------------------|---------------------|-----------------------------------------------------------------------------------|----------------------|------------------------------------------|----------------------------------------------------------------|---------------------------|------------------------------------------------------------------------------------------------------------------------------|
|      | MISCELLANEOUS       |                     |                                                                                   |                      |                                          |                                                                |                           |                                                                                                                              |
| 70   | frequency response  | a                   | $\sim$ /3-50 MHz/ sweep<br>lin cont/TS = 5 sec/<br>0,001 Vpp                      | 80%/amplifier unit 1 | 0.45 dB                                  | OUTPUT connector, spectrum<br>analyser                         | 50 Ohm                    | start adjustment at full<br>left position of R05<br>(bottom view) and turn it<br>until frequency response is<br>within 45 dB |
| 71   | frequency, level pp | c                   | $\sim$ /1 kHz/10Vpp                                                               | —                    | 8,58935 MHz $\pm$ 3 Hz<br>level >3,5 Vpp | INT CLOCK connector, counter,<br>oscilloscope with 1:10 atten. | —                         | e.g. PM 6654 with 1 : 10<br>attenuator                                                                                       |
| 72   | frequency           | c                   | $\sim$ /1MHz/10Vpp                                                                | —                    | 1,164153 MHz $\pm$ 1 Hz                  | OUTPUT connector, counter                                      | 50 Ohm                    |                                                                                                                              |
| 73   | frequency, level pp | c                   | $\sim$ /10MHz/10Vpp                                                               | —                    | 10 MHz $\pm$ 3 Hz<br>level >3,5 Vpp      | TTL out connector, counter,<br>oscilloscope                    | —                         |                                                                                                                              |
| 74   | modulation depth    | c                   | $\sim$ /10MHz/AM EX1/20Vpp                                                        | —                    | (50 $\pm$ 7)%                            | OUTPUT connector, modulation<br>meter                          | 50 Ohm                    | connect external signal-<br>sine wave, 1 kHz, 2.8 Vpp<br>to MOD INPUT                                                        |
| 75   | gate function       | c                   | $\sim$ /1MHz/GATE INT/10Vpp<br>fm = 1 kHz                                         | —                    | check of the gate<br>function            | OUTPUT connector, oscilloscope                                 | 50 Ohm                    |                                                                                                                              |
| 76   | Mod out amplitude   | c                   | $\sim$ /1MHz/GATE INT/10Vpp<br>fm = 1 kHz                                         | —                    | sine wave 2,8 Vpp                        | MOD OUT connector, oscilloscope                                | —                         |                                                                                                                              |
| 77   | Pen lift amplitude  | c                   | $\sim$ /fskstart = 1 kHz/<br>fskstop = 10 kHz/TS = 10ms/<br>lin sweep cont/10 Vpp | —                    | square wave signal<br>>16 Vpp            | PEN LIFT connector,<br>oscilloscope                            | —                         |                                                                                                                              |
| 78   | Sweep out amplitude | c                   | $\sim$ /fskstart = 1 kHz/<br>fskstop = 10 kHz/TS=100 ms/<br>lin sweep cont/10 Vpp | —                    | sawtooth signal<br>10 Vpp                | SWEPT OUT connector,<br>oscilloscope                           | —                         |                                                                                                                              |

## 9. SAFETY INSPECTION AND TESTS AFTER REPAIR AND MAINTENANCE IN THE PRIMARY CIRCUIT

### 9.1. GENERAL DIRECTIVES

- Take care that creepage distances and clearances have not been reduced
- Before soldering, wires:
  - should be bent through the holes of solder tags, or wrapped round the tag in the form of an open U, or, wiring rigidity shall be maintained by cable clamps or cable lacing.
- Replace all insulating guards and -plates.

### 9.2. SAFETY COMPONENTS

Components in the primary circuit may only be renewed by components selected by Philips, see also chapter 10.

### 9.3. CHECKING THE PROTECTIVE EARTH CONNECTION

The correct connection and condition is checked by visual control and by measuring the resistance between the protective-lead connection at the plug and the cabinet/frame. The resistance shall not be more than  $0.5 \Omega$ . During measurement the mains cable should be moved. Resistance variations indicate a defect.

### 9.4. CHECKING THE INSULATION RESISTANCE

Measure the insulation resistance at  $U = 500$  Vdc between the mains connections and the protective lead connections. For this purpose set the mains switch to ON. The insulation resistance shall not be less than  $2 M\Omega$ .

Note:

$2 M\Omega$  is a minimum requirement at  $40^\circ C$  and 95 % relative humidity. Under normal conditions the insulation resistance should be much higher (10 to  $20 M\Omega$ ).



### 9.5. TEST AFTER REPAIR AND MAINTENANCE

This part of the checking — and adjusting procedure represents the final check of the PM 5193. Bottom and top cover of the cabinet must be closed and the instrument must be warmed up for at least 2 hours. The check contains measurements of DC-levels, amplitudes and frequencies on following their specifications and furthermore some tests of modulation functions. The sequence of the measurements is free selectable.

#### 9.5.1. Frequency Measurements

| Objective            | Frequency setting | maximum tolerance | connector |
|----------------------|-------------------|-------------------|-----------|
| basic frequency      | 1 MHz             | $\pm 0,8$ Hz      | OUTPUT    |
| modulation frequency | 50 Hz             | $\pm 1,25$ Hz     | MOD OUT   |
| FREQ (kHz)           | 500 Hz            | $\pm 12,5$ Hz     | "         |
|                      | 5 kHz             | $\pm 175,0$ Hz    | "         |
|                      | 50 kHz            | $\pm 1,25$ kHz    | "         |
|                      | 200 kHz           | $+ 8/- 20$ kHz    | "         |

## 9.5.2. Checking of the square wave and pulse signals



| Setting                                                                                          | Connector | Measuring Instrument                   |
|--------------------------------------------------------------------------------------------------|-----------|----------------------------------------|
|  /10 MHz/10 Vpp | OUTPUT    | wide band oscilloscope<br>(tr ≤ 1nsec) |
|  /30 MHz/10 Vpp | OUTPUT    | —                                      |

## 9.5.3. Modulation Measurements

| Modulation | Carrier Frequency | Object                                   | Measured tolerance                                                             |
|------------|-------------------|------------------------------------------|--------------------------------------------------------------------------------|
| OFF        | 4.05 MHz          | residual FM rms                          | < 0,02 % of carrier frequency<br>or < 1000 Hz<br>(smallest value in each case) |
| "          | 8,589 MHz         |                                          |                                                                                |
| "          | 19 MHz            |                                          |                                                                                |
| "          | 42,9487 MHz       |                                          |                                                                                |
| FM EXT     | 4,05 MHz          | B <sub>iff</sub> = 10 Hz – 20 kHz        |                                                                                |
| "          | 8,589 MHz         |                                          |                                                                                |
| "          | 19 MHz            |                                          |                                                                                |
| "          | 42,9487 MHz       |                                          |                                                                                |
| FM INT     | 5 MHz             | frequency deviation<br>setting = 200 kHz | 200 ± 30 kHz                                                                   |
| "          | 10 MHz            |                                          |                                                                                |
| "          | 20 MHz            |                                          |                                                                                |
| "          | 35 MHz            |                                          |                                                                                |
| "          | 50 MHz            | mod. depth setting 10 %                  | 200 + 30/– 110 kHz<br>(10 ± 3) %                                               |
| AM INT     | 5 MHz             |                                          |                                                                                |
| "          | 5 MHz             |                                          |                                                                                |
| "          | 5 MHz             |                                          |                                                                                |
| FM EXT     | 5 MHz             | freq. dev. U <sub>mod</sub> = 1 V/1 KHz  | 200 ± 40 kHz                                                                   |

## 9.5.4. DC-measurements

modulation off, frequency = 1 kHz

| Waveform                                                                            | Setting<br>AC      | DC  | DC-output<br>open<br>circuit | Tolerance<br>of DC-output open circuit       |
|-------------------------------------------------------------------------------------|--------------------|-----|------------------------------|----------------------------------------------|
| AC OFF                                                                              | 0                  | 0   |                              | ± 30 mV                                      |
| "                                                                                   | 0                  | -10 | -10                          | ± 1,5 % ± 30 mV                              |
| "                                                                                   | 0                  | - 5 | - 5                          |                                              |
| "                                                                                   | 0                  | 5   | 5                            |                                              |
| "                                                                                   | 0                  | 10  | 10                           |                                              |
|  | 3,4 . . . , 20 Vpp | 0   | -                            | ± 100 mV <sub>max</sub> , average: 0 ± 50 mV |
|                                                                                     | 5, 10, 15, 20 Vpp  | 0   | -                            | ± 150 mV                                     |
|                                                                                     | 1 Vpp              | 0   | 0,5 V                        | ± 5 % ± 30 mV                                |
|                                                                                     | 3 Vpp              | 0   | 1,5 V                        |                                              |
| "                                                                                   | 5 Vpp              | 0   | 2,5 V                        |                                              |
| "                                                                                   | 7 Vpp              | 0   | 3,5 V                        |                                              |
| "                                                                                   | 10 Vpp             | 0   | 5 V                          | $\Delta U_{dc} < 25 \text{ mV}$              |
| 1 KHz/3 MHz                                                                         | 10 Vpp             | 0   |                              |                                              |
| AM, frequency = 1 kHz                                                               |                    |     |                              |                                              |
|  | 10 Vpp             | 0   | 0                            | ± 150 mV                                     |



## 9.5.5. AC-Measurements

| Waveform | Frequency | Modulation       | Setting Vpp | Tolerance    |
|----------|-----------|------------------|-------------|--------------|
| "        | 1 kHz     | OFF              | 3,1         | ± 1,5 %      |
| "        | "         | "                | 3,2         |              |
| "        | "         | "                | 6,3         |              |
| "        | "         | "                | 6,4         |              |
| "        | "         | "                | 12,7        |              |
| "        | "         | "                | 12,8        |              |
| "        | "         | "                | 20,0        | ± 2,0 %      |
| "        | "         | "                | 0,30        |              |
| "        | "         | "                | 1,00        | "            |
| "        | "         | "                | 2,00        | "            |
| "        | "         | "                | 0,003       | ± 12,5 %     |
| "        | "         | "                | 0,010       | ± 5,5 %      |
| "        | "         | "                | 0,020       | ± 4,0 %      |
| "        | "         | "                | 0,050       | ± 3,1 %      |
| "        | "         | "                | 0,100       | ± 2,8 %      |
| "        | "         | "                | 0,200       | ± 2,65 %     |
| "        | "         | "                | 10,0        | ± 2,5 %      |
| "        | "         | "                | 10,0        | ± 2,0 %      |
| "        | "         | "                | 5,0         | ± 2,5 %      |
| "        | "         | "                | 1,0         | ± 3,5 %      |
| "        | "         | "                | 10,0        | ± 1,5 %      |
| "        | "         | "                | 10,0        | ± 2,0 %      |
| "        | "         | "                | 10,0        | ± 2,0 %      |
| "        | "         | "                | 10,0        | ± 2,5 %      |
| "        | "         | "                | 10,0        | ± 2,5 %      |
| "        | "         | Burst not trigg. | 20,0        | ± 2,5 mVrms  |
| "        | "         | AM INT 0 %       | 20,0        | ± 2,0 %      |
| "        | 10 kHz    | "                | 20,0        | ± 2,0 %      |
| "        | 200 kHz   | OFF              | 10,0        | ± 1,5 %      |
| "        | 2.146 MHz | "                | 10,0        | + 0 / - 3 %  |
| "        | 20 MHz    | "                | 10,0        | ± 8,0 %      |
| "        | 40 MHz    | "                | 10,0        | ± 8,0 %      |
| "        | 50 MHz    | "                | 10,0        | ± 8,0 %      |
| "        | 50 MHz    | "                | 20,0        | + 6 / - 12 % |
| "        | 2.146 MHz | "                | 1,00        | ± 3,5 %      |
| "        | 20 MHz    | "                | 1,00        | ± 11,5 %     |
| "        | 50 MHz    | "                | 1,00        | ± 11,5 %     |
| "        | 2.146 MHz | AM INT 0 %       | 20,0        | ± 5,0 %      |
| "        | 20 MHz    | " 0 %            | 20,0        | ± 8,0 %      |
| "        | 50 MHz    | " 0 %            | 20,0        | + 7 / - 30 % |
| "        | 2.146 MHz | OFF              | 0,100       | ± 5,0 %      |
| "        | 20 MHz    | "                | 0,100       | ± 30,0 %     |
| "        | 50 MHz    | "                | 0,100       | ± 30,0 %     |
| "        | 2.146 MHz | "                | 0,010       | ± 10,0 %     |
| "        | 20 MHz    | "                | 0,010       | ± 35,0 %     |
| "        | 50 MHz    | "                | 0,010       | ± 35,0 %     |

## 10. SPARE PARTS

### 10.1. GENERAL

The synthesizer/function generator PM 5193 is repaired on single component level. No complete boards and modules are available at Concern Service Eindhoven.

Loaded PROMs must be ordered directly via Philips Supply Center Hamburg (please note software version).

In case of difficult faults central repair facility of the complete instrument is possible on special request via repair procedure at Supply Center Hamburg.

Conversion of an existing instrument to a different version is not foreseen.

#### Standard Parts

Electrical and mechanical parts replacement can be obtained through your local Philips organisation or representative. However, many of the standard electronic components can be obtained from other local suppliers. Before purchasing or ordering replacement parts, check the parts list for value, tolerance, rating and description.

**NOTE:** Physical size and shape of a component may affect instrument performance, particularly at high frequencies. Always use direct-replacement components, unless it is known that a substitute will not degrade instrument performance.

#### Special Parts

In addition to the standard electronic components, some special components are used:

- Components, manufactured or selected by Philips to meet specific performance requirements.
- Components which are important for the safety of the instrument marked with 'S' in the parts list.

**ATTENTION:** Both type of components may only be replaced by components obtained through your local Philips organisation.

### 10.2. STATIC SENSITIVE COMPONENTS

This instrument contains electrical components that are susceptible to damage from static discharge. Servicing static-sensitive assemblies or components should be performed only at a static-free work station by qualified service personnel.

### 10.3. HANDLING MOS DEVICES

Though all our MOS integrated circuits incorporate protection against electrostatic discharges, they can nevertheless be damaged by accidental over-voltages. In storing and handling them, the following precautions are recommended.

**CAUTION:** Testing or handling and mounting call for special attention to personal safety. Personnel handling MOS devices should normally be connected to ground via a resistor.

### 10.4. SOLDERING TECHNIQUES

#### Working method:

- Carefully unsolder one after the other the soldering tags of the semi-conductor.
- Remove all superfluous soldering material. Use a sucking iron or sucking litze wire.
- Check that the tags of the replacement part are clean and pre-tinned on the soldering places.
- Locate the replacement semi-conductor exactly on its place, and solder each tag to the relevant printed conductor on the circuit board.

**NOTE:** Bear in mind that the maximum permissible soldering time is 10 seconds during which the temperature of the tags must not exceed 250° C. The use of solder with a low melting point is therefore recommended.

Take care not to damage the plastic encapsulation of the semi-conductor (softening point of the plastic is 150° C).

**ATTENTION:** When you are soldering inside the instrument it is essential to use a low-voltage soldering iron, the tip of which must be earthed to ground of the instrument.

Suitable soldering irons should have temperature control and different types of nozzles (pin point tips), e. g. Weller Magnastat WTCP or WECP, Ersi TC 70/24 V.

If a higher wattage-rating soldering iron is used on the etched circuit boards excessive heat can cause the etched circuit wiring to separate from the board base material.

In general use short-time heating with high tip temperature at a small point, avoid long time heating.

## 10.5. PARTS LIST PM 5193

### 10.5.1. Mechanical parts

#### Cabinet

| Item | Quantity | Order number   | Description                       |
|------|----------|----------------|-----------------------------------|
| A    | 1        | 5322 447 91368 | Top cover                         |
| B    | 1        | 5322 447 91369 | Bottom cover                      |
| C    | 4        | 5322 462 40756 | Plastic foot                      |
| D    | 4        | 5322 462 44434 | Rubber foot, adhesive             |
| E    | 4        | 5322 492 64745 | Locking clip                      |
| F    | 1        | 5322 401 10867 | Tilting support                   |
| G    | 1        | 5322 447 91373 | Rear panel                        |
| H    | 2        | 5322 462 40761 | Rear bumper                       |
| I    | 1        | 5322 447 91372 | Front panel                       |
| J    | 1        | 5322 447 91371 | Window for display                |
| K    | 1        | 5322 456 90257 | Text plate PM 5193                |
| L    | 1        | 5322 447 90502 | Front plate edging (upper)        |
| M    | 1        | 5322 466 92117 | Front plate edging (lower)        |
| N    | 1        | 5322 460 60433 | Profile ornament                  |
| O    | 1        | 5322 460 60436 | Profile ornament with text        |
| P    | 2        | 5322 447 90501 | Side piece                        |
| P    | 2        | 5322 263 70186 | Handle assembly (rack), not shown |
| Q    | 1        | 5322 460 60432 | Profile orn. long, perf. (left)   |
| R    | 1        | 5322 460 60434 | Profile orn. short (right)        |
| R    | 1        | 5322 460 60431 | Profile orn. short, perf. (right) |
| S    | 1        | 5322 498 50176 | Rubber handle                     |
| T    | 1        | 5322 462 40759 | Steel insert                      |




Fig. 10-1

## 10.5.2. Miscellaneous, parts not on units

| Item     | Fig.    | Quantity | Order number      | Description                  |
|----------|---------|----------|-------------------|------------------------------|
| 880      | 33 (31) | 1        | 5322 276 12029 *S | Mains switch                 |
| 881, 882 | 33 (31) | 2        | 5322 267 10004    | BNC connector, front         |
| 882-887  | 33 (32) | 6        | 5322 267 10173    | BNC connector, rear          |
|          | 33 (32) | 1        | 5322 321 22352    | IEEE connector wired         |
| 870      | 33 (32) | 1        | 5322 267 30416 *S | Mains socket with filter     |
|          | 10-2    | 1        | 5322 321 10388 *S | Mains cable (Europe)         |
|          | 10-3    | 1        | 5322 321 20816 *S | Mains cable (USA)            |
|          | 10-4    | 1        | 5322 321 10123 *S | Mains cable (U. K.)          |
|          | 32      | 1        | 5322 267 10173 *S | Fuse holder                  |
| 869      | 33 (32) | 1        | 4822 253 30018 *S | Fuse 630 mA T                |
| 869      | 33 (32) | 1        | 4822 253 30022 *S | Fuse 1.25 AT                 |
| 869      | 33 (32) | 1        | 4822 253 30024 *S | Fuse 1.6 AT                  |
| 868      | 33      | 1        | 5322 361 10451 *S | Fan                          |
| 751      | 33      | 1        | 5322 146 21241 *S | Transformer                  |
|          | 31      | 15       | 5322 414 60037    | Knob, large 12.5 x 6.5       |
|          | 31      | 7        | 5322 414 60036    | Knob, small 6.5 x 6.5        |
|          | 31      | 36       | 5322 414 60038    | Knob, small with LED         |
| 881, 882 | 33      | 2        | 5322 116 21068    | Varistor (BNC front)         |
| 852-857  | 33      | 6        | 5322 116 21137    | Varistor (BNC rear)          |
| 850-858  | 33      | 9        | 5322 526 14034    | Damping bead (BNC connector) |
|          | 32      | 1        | 5322 462 44172    | Cap for IC (rear panel)      |

\*S = Safety component, see chapter 10.1.

Mains cables




Fig. 10-2




Fig. 10-3




Fig. 10-4

## 10.5.3. Electrical Parts

Some parts are listed in chapter 10.5.2.

All metal film resistors not listed are of type MR 25  $\pm$  1 % 0.4 W (ordering code see end of this list).

\*1 Please order loaded PROM directly via Philips Supply Center Hamburg (note software version).

| Pos. no.                                          | Description      | Ordering code              |
|---------------------------------------------------|------------------|----------------------------|
| <b>UNIT 1, POWER SUPPLY</b>                       |                  |                            |
| <b>INTEGRATED CIRCUITS / UNIT 1, POWER SUPPLY</b> |                  |                            |
| 301, 303                                          | Integr. circuit  | Regulator 78GCU1           |
| 302, 304                                          | Integr. circuit  | Regulator 79GCU1           |
| 305                                               | Integr. circuit  | Regulator LM223K           |
|                                                   |                  | 5322 209 85565             |
|                                                   |                  | 5322 209 86349             |
|                                                   |                  | 5322 209 71639 (rear wall) |
| <b>TRANSISTORS / UNIT 1, POWER SUPPLY</b>         |                  |                            |
| 351                                               | Transistor       | BD204                      |
| 352                                               | Transistor       | BD203                      |
| 360                                               | Transistor       | BC558B                     |
|                                                   |                  | 5322 130 44324             |
|                                                   |                  | 5322 130 44325             |
|                                                   |                  | 4822 130 44197             |
| <b>DIODES / UNIT 1, POWER SUPPLY</b>              |                  |                            |
| 401                                               | Rectifier        | SKB2/08L5A                 |
| 402-405                                           | Diode, reference | BZX92                      |
| 417                                               | Diode, reference | BZX75C1V4                  |
| 420, 421                                          | Rectifier        | BY260-200                  |
|                                                   |                  | 5322 130 32031             |
|                                                   |                  | 5322 130 34397             |
|                                                   |                  | 4822 130 34047             |
|                                                   |                  | 4822 130 32145 (rear wall) |
| <b>CAPACITORS / UNIT 1, POWER SUPPLY</b>          |                  |                            |
| 501, 503                                          | Cap. foil        | 220 nF                     |
| 502, 504                                          | Cap. electrolyt. | 10 000 $\mu$ F             |
| 505, 506                                          | Cap. solid alu.  | 1 $\mu$ F                  |
| 508-510                                           | Cap. foil        | 220 nF                     |
| 511-513                                           | Cap. electrolyt. | 4 700 $\mu$ F              |
|                                                   |                  | 20 %                       |
|                                                   |                  | 100 V                      |
|                                                   |                  | 4822 121 40232             |
|                                                   |                  | 40 V                       |
|                                                   |                  | 5322 124 41278             |
|                                                   |                  | 25 V                       |
|                                                   |                  | 4822 124 20944             |
|                                                   |                  | 100 V                      |
|                                                   |                  | 4822 121 40232             |
|                                                   |                  | 16 V                       |
|                                                   |                  | 5322 124 70435             |
|                                                   |                  | 25 V                       |
|                                                   |                  | 4822 124 20944             |
| 512                                               | Cap. foil        | 220 nF                     |
| 514, 515                                          | Cap. solid alu.  | 1 $\mu$ F                  |
| 516                                               | Cap. foil        | 220 nF                     |
| 517                                               | Cap. electrolyt. | 22 000 $\mu$ F             |
| 518                                               | Cap. solid alu.  | 1 $\mu$ F                  |
|                                                   |                  | 20 %                       |
|                                                   |                  | 100 V                      |
|                                                   |                  | 4822 121 40232             |
|                                                   |                  | 25 V                       |
|                                                   |                  | 4822 124 21255             |
| 519                                               | Cap. ceramic     | 100 nF                     |
| 520                                               | Cap. solid alu.  | 2.2 $\mu$ F                |
| 521-523                                           | Cap. ceramic     | 100 nF                     |
| 524, 525                                          | Cap. solid alu.  | 2.2 $\mu$ F                |
| 526                                               | Cap. electrolyt. | 47 $\mu$ F                 |
|                                                   |                  | 10 %                       |
|                                                   |                  | 50 V                       |
|                                                   |                  | 5322 122 32941             |
|                                                   |                  | 25 V                       |
|                                                   |                  | 4822 124 21255             |
|                                                   |                  | 40 V                       |
|                                                   |                  | 5322 124 14014             |
|                                                   |                  | 63 V                       |
|                                                   |                  | 4822 124 40433             |
| 527                                               | Cap. ceramic     | 100 nF                     |
| 528                                               | Cap. solid alu.  | 22 $\mu$ F                 |
|                                                   |                  | 10 %                       |
|                                                   |                  | 50 V                       |
|                                                   |                  | 5322 122 32941             |
|                                                   |                  | 10 V                       |
|                                                   |                  | 4822 124 20943             |

| Pos. no.                            | Description     |           |        |       | Ordering code  |
|-------------------------------------|-----------------|-----------|--------|-------|----------------|
| RESISTORS / UNIT 1, POWER SUPPLY    |                 |           |        |       |                |
| 602                                 | Res. metal film | 5.6 Ω     | 5 %    | 2.5 W | 4822 116 52165 |
| 604, 609                            | Potm. trimmer   | 220 Ω     | CERMET | 0.1 W | 4822 100 10359 |
| 607                                 | Res. metal film | 5.6 Ω     | 5 %    | 2.5 W | 4822 116 52165 |
| 612                                 | Potm. trimmer   | 470 Ω     | CERMET | 0.1 W | 5322 101 14047 |
| 615                                 | Potm. trimmer   | 220 Ω     | CERMET | 0.1 W | 4822 100 10359 |
| COIL / UNIT 1, POWER SUPPLY         |                 |           |        |       |                |
| 800                                 | Coil            |           |        |       | 5322 158 10271 |
| UNIT 1, AMPLIFIER                   |                 |           |        |       |                |
| INTEGRATED CIRCUITS / UNIT 1, AMPL. |                 |           |        |       |                |
| 301                                 | Integr. circuit | MC1558U   |        |       | 5322 209 71645 |
| 302                                 | Integr. circuit | HEF4094BP |        |       | 5322 209 10421 |
| 303                                 | Integr. circuit | SE538N    |        |       | 5322 209 71641 |
| 304, 305                            | Integr. circuit | TL071IP   |        |       | 5322 209 71643 |
| 306                                 | Integr. circuit | HEF4094BP |        |       | 5322 209 10421 |
| 307                                 | Integr. circuit | DAC-08EN  |        |       | 5322 209 11254 |
| 308                                 | Integr. circuit | TL072IP   |        |       | 5322 209 71646 |
| 312                                 | Integr. circuit | HEF4094BP |        |       | 5322 209 10421 |
| 313                                 | Integr. circuit | 7406N-00  |        |       | 5322 209 86327 |
| 314, 315                            | Integr. circuit | HEF4066BP |        |       | 5322 209 10357 |
| TRANSISTORS / UNIT 1, AMPL.         |                 |           |        |       |                |
| 320-322                             | Transistor      | BC548B    |        |       | 4822 130 40937 |
| 330, 332                            | Transistor      | BFW16A    |        |       | 5322 130 44015 |
| 331                                 | Transistor      | 2N4035    |        |       | 5322 130 44201 |
| 333                                 | Transistor      | BF450     |        |       | 4822 130 44237 |
| 334, 335                            | Transistor      | BC558B    |        |       | 4822 130 44197 |
| 336                                 | Transistor      | BF240     |        |       | 4822 130 40902 |
| 337                                 | Transistor      | BF450     |        |       | 4822 130 44237 |
| 338                                 | Transistor      | BC548B    |        |       | 4822 130 40937 |
| 339                                 | Transistor      | BC558B    |        |       | 4822 130 44197 |
| 340                                 | Transistor      | BF240     |        |       | 4822 130 40902 |
| 341                                 | Transistor      | BF450     |        |       | 4822 130 44237 |
| 343                                 | Transistor      | BC558B    |        |       | 4822 130 44197 |
| 344                                 | Transistor      | BF240     |        |       | 4822 130 40902 |
| 345                                 | Transistor      | BF450     |        |       | 4822 130 44237 |
| 347                                 | Transistor      | BC558B    |        |       | 4822 130 44197 |
| 348                                 | Transistor      | BF240     |        |       | 4822 130 40902 |
| 349                                 | Transistor      | BF450     |        |       | 4822 130 44237 |
| 351                                 | Transistor      | BC558B    |        |       | 4822 130 44197 |
| 352                                 | Transistor      | BF240     |        |       | 4822 130 40902 |
| 353                                 | Transistor      | BF450     |        |       | 4822 130 44237 |

| Pos. no. | Description |         | Ordering code  |
|----------|-------------|---------|----------------|
| 355      | Transistor  | BC558B  | 4822 130 44197 |
| 356      | Transistor  | BF240   | 4822 130 40902 |
| 357      | Transistor  | BF450   | 4822 130 44237 |
| 359      | Transistor  | BC558B  | 4822 130 44197 |
| 360      | Transistor  | BF240   | 4822 130 40902 |
| 361      | Transistor  | BF450   | 4822 130 44237 |
| 363      | Transistor  | BC558B  | 4822 130 44197 |
| 364      | Transistor  | BF240   | 4822 130 40902 |
| 365      | Transistor  | BSX20   | 4822 130 41705 |
| 366      | Transistor  | BC558B  | 4822 130 44197 |
| 367      | Transistor  | BC548B  | 4822 130 40937 |
| 368      | Transistor  | 2N2894A | 5322 130 44127 |
| 369      | Transistor  | BC558C  | 5322 130 60068 |
| 370      | Transistor  | 2N4035  | 5322 130 44201 |
| 371      | Transistor  | BC548B  | 4822 130 40937 |
| 372      | Transistor  | BSX20   | 4822 130 41705 |
| 373      | Transistor  | BC558B  | 4822 130 44197 |
| 374      | Transistor  | BC548C  | 4822 130 44196 |
| 375      | Transistor  | 2N4035  | 5322 130 44201 |
| 376      | Transistor  | BFW16A  | 5322 130 44015 |
| 377      | Transistor  | BC548B  | 4822 130 40937 |
| 378      | Transistor  | BSX20   | 4822 130 41705 |
| 379, 380 | Transistor  | BFW16A  | 5322 130 44015 |
| 381      | Transistor  | 2N2894A | 5322 130 44127 |
| 382, 383 | Transistor  | 2N5583  | 5322 130 44033 |
| 384      | Transistor  | BSS61   | 5322 130 44714 |
| 385-387  | Transistor  | 2N5583  | 5322 130 44033 |
| 388      | Transistor  | 2N2905A | 5322 130 40468 |
| 389      | Transistor  | 2N2219A | 5322 130 44034 |
| 390-392  | Transistor  | BFW16A  | 5322 130 44015 |
| 393      | Transistor  | BSS52   | 5322 130 44579 |
| 394, 395 | Transistor  | 2N2905A | 5322 130 40468 |
| 396      | Transistor  | BF450   | 4822 130 44237 |
| 397, 398 | Transistor  | 2N2219A | 5322 130 44034 |
| 399      | Transistor  | BF240   | 4822 130 40902 |

## DIODES / UNIT 1, AMPL.

|          |             |                  |                |
|----------|-------------|------------------|----------------|
| 403, 404 | Diode, ref. | BZV46C1V5        | 5322 130 34865 |
| 405, 406 | Diode       | BAW62            | 4822 130 30613 |
| 409, 411 | Diode, ref. | BZV46C1V5        | 5322 130 34865 |
| 416, 417 | Diode, ref. | BZX79C6V8        | 4822 130 34278 |
| 419, 420 | Diode, ref. | BZX79C5V1        | 4822 130 34233 |
| 421, 422 | Diode, ref. | BZX79C6V2        | 4822 130 34167 |
| 423      | Diode, ref. | BZX90            | 5322 130 34397 |
| 424-439  | Diode       | BA482 (selected) | 5322 130 80265 |
| 440, 441 | Diode, ref. | BZV46C1V5        | 5322 130 34865 |
| 442      | Diode, ref. | BZX90            | 5322 130 34397 |



| Pos. no.                   | Description      |             |             |       | Ordering code  |
|----------------------------|------------------|-------------|-------------|-------|----------------|
| CAPACITORS / UNIT 1, AMPL. |                  |             |             |       |                |
| 501                        | Cap. ceramic     | 10 nF       | + 20/- 90 % | 40 V  | 4822 122 30043 |
| 502                        | Cap. ceramic     | 1 nF        | 10 %        | 100 V | 5322 122 32331 |
| 503                        | Cap. ceramic     | 2.2 pF      | 0.25 %      | 100 V | 4822 122 31036 |
| 504, 506                   | Cap. ceramic     | 100 nF      | 10 %        | 50 V  | 5322 122 32941 |
| 505, 507                   | Cap. electrolyt. | 220 $\mu$ F |             | 16 V  | 4822 124 40196 |
| 508-511                    | Cap. ceramic     | 100 nF      | 10 %        | 50 V  | 5322 122 32941 |
| 512                        | Cap. ceramic     | 39 pF       | 2 %         | 100 V | 4822 122 31069 |
| 513                        | Cap. trimmer     | 5.5-65 pF   |             | 100 V | 5322 125 54025 |
| 514                        | Cap. solid alu.  | 10 $\mu$ F  |             | 16 V  | 4822 124 21314 |
| 515                        | Cap. ceramic     | 10 nF       | + 20/- 90 % | 40 V  | 4822 122 30043 |
| 516                        | Cap. ceramic     | 100 nF      | 10 %        | 50 V  | 5322 122 32941 |
| 517-520                    | Cap. ceramic     | 10 nF       | + 20/- 90 % | 40 V  | 4822 122 30043 |
| 521                        | Cap. ceramic     | 100 nF      | 10 %        | 50 V  | 5322 122 32941 |
| 522                        | Cap. solid alu.  | 10 $\mu$ F  |             | 16 V  | 4822 124 21314 |
| 523                        | Cap. ceramic     | 10 nF       | + 20/- 90 % | 40 V  | 4822 122 30043 |
| 525                        | Cap. ceramic     | 100 nF      | 10 %        | 50 V  | 5322 122 32941 |
| 526                        | Cap. ceramic     | 100 pF      | 2 %         | 100 V | 4822 122 31316 |
| 528-531                    | Cap. ceramic     | 100 nF      | 10 %        | 50 V  | 5322 122 32941 |
| 532, 533                   | Cap. ceramic     | 470 pF      | 2 %         | 63 V  | 4822 122 32062 |
| 534                        | Cap. ceramic     | 100 nF      | 10 %        | 50 V  | 5322 122 32941 |
| 536, 537                   | Cap. solid alu.  | 10 $\mu$ F  |             | 16 V  | 4822 124 21314 |
| 538                        | Cap. ceramic     | 4.7 nF      | 10 %        | 100 V | 4822 122 31125 |
| 539                        | Cap. ceramic     | 150 pF      | 2 %         | 100 V | 4822 122 31413 |
| 540, 542                   | Cap. ceramic     | 68 pF       | 2 %         | 100 V | 4822 122 31349 |
| 544                        | Cap. ceramic     | 100 nF      | 10 %        | 50 V  | 5322 122 32941 |
| 545                        | Cap. solid alu.  | 1 $\mu$ F   |             | 25 V  | 4822 124 20944 |
| 547                        | Cap. ceramic     | 10 nF       | + 20/- 90 % | 40 V  | 4822 122 30043 |
| 548                        | Cap. ceramic     | 100 nF      | 10 %        | 50 V  | 5322 122 32941 |
| 549, 550                   | Cap. ceramic     | 10 nF       | + 20/- 90 % | 40 V  | 4822 122 30043 |
| 551, 553                   | Cap. ceramic     | 100 nF      | 10 %        | 50 V  | 5322 122 32941 |
| 554                        | Cap. solid alu.  | 1 $\mu$ F   |             | 25 V  | 4822 124 20944 |
| 555                        | Cap. ceramic     | 10 nF       | + 20/- 90 % | 40 V  | 4822 122 30043 |
| 557                        | Cap. ceramic     | 15 pF       | 2 %         | 100 V | 4822 122 31823 |
| 560, 561                   | Cap. ceramic     | 100 nF      | 10 %        | 50 V  | 5322 122 32941 |
| 562-565                    | Cap. ceramic     | 10 nF       | + 20/- 90 % | 40 V  | 4822 122 30043 |
| 566-574                    | Cap. ceramic     | 100 nF      | 10 %        | 50 V  | 5322 122 32941 |
| 577, 578                   | Cap. ceramic     | 220 pF      | 2 %         | 100 V | 5322 122 34047 |
| 580                        | Cap. ceramic     | 12 pF       | 2 %         | 100 V | 4822 122 31056 |
| 581, 582                   | Cap. ceramic     | 470 nF      | 20 %        | 100 V | 5322 122 33078 |
| 583                        | Cap. ceramic     | 1 nF        | 10 %        | 100 V | 4822 122 30027 |

| Pos. no.                  | Description     | Ordering code      |       |         |                |
|---------------------------|-----------------|--------------------|-------|---------|----------------|
| RESISTORS / UNIT 1, AMPL. |                 |                    |       |         |                |
| 609, 610                  | Res. metal film | 312 $\Omega$       | 0.1 % | 0.25 W  | 5322 116 80206 |
| 611, 612                  | Res. metal film | 412 $\Omega$       | 0.1 % | 0.25 W  | 5322 116 80211 |
| 613, 614                  | Res. metal film | 825 $\Omega$       | 0.1 % | 0.25 W  | 5322 116 80213 |
| 644, 653                  | Res. network    | 8 x 4.7 k $\Omega$ | 5 %   | 0.125 W | 5322 116 90132 |
| 666                       | Potm. trimmer   | 100 $\Omega$       | carb. | 0.1 W   | 4822 100 10075 |
| 700                       | Potm. trimmer   | 2.2 k $\Omega$     | carb. | 0.1 W   | 4822 100 10029 |
| 702                       | Res. metal film | 130 $\Omega$       | 5 %   | 1.6 W   | 5322 116 55509 |
| 769                       | Potm. trimmer   | 1 k $\Omega$       | carb. | 0.1 W   | 4822 100 10037 |
| 771                       | Potm. trimmer   | 4.7 k $\Omega$     | carb. | 0.1 W   | 4822 100 10036 |
| 787                       | Res. metal film | 100 $\Omega$       | 0.1 % | 0.25 W  | 5322 116 80208 |
| 788                       | Res. metal film | 150 $\Omega$       | 0.1 % | 0.25 W  | 5322 116 80209 |
| 789                       | Res. metal film | 261 $\Omega$       | 0.1 % | 0.25 W  | 5322 116 80205 |
| 792, 793                  | Res. metal film | 100 $\Omega$       | 0.1 % | 0.25 W  | 5322 116 80208 |
| 794                       | Res. metal film | 150 $\Omega$       | 0.1 % | 0.25 W  | 5322 116 80209 |
| 795                       | Res. metal film | 261 $\Omega$       | 0.1 % | 0.25 W  | 5322 116 80205 |
| 805                       | Potm. trimmer   | 2.2 k $\Omega$     | carb. | 0.1 W   | 4822 100 10029 |
| 809                       | Potm. trimmer   | 10 k $\Omega$      | carb. | 0.1 W   | 4822 100 10035 |
| 825-828                   | Res. metal film | 39 $\Omega$        | 5 %   | 0.5 W   | 4822 116 52193 |
| 874                       | Potm. trimmer   | 470 $\Omega$       | carb. | 0.1 W   | 4822 100 10038 |
| COILS / UNIT 1, AMPL.     |                 |                    |       |         |                |
| 831, 832                  | Wide band choke |                    |       |         | 5322 158 10271 |
| 833, 835                  | Choke           | 220 $\mu$ H        |       |         | 5322 157 53012 |
| 838                       | Wide band choke |                    |       |         | 5322 157 53015 |
| 873                       | Choke           | 220 $\mu$ H        |       |         | 5322 157 53012 |
| RELAIS / UNIT 1, AMPL.    |                 |                    |       |         |                |
| 841-850                   | Reed relais     | 5 V                |       |         | 5322 280 20281 |

Pos. no. Description

Ordering code

## UNIT 1, MODULATOR

## INTEGRATED CIRCUITS / UNIT 1, MOD.

|          |                 |             |                |
|----------|-----------------|-------------|----------------|
| 301      | Integr. circuit | HEF4053BP   | 5322 209 10576 |
| 302      | Integr. circuit | HEF4094BP   | 5322 209 10421 |
| 303      | Integr. circuit | N74LS02N    | 5322 209 85312 |
| 304      | Integr. circuit | N74LS27N    | 5322 209 85561 |
| 305      | Integr. circuit | MC1495L     | 5322 209 71638 |
| 306      | Integr. circuit | NE538N      | 5322 209 81343 |
| 307      | Integr. circuit | HEF4094BP   | 5322 209 10421 |
| 308      | Integr. circuit | DAC-08EN    | 5322 209 11254 |
| 309      | Integr. circuit | TL072ACP-00 | 5322 209 71644 |
| 310      | Integr. circuit | XR-2206CP   | 5322 209 86453 |
| 311      | Integr. circuit | AD7523JN    | 5322 209 70195 |
| 313, 316 | Integr. circuit | HEF4094BP   | 5322 209 10421 |
| 314, 315 | Integr. circuit | HEF4053BP   | 5322 209 10576 |
| 317      | Integr. circuit | HEF4001BP   | 4822 209 10246 |

## TRANSISTORS / UNIT 1, MOD.

|          |            |         |                |
|----------|------------|---------|----------------|
| 350      | Transistor | BC558B  | 4822 130 44197 |
| 352, 355 | Transistor | BC548B  | 4822 130 40937 |
| 358      | Transistor | BSX20   | 4822 130 41705 |
| 359      | Transistor | 2N2894A | 5322 130 44127 |
| 360, 361 | Transistor | BSX20   | 4822 130 41705 |
| 362      | Transistor | BC548B  | 4822 130 40937 |
| 363      | Transistor | BC558B  | 4822 130 44197 |
| 364, 365 | Transistor | 2N2894A | 5322 130 44127 |
| 366, 367 | Transistor | BSX20   | 4822 130 41705 |
| 378, 379 | Transistor | BF450   | 4822 130 44237 |
| 380, 381 | Transistor | BF240   | 4822 130 40902 |
| 382      | Transistor | BC548B  | 4822 130 40937 |
| 383      | Transistor | BC558B  | 4822 130 44197 |
| 384, 385 | Transistor | BC548B  | 4822 130 40937 |

| Pos. no.                  | Description      | Ordering code |      |                |                |
|---------------------------|------------------|---------------|------|----------------|----------------|
| DIODES / UNIT 1, MOD.     |                  |               |      |                |                |
| 401, 402                  | Diode, ref.      | BZX79B4V7     |      | 4822 130 34174 |                |
| 403-408                   | Diode, ref.      | BZX79B6V8     |      | 4822 130 34278 |                |
| 410-418                   | Diode            | BA481         |      | 5322 130 32239 |                |
| 421                       | Diode, ref.      | BZX79C8V2     |      | 4822 130 34382 |                |
| 422, 423                  | Diode, ref.      | BZX79C6V8     |      | 4822 130 34278 |                |
| 425                       | Diode, ref.      | BZX79B4V7     |      | 4822 130 34174 |                |
| 426                       | Diode            | BAW62         |      | 4822 130 30613 |                |
| 427, 428                  | Diode, ref.      | BZX79B4V7     |      | 4822 130 34174 |                |
| 429, 430                  | Diode, ref.      | BZX79B4V3     |      | 4822 130 31554 |                |
| 431                       | Diode, ref.      | BZX79B10      |      | 4822 130 34297 |                |
| 432, 433                  | Diode            | BA481         |      | 5322 130 32239 |                |
| CAPACITORS / UNIT 1, MOD. |                  |               |      |                |                |
| 503                       | Cap. trimmer     | 2-22 pF       |      | 100 V          | 4822 125 50045 |
| 504                       | Cap. ceramic     | 100 nF        | 10 % | 50 V           | 5322 122 32941 |
| 505, 511                  | Cap. trimmer     | 2-22 pF       |      | 100 V          | 4822 125 50045 |
| 513                       | Cap. ceramic     | 120 pF        | 2 %  | 100 V          | 4822 122 31685 |
| 514-516                   | Cap. ceramic     | 100 nF        | 10 % | 20 V           | 5322 122 30108 |
| 517                       | Cap. ceramic     | 270 pF        | 2 %  | 100 V          | 4822 122 30107 |
| 519                       | Cap. ceramic     | 220 pF        | 2 %  | 100 V          | 5322 122 34047 |
| 520                       | Cap. ceramic     | 10 nF         |      | 40 V           | 4822 122 30043 |
| 521                       | Cap. ceramic     | 100 nF        | 10 % | 50 V           | 5322 122 32941 |
| 522                       | Cap. solid alu.  | 15 $\mu$ F    |      | 16 V           | 4822 124 20977 |
| 523                       | Cap. solid alu.  | 1 $\mu$ F     |      | 25 V           | 4822 124 20944 |
| 524                       | Cap. trimmer     | 11-120 pF     |      | 150 V          | 5322 125 50183 |
| 525                       | Cap. ceramic     | 100 pF        | 2 %  | 100 V          | 4822 122 31316 |
| 526                       | Cap. foil        | 1.6 nF        | 1 %  | 160 V          | 5322 121 51123 |
| 527                       | Cap. foil        | 1.82 nF       | 1 %  | 160 V          | 5322 121 54259 |
| 528                       | Cap. ceramic     | 100 nF        | 10 % | 50 V           | 5322 122 32941 |
| 529                       | Cap. solid alu.  | 15 $\mu$ F    |      | 16 V           | 4822 124 20977 |
| 530                       | Cap. ceramic     | 100 nF        | 10 % | 50 V           | 5322 122 32941 |
| 532                       | Cap. foil        | 33 nF         | 1 %  | 63 V           | 5322 121 54111 |
| 533                       | Cap. foil        | 330 nF        | 1 %  | 63 V           | 5322 121 54171 |
| 534                       | Cap. ceramic     | 100 nF        | 10 % | 50 V           | 5322 122 32941 |
| 536                       | Cap. ceramic     | 33 pF         | 2 %  | 100 V          | 5322 122 32072 |
| 537                       | Cap. electrolyt. | 47 $\mu$ F    |      | 25 V           | 4822 124 22027 |
| 540-544                   | Cap. ceramic     | 100 nF        | 10 % | 100 V          | 5322 122 32941 |
| 545-546                   | Cap. ceramic     | 100 pF        | 2 %  | 100 V          | 4822 122 31316 |
| 547                       | Cap. ceramic     | 22 pF         | 2 %  | 100 V          | 5322 122 32143 |
| 548-549                   | Cap. ceramic     | 82 pF         | 2 %  | 100 V          | 4822 122 31237 |
| 550                       | Cap. ceramic     | 2.2 nF        | 10 % | 100 V          | 4822 122 30114 |

| Pos. no.                 | Description     | Ordering code  |        |        |                |
|--------------------------|-----------------|----------------|--------|--------|----------------|
| RESISTORS / UNIT 1, MOD. |                 |                |        |        |                |
| 601                      | Res. metal film | 1 k $\Omega$   | 0.1 %  | 0.25 W | 5322 116 52384 |
| 602, 607                 | Potm. trimmer   | 47 k $\Omega$  | CERMET | 0.5 W  | 5322 101 10509 |
| 604, 606                 | Res. metal film | 2 k $\Omega$   | 0.1 %  | 0.25 W | 5322 116 51812 |
| 609, 611                 | Res. metal film | 2 k $\Omega$   | 0.1 %  | 0.25 W | 5322 116 51812 |
| 613                      | Potm. trimmer   | 470 $\Omega$   | CERMET | 0.5 W  | 5322 101 14047 |
| 624, 627                 | Potm. trimmer   | 100 $\Omega$   | CERMET | 0.5 W  | 5322 101 14011 |
| 663, 681                 | Potm. trimmer   | 10 k $\Omega$  | carb.  | 0.1 W  | 4822 100 10035 |
| 684                      | Potm. trimmer   | 2.2 k $\Omega$ | carb.  | 0.1 W  | 4822 100 10029 |
| 686                      | Potm. trimmer   | 470 $\Omega$   | carb.  | 0.1 W  | 4822 100 10038 |
| 696                      | Potm. trimmer   | 1 k $\Omega$   | CERMET | 0.5 W  | 4822 100 10254 |
| 699                      | Potm. trimmer   | 10 k $\Omega$  | carb.  | 0.1 W  | 4822 100 10035 |
| 700                      | Potm. trimmer   | 220 $\Omega$   | carb.  | 0.1 W  | 4822 100 10019 |
| 702, 709                 | Potm. trimmer   | 22 k $\Omega$  | carb.  | 0.1 W  | 4822 100 10051 |
| 707                      | Potm. trimmer   | 1 k $\Omega$   | carb.  | 0.1 W  | 4822 100 10037 |
| 714                      | Res. N. T. C.   | 4.7 k $\Omega$ | 10 %   | 0.25 W | 5322 116 30215 |
| COILS / UNIT 1, MOD.     |                 |                |        |        |                |
| 801                      | Choke           | 0.33 $\mu$ H   |        |        | 5322 157 53013 |
| 802                      | Choke           | 220 $\mu$ H    |        |        | 5322 157 53012 |
| RELAIS / UNIT 1, MOD.    |                 |                |        |        |                |
| 810-816                  | Reed relais     | 5 V            |        |        | 5322 280 20281 |

| Pos. no. | Description | Ordering code |
|----------|-------------|---------------|
|----------|-------------|---------------|

## UNIT 1, PULSE GENERATOR

## INTEGRATED CIRCUITS / UNIT 1, PULSE GEN.

|          |                 |           |                |
|----------|-----------------|-----------|----------------|
| 301      | Integr. circuit | NE521N    | 5322 209 14441 |
| 302      | Integr. circuit | N74LS86N  | 5322 209 84997 |
| 303      | Integr. circuit | N74S258N  | 5322 209 85674 |
| 304      | Integr. circuit | HEF4094BP | 5322 209 10421 |
| 305      | Integr. circuit | N74S00N   | 5322 209 84167 |
| 306      | Integr. circuit | DAC-08EN  | 5322 209 11254 |
| 307      | Integr. circuit | MC1458N   | 4822 209 81349 |
| 308, 309 | Integr. circuit | LF356N    | 5322 209 86422 |

## TRANSISTORS / UNIT 1, PULSE GEN.

|          |            |         |                |
|----------|------------|---------|----------------|
| 351, 353 | Transistor | BSX20   | 4822 130 41705 |
| 352, 354 | Transistor | 2N2894A | 5322 130 44127 |
| 355, 360 | Transistor | BSX20   | 4822 130 41705 |
| 356, 357 | Transistor | 2N2894A | 5322 130 44127 |
| 358      | Transistor | 2N5583  | 5322 130 44033 |
| 359      | Transistor | 2N2894A | 5322 130 44127 |
| 361, 365 | Transistor | 2N5583  | 5322 130 44033 |
| 362, 366 | Transistor | BFW16A  | 5322 130 44015 |
| 363      | Transistor | 2N2905A | 5322 130 40468 |
| 364      | Transistor | 2N219A  | 5322 130 44034 |

## DIODES / UNIT 1, PULSE GEN.

|          |             |           |                |
|----------|-------------|-----------|----------------|
| 401, 402 | Diode, ref. | BZX79B4V7 | 4822 130 34174 |
| 403      | Diode, ref. | BZV46C2V0 | 4822 130 31248 |
| 404      | Diode, ref. | BZX79B6V2 | 4822 130 34167 |
| 405-408  | Diode       | BA481     | 5322 130 32239 |
| 409, 410 | Diode, ref. | BZX75C2V8 | 4822 130 34048 |
| 411      | Diode, ref. | BZX79B4V7 | 4822 130 34174 |
| 412, 413 | Diode       | BA481     | 5322 130 32239 |
| 414      | Diode, ref. | BZX79B3V3 | 5322 130 31504 |
| 415, 416 | Diode, ref. | BZX75B16  | 4822 130 34268 |
| 417      | Diode, ref. | BZX79B9V1 | 4822 130 30862 |
| 418      | Diode, ref. | BZX79B15  | 4822 130 34281 |
| 419      | Diode, ref. | BZX79B10  | 4822 130 34297 |
| 420      | Diode, ref. | BZX79B13  | 4822 130 34195 |
| 421-424  | Diode       | BAT14036  | 5322 130 80266 |
| 425, 426 | Diode, ref. | BZX79B12  | 4822 130 34197 |
| 427, 428 | Diode       | BAW62     | 4822 130 30613 |

| Pos. no.                        | Description     |                |             |       | Ordering code  |
|---------------------------------|-----------------|----------------|-------------|-------|----------------|
| CAPACITORS / UNIT 1, PULSE GEN. |                 |                |             |       |                |
| 501, 502                        | Cap. ceramic    | 10 nF          | + 50/- 20 % | 100 V | 4822 122 31414 |
| 503                             | Cap. ceramic    | 220 pF         | 2 %         | 100 V | 5322 122 34047 |
| 504, 505                        | Cap. ceramic    | 100 nF         | 10 %        | 50 V  | 5322 122 32941 |
| 506, 507                        | Cap. ceramic    | 10 nF          | + 50/- 20 % | 100 V | 4822 122 31414 |
| 508, 509                        | Cap. ceramic    | 100 nF         | 10 %        | 50 V  | 5322 122 32941 |
| 510, 511                        | Cap. ceramic    | 10 nF          | + 50/- 20 % | 100 V | 4822 122 31414 |
| 512-517                         | Cap. ceramic    | 100 nF         | 10 %        | 50 V  | 5322 122 32941 |
| 518, 519                        | Cap. solid die. | 10 $\mu$ F     |             | 16 V  | 4822 124 21314 |
| 520                             | Cap. ceramic    | 100 nF         | 10 %        | 50 V  | 5322 122 32941 |
| 521                             | Cap. ceramic    | 33 pF          | 2 %         | 100 V | 5322 122 32072 |
| 522, 523                        | Cap. ceramic    | 1 nF           | 10 %        | 100 V | 4822 122 30027 |
| 525                             | Cap. ceramic    | 10 nF          | + 50/- 20 % | 100 V | 4822 122 31414 |
| 526, 527                        | Cap. ceramic    | 100 nF         | 10 %        | 50 V  | 5322 122 32941 |
| 530, 531                        | Cap. ceramic    | 10 nF          | + 50/- 20 % | 100 V | 4822 122 31414 |
| 532, 533                        | Cap. solid die. | 10 $\mu$ F     |             | 16 V  | 4822 124 21314 |
| 534, 535                        | Cap. ceramic    | 10 pF          | 2 %         | 100 V | 4822 122 32185 |
| 536, 539                        | Cap. ceramic    | 100 nF         | 10 %        | 50 V  | 5322 122 32941 |
| 537, 538                        | Cap. trimmer    | 2-22 pF        |             | 100 V | 4822 125 50045 |
| 541                             | Cap. ceramic    | 10 nF          | + 50/- 20 % | 100 V | 4822 122 31414 |
| 542                             | Cap. ceramic    | 1 nF           | 10 %        | 100 V | 4822 122 30027 |
| RESISTORS / UNIT 1, PULSE GEN.  |                 |                |             |       |                |
| 603                             | Potm. trimmer   | 100 k $\Omega$ | carb.       | 0.1 W | 4822 100 10052 |
| 614                             | Potm. trimmer   | 4.7 k $\Omega$ | carb.       | 0.1 W | 4822 100 10036 |
| 624, 627                        | Potm. trimmer   | 4.7 k $\Omega$ | carb.       | 0.1 W | 4822 100 10036 |
| 650                             | Res. metal film | 150 $\Omega$   | 5 %         | 1.6 W | 4822 116 51142 |
| 654, 659                        | Potm. trimmer   | 4.7 k $\Omega$ | carb.       | 0.1 W | 4822 100 10036 |
| 662                             | Potm. trimmer   | 4.7 k $\Omega$ | carb.       | 0.1 W | 4822 100 10036 |
| 664                             | Potm. trimmer   | 10 k $\Omega$  | carb.       | 0.1 W | 4822 100 10035 |
| 684                             | Potm. trimmer   | 2.2 k $\Omega$ | carb.       | 0.1 W | 4822 100 10029 |
| COILS / UNIT 1, PULSE GEN.      |                 |                |             |       |                |
| 805                             | Damping bead    |                |             |       | 5322 526 10365 |
| 806                             | Choke           | 22 $\mu$ H     |             |       | 5322 157 50317 |
| 811                             | Wide band choke |                |             |       | 5322 157 53015 |
| 812                             | Damping bead    |                |             |       | 5322 526 10015 |

| Pos. no.                                       | Description     |                  | Ordering code  |
|------------------------------------------------|-----------------|------------------|----------------|
| <b>UNIT 1, PLL / VCO</b>                       |                 |                  |                |
| <b>INTEGRATED CIRCUITS / UNIT 1, PLL / VCO</b> |                 |                  |                |
| 301                                            | Integr. circuit | HEF4094BP        | 5322 209 10421 |
| 302                                            | Integr. circuit | DAC—08EN         | 5322 209 11254 |
| 303, 312                                       | Integr. circuit | LF356N           | 5322 209 86451 |
| 304, 307                                       | Integr. circuit | LF256H           | 5322 209 71642 |
| 306                                            | Integr. circuit | TL072IP          | 5322 209 71646 |
| 309                                            | Integr. circuit | MC4044P          | 5322 209 85821 |
| 311                                            | Integr. circuit | MC1456P1         | 5322 209 71647 |
| 313                                            | Integr. circuit | HEF4053BP        | 5322 209 10576 |
| 314                                            | Integr. circuit | N74S00N          | 5322 209 84167 |
| 316                                            | Integr. circuit | SN74197N         | 5322 209 84516 |
| 317                                            | Integr. circuit | N74LS393N        | 4822 209 80447 |
| 318                                            | Integr. circuit | N74LS00N         | 5322 209 84823 |
| 320                                            | Integr. circuit | MC3346P (CA3086) | 5322 209 84111 |
| <b>TRANSISTORS / UNIT 1, PLL / VCO</b>         |                 |                  |                |
| 351, 354                                       | Transistor      | BC548B           | 4822 130 40937 |
| 352, 353                                       | Transistor      | BC558B           | 4822 130 44197 |
| 356                                            | Transistor      | BF450            | 4822 130 44237 |
| 357, 358                                       | Transistor      | 2N4035           | 5322 130 44201 |
| 359                                            | Transistor      | BF240            | 4822 130 40902 |
| 361                                            | Transistor      | BSV79            | 5322 130 44017 |
| 362                                            | Transistor      | 8FX89            | 5322 130 40542 |
| 363                                            | Transistor      | 8FW16A           | 5322 130 44015 |
| 364, 366                                       | Transistor      | 8FX89            | 5322 130 40542 |
| 367, 368                                       | Transistor      | 2N2894A          | 5322 130 44127 |
| 369, 371                                       | Transistor      | PH2369           | 4822 130 41594 |
| 372                                            | Transistor      | BC548B           | 4822 130 40937 |
| 373                                            | Transistor      | BC558B           | 4822 130 44197 |
| 374, 376                                       | Transistor      | 2N4035           | 5322 130 44201 |
| 375, 377                                       | Transistor      | BF240            | 4822 130 40902 |
| 378                                            | Transistor      | 2N4035           | 5322 130 44201 |
| 379                                            | Transistor      | BF450            | 4822 130 44237 |
| 380                                            | Transistor      | BF240            | 4822 130 40902 |
| 381                                            | Transistor      | BC558B           | 4822 130 44197 |
| 382                                            | Integr. circuit | Regul. UA7815UC  | 4822 209 80808 |
| <b>DIODES / UNIT 1, PLL / VCO</b>              |                 |                  |                |
| 401, 402                                       | Diode, ref.     | BZX79C4V7        | 4822 130 34174 |
| 403                                            | Diode, ref.     | BZX91            | 5322 130 34397 |
| 404-407                                        | Diode, ref.     | BZX79C4V7        | 4822 130 34174 |
| 408                                            | Diode, ref.     | BZX79C4V3        | 4822 130 31554 |
| 409, 411                                       | Diode, ref.     | BZX79C5V1        | 4822 130 34233 |
| 412                                            | Diode, ref.     | BZX91            | 5322 130 34397 |
| 413, 417                                       | Diode, ref.     | BZX79C4V7        | 4822 130 34174 |
| 414, 420                                       | Diode           | BAW62            | 4822 130 30613 |
| 416                                            | Diode, ref.     | BZX79C6V2        | 4822 130 34167 |
| 418                                            | Diode, ref.     | BZV46C1V5        | 5322 130 34865 |
| 419                                            | Diode, ref.     | BZX79B3V3        | 5322 130 31504 |



| Pos. no.                       | Description      |               |             |        | Ordering code  |
|--------------------------------|------------------|---------------|-------------|--------|----------------|
| CAPACITORS / UNIT 1, PLL / VCO |                  |               |             |        |                |
| 502                            | Cap. ceramic     | 10 nF         | + 50/- 20 % | 100 V  | 4822 122 31414 |
| 503                            | Cap. solid alu.  | 10 $\mu$ F    |             | 16 V   | 4822 124 21314 |
| 504-508                        | Cap. ceramic     | 100 nF        | 10 %        | 50 V   | 5322 122 32941 |
| 509                            | Cap. ceramic     | 33 pF         | 2 %         | 100 V  | 5322 122 32072 |
| 511                            | Cap. ceramic     | 220 pF        | 2 %         | 100 V  | 5322 122 34047 |
| 512                            | Cap. ceramic     | 100 nF        | 10 %        | 20 V   | 5322 122 30108 |
| 513, 514                       | Cap. tantal      | 47 $\mu$ F    |             | 6.3 V  | 4822 124 10197 |
| 516                            | Cap. foil        | 4.7 nF        | 5 %         | 63 V   | 4822 121 50639 |
| 517                            | Cap. ceramic     | 470 pF        | 2 %         | 63 V   | 4822 122 32062 |
| 518, 519                       | Cap. ceramic     | 100 nF        | 10 %        | 50 V   | 5322 122 32941 |
| 521, 522                       | Cap. electrolyt. | 100 $\mu$ F   |             | 25 V   | 4822 124 40207 |
| 523, 524                       | Cap. ceramic     | 4.7 nF        | 10 %        | 100 V  | 4822 122 31125 |
| 526                            | Cap. trimmer     | 2-10 pF       |             | 100 V  | 4822 125 50082 |
| 527                            | Cap. ceramic     | 18 pF         | 2 %         | 100 V  | 4822 122 31061 |
| 528, 529                       | Cap. ceramic     | 4.7 nF        | 10 %        | 100 V  | 4822 122 31125 |
| 530                            | Cap. ceramic     | 100 nF        | 10 %        | 50 V   | 5322 122 32941 |
| 533, 547                       | Cap. ceramic     | 10 nF         | + 50/- 20 % | 100 V  | 4822 122 31414 |
| 536                            | Cap. trimmer     | 2-22 pF       |             | 100 V  | 4822 125 50045 |
| 537                            | Cap. ceramic     | 22 pF         | 2 %         | 100 V  | 5322 122 32143 |
| 539                            | Cap. ceramic     | 100 nF        | 10 %        | 20 V   | 5322 122 30108 |
| 541                            | Cap. ceramic     | 470 pF        | 2 %         | 63 V   | 4822 122 32062 |
| 542                            | Cap. ceramic     | 100 nF        | 10 %        | 20 V   | 5322 122 30108 |
| 544                            | Cap. ceramic     | 2.2 nF        | 10 %        | 100 V  | 4822 122 30114 |
| 548-552                        | Cap. ceramic     | 100 nF        | 10 %        | 50 V   | 5322 122 32941 |
| 556                            | Cap. tantal      | 47 $\mu$ F    |             | 6.3 V  | 5322 124 10197 |
| 557, 566                       | Cap. ceramic     | 100 nF        | 10 %        | 50 V   | 5322 122 32941 |
| 558                            | Cap. solid alu.  | 10 $\mu$ F    |             | 16 V   | 4822 124 21314 |
| 559-562                        | Cap. ceramic     | 10 nF         | + 50/- 20 % | 100 V  | 4822 122 31414 |
| 563                            | Cap. ceramic     | 27 pF         | 2 %         | 100 V  | 4822 122 30045 |
| 564-565                        | Cap. ceramic     | 10 nF         | + 50/- 20 % | 100 V  | 4822 122 31414 |
| 568, 569                       | Cap. ceramic     | 100 nF        | 10 %        | 20 V   | 5322 122 30108 |
| 570                            | Cap. ceramic     | 220 pF        | 2 %         | 100 V  | 5322 122 34047 |
| 571                            | Cap. ceramic     | 100 nF        | 10 %        | 20 V   | 5322 122 30108 |
| 572                            | Cap. ceramic     | 10 nF         | + 50/- 20 % | 100 V  | 4822 122 31414 |
| 573, 574                       | Cap. ceramic     | 100 nF        | 10 %        | 50 V   | 5322 122 32941 |
| RESISTORS / UNIT 1, PLL / VCO  |                  |               |             |        |                |
| 611                            | Potm. trimmer    | 470 $\Omega$  | carb.       | 0.1 W  | 4822 100 10038 |
| 614, 621                       | Potm. trimmer    | 10 k $\Omega$ | carb.       | 0.1 W  | 4822 100 10035 |
| 620                            | Potm. trimmer    | 22 k $\Omega$ | carb.       | 0.1 W  | 4822 100 10051 |
| 625                            | Resistor         | 10 M $\Omega$ | 5 %         | 0.25 W | 4822 110 72214 |
| 636                            | Potm. trimmer    | 220 $\Omega$  | carb.       | 0.1 W  | 4822 100 10019 |
| 650, 655                       | Res. metal film  | 39 $\Omega$   | 5 %         | 0.5 W  | 4822 116 52193 |
| 684                            | Potm. trimmer    | 100 $\Omega$  | carb.       | 0.1 W  | 4822 100 10075 |
| 706, 709                       | Potm. trimmer    | 22 k $\Omega$ | carb.       | 0.1 W  | 4822 100 10051 |
| 721                            | Potm. trimmer    | 100 $\Omega$  | carb.       | 0.1 W  | 4822 100 10075 |
| COILS / UNIT 1, PLL / VCO      |                  |               |             |        |                |
| 801-803                        | Damping lead     | FXC3B         |             |        | 5322 526 10366 |
| 805                            | Damping lead     | FXC3B         |             |        | 5322 526 10366 |
| 806                            | Coil             | 0.15 $\mu$ H  |             |        | 5322 157 53014 |
| 804, 807                       | Coil             | 4.7 $\mu$ H   |             |        | 5322 158 10628 |
| 808                            | Coil             | 15 $\mu$ H    |             |        | 5322 158 14004 |

| Pos. no.                                 | Description      |                          | Ordering code                 |
|------------------------------------------|------------------|--------------------------|-------------------------------|
| <b>UNIT 2, CPU</b>                       |                  |                          |                               |
| <b>INTEGRATED CIRCUITS / UNIT 2, CPU</b> |                  |                          |                               |
| 301-304                                  | Integr. circuit  | MC3441AP                 | 5322 209 85464                |
| 305                                      | Integr. circuit  | HEF4093BP                | 5322 209 14927                |
| 306                                      | Integr. circuit  | HEF4738VP                | 5322 209 14509                |
| 307                                      | Integr. circuit  | HEF40244BP               | 5322 209 10489                |
| 308                                      | Integr. circuit  | HEF40373BP               | 5322 209 10491                |
| 309, 310                                 | Integr. circuit  | HEF4014BP                | 4822 209 10296                |
| 311                                      | Integr. circuit  | HEF4094BP                | 5322 209 10421                |
| 312                                      | Integr. circuit  | HEF4514BP                | 5322 209 14051                |
| 313                                      | Integr. circuit  | N74LS175N                | 5322 209 84999                |
| 314                                      | Integr. circuit  | N74LS363N                | 5322 209 81776                |
| 315*1                                    | I. C. P27128     | (PROM, software version) |                               |
| 317                                      | Integr. circuit  | PC74HC04P                | 5322 209 11323                |
| 318                                      | Integr. circuit  | P8031U processor         | 5322 209 82034                |
| 319                                      | Integr. circuit  | N74LS390N                | 5322 209 86362                |
| 320                                      | Integr. circuit  | HEF4049BP                | 4822 209 10306                |
| 321                                      | Integr. circuit  | HEF4094BP                | 5322 209 10421                |
| 322                                      | Integr. circuit  | LM741CN                  | 4822 209 80617                |
| 323                                      | Integr. circuit  | DAC-08EN                 | 5322 209 11254                |
| 324, 325                                 | Integr. circuit  | PCD8571P                 | 4822 209 83571                |
| <b>TRANSISTOR / UNIT 2, CPU</b>          |                  |                          |                               |
| 351                                      | Transistor       | BC337-16                 | 4822 130 41095                |
| <b>DIODE / UNIT 2, CPU</b>               |                  |                          |                               |
| 401-404                                  | Diode            | BAW62                    | 4822 130 30613                |
| <b>CAPACITORS / UNIT 2, CPU</b>          |                  |                          |                               |
| 501                                      | Cap. solid alu.  | 3.3 $\mu$ F              | 16 V 4822 124 20947           |
| 502                                      | Cap. ceramic     | 220 pF                   | 10 % 100 V 4822 122 30094     |
| 503, 505                                 | Cap. ceramic     | 22 pF                    | 2 % 100 V 5322 122 32143      |
| 504                                      | Cap. ceramic     | 27 pF                    | 2 % 100 V 4822 122 30045      |
| 506-511                                  | Cap. ceramic     | 22 nF                    | +20/-90 % 40 V 4822 122 30103 |
| 512                                      | Cap. electrolyt. | 220 $\mu$ F              | 16 V 4822 124 40196           |
| 513-515                                  | Cap. ceramic     | 22 nF                    | +20/-90 % 40 V 4822 122 30103 |
| 517                                      | Cap. ceramic     | 100 nF                   | 10 % 50 V 5322 122 32941      |

| Pos. no.                    | Description  |            |     |         |                | Ordering code |
|-----------------------------|--------------|------------|-----|---------|----------------|---------------|
| RESISTORS / UNIT 2, CPU     |              |            |     |         |                |               |
| 601, 602                    | Res. network | 8 x 4.7 kΩ | 5 % | 0.125 W | 5322 116 90132 |               |
| 604, 605                    | Res. network | 8 x 4.7 kΩ | 5 % | 0.125 W | 5322 116 90132 |               |
| 609                         | Res. network | 8 x 4.7 kΩ | 5 % | 0.125 W | 5322 116 90132 |               |
| CRYSTAL / UNIT 2, CPU       |              |            |     |         |                |               |
| 801                         | Crystal      | 10 MHz     |     |         | 5322 242 71724 |               |
| MISCELLANEOUS / UNIT 2, CPU |              |            |     |         |                |               |
| 802                         | Lithium cell | 3V/160mAh  |     |         | 5322 138 10144 |               |

| Pos. no.                                 | Description     |                     | Ordering code  |
|------------------------------------------|-----------------|---------------------|----------------|
| <b>UNIT 2, DFS</b>                       |                 |                     |                |
| <b>INTEGRATED CIRCUITS / UNIT 2, DFS</b> |                 |                     |                |
| 301                                      | Integr. circuit | PC74HC04P           | 5322 209 11323 |
| 302, 306                                 | Integr. circuit | N74LS132N           | 5322 209 85201 |
| 303                                      | Integr. circuit | SN74LS109AN         | 5322 209 85974 |
| 304, 305                                 | Integr. circuit | N74LS02N            | 5322 209 85312 |
| 307-311                                  | Integr. circuit | HEF4094BP           | 5322 209 10421 |
| 312-321                                  | Integr. circuit | N74LS283N           | 5322 209 86052 |
| 322, 323                                 | Integr. circuit | N74LS273N           | 5322 209 85792 |
| 324                                      | Integr. circuit | N74LS174N           | 5322 209 81632 |
| 325, 326                                 | Integr. circuit | N74LS273N           | 5322 209 85792 |
| 327                                      | Integr. circuit | N74LS86N            | 5322 209 84997 |
| 328                                      | Integr. circuit | N74LS153N           | 5322 209 85488 |
| 329                                      | Integr. circuit | SN74LS151N          | 5322 209 86452 |
| 330                                      | Integr. circuit | N74LS00N            | 5322 209 84823 |
| 331, 332                                 | Integr. circuit | N74LS86N            | 5322 209 84997 |
| 333                                      | Integr. circuit | N74LS174N           | 5322 209 81632 |
| 334                                      | Integr. circuit | N74LS175N           | 5322 209 84999 |
| 335                                      | Integr. circuit | N82S115N (sine ROM) | 5322 209 82603 |
| 336, 337                                 | Integr. circuit | N74LS157N           | 5322 209 81521 |
| 338                                      | Integr. circuit | N74LS174N           | 5322 209 81632 |
| 339                                      | Integr. circuit | N74LS175N           | 5322 209 84999 |
| 340, 341                                 | Integr. circuit | N74LS86N            | 5322 209 84997 |
| 342                                      | Integr. circuit | N74LS273N           | 5322 209 85792 |
| 343                                      | Integr. circuit | N74LS175N           | 5322 209 84999 |
| 344, 345                                 | Integr. circuit | N74S04N             | 5322 209 84475 |
| 346                                      | Integr. circuit | MC1458N             | 4822 209 81349 |
| 347                                      | Integr. circuit | SN74LS151N          | 5322 209 86452 |
| 348                                      | Integr. circuit | HEF4050BP           | 4822 209 10261 |
| 360                                      | Integr. circuit | NE521N              | 5322 209 14441 |
| 361                                      | Integr. circuit | N74S153N            | 5322 209 85688 |
| 362                                      | Integr. circuit | HEF4094BP           | 5322 209 10421 |
| 363                                      | Integr. circuit | N74LS00N            | 5322 209 84823 |
| 364                                      | Integr. circuit | N74LS107N           | 5322 209 85816 |
| 365                                      | Integr. circuit | N74S02N             | 5322 209 85407 |
| 366, 367                                 | Integr. circuit | N74LS191N           | 5322 209 84989 |
| 368, 369                                 | Integr. circuit | N74LS157N           | 5322 209 81521 |
| 370, 371                                 | Integr. circuit | HEF4094BP           | 5322 209 10421 |
| 372                                      | Integr. circuit | SN74S112N           | 5322 209 85741 |
| 373                                      | Integr. circuit | N74LS32N            | 5322 209 85311 |
| 374                                      | Integr. circuit | SN74LS123N          | 5322 209 85266 |
| 375                                      | Integr. circuit | N74LS107N           | 5322 209 85816 |
| 376                                      | Integr. circuit | N74LS37N            | 4822 209 80916 |
| 377                                      | Integr. circuit | N74LS0PN            | 5322 209 84995 |
| 378                                      | Integr. circuit | SN74LS123N          | 5322 209 85266 |

| Pos. no.                  | Description  |                   | Ordering code        |
|---------------------------|--------------|-------------------|----------------------|
| TRANSISTORS / UNIT 2, DFS |              |                   |                      |
| 379, 402                  | Transistor   | BC548B            | 4822 130 40937       |
| 401, 403                  | Transistor   | BC558C            | 5322 130 60068       |
| 404, 407                  | Transistor   | BC558B            | 4822 130 44197       |
| 405, 406                  | Transistor   | BC558C            | 5322 130 60068       |
| 408, 409                  | Transistor   | BC558C            | 5322 130 60068       |
| 410, 413                  | Transistor   | BC558B            | 4822 130 44197       |
| 411, 412                  | Transistor   | BC558C            | 5322 130 60068       |
| 414, 415                  | Transistor   | BC558C            | 5322 130 60068       |
| 416, 419                  | Transistor   | BC558B            | 4822 130 44197       |
| 417, 418                  | Transistor   | BC558C            | 5322 130 60068       |
| 420, 421                  | Transistor   | BC558C            | 5322 130 60068       |
| 422, 425                  | Transistor   | BC558B            | 4822 130 44197       |
| 423, 424                  | Transistor   | BC558C            | 5322 130 60068       |
| 426, 427                  | Transistor   | BC558C            | 5322 130 60068       |
| 428, 430                  | Transistor   | BC558B            | 4822 130 44197       |
| 429                       | Transistor   | BC558C            | 5322 130 60068       |
| 431, 441                  | Transistor   | BC548B            | 4822 130 40937       |
| DIODES / UNIT 2, DFS      |              |                   |                      |
| 451-460                   | Diode        | BAW62             | 4822 130 30613       |
| 461, 463                  | Diode, ref.  | BZX79B4V3         | 4822 130 31554       |
| 462, 464                  | Diode        | BAW62             | 4822 130 30613       |
| 465, 467                  | Diode, ref.  | BZX79B4V3         | 4822 130 31554       |
| 466, 468                  | Diode        | BAW62             | 4822 130 30613       |
| 469, 471                  | Diode, ref.  | BZX79B4V3         | 4822 130 31554       |
| 470, 472                  | Diode        | BAW62             | 4822 130 30613       |
| 473, 475                  | Diode, ref.  | BZX79B4V3         | 4822 130 31554       |
| 474, 476                  | Diode        | BAW62             | 4822 130 30613       |
| 477                       | Diode, ref.  | BZX79B4V3         | 4822 130 31554       |
| 478                       | Diode, ref.  | BZV46X2V0         | 4822 130 31248       |
| 480                       | Diode, ref.  | BZX79B5V1         | 4822 130 34233       |
| CAPACITORS / UNIT 2, DFS  |              |                   |                      |
| 501, 507                  | Cap. ceramic | 22 nF + 20/- 90 % | 40 V 4822 122 30103  |
| 502                       | Cap. ceramic | 22 pF 2 %         | 100 V 5322 122 32143 |
| 503                       | Cap. ceramic | 56 pF 2 %         | 100 V 4822 122 32027 |
| 504                       | Cap. ceramic | 33 pF 2 %         | 100 V 5322 122 32072 |
| 505                       | Cap. trimmer | 2.5-27 pF         | 100 V 5322 125 54083 |

| Pos. no. | Description      |             |             |       | Ordering code  |
|----------|------------------|-------------|-------------|-------|----------------|
| 506      | Cap. solid alu.  | 1 $\mu$ F   |             | 25 V  | 4822 124 20944 |
| 511-517  | Cap. ceramic     | 22 nF       | + 20/- 90 % | 40 V  | 4822 122 30103 |
| 518      | Cap. electrolyt. | 220 $\mu$ F |             | 16 V  | 4822 124 40196 |
| 519      | Cap. ceramic     | 22 nF       | + 20/- 90 % | 40 V  | 4822 122 30103 |
| 520, 521 | Cap. ceramic     | 4.7 nF      | 10 %        | 100 V | 4822 122 31125 |
| 522      | Cap. ceramic     | 82 pF       | 2 %         | 100 V | 4822 122 31237 |
| 523, 524 | Cap. ceramic     | 33 pF       | 2 %         | 100 V | 5322 122 32072 |
| 525, 526 | Cap. ceramic     | 4.7 nF      | 10 %        | 100 V | 4822 122 31125 |
| 527      | Cap. ceramic     | 82 pF       | 2 %         | 100 V | 4822 122 31237 |
| 528      | Cap. ceramic     | 33 pF       | 2 %         | 100 V | 5322 122 32072 |
| 529, 530 | Cap. ceramic     | 4.7 nF      | 10 %        | 100 V | 4822 122 31125 |
| 531      | Cap. ceramic     | 82 pF       | 2 %         | 100 V | 4822 122 31237 |
| 532      | Cap. ceramic     | 33 pF       | 2 %         | 100 V | 5322 122 32072 |
| 533, 534 | Cap. ceramic     | 4.7 nF      | 10 %        | 100 V | 4822 122 31125 |
| 535      | Cap. ceramic     | 82 pF       | 2 %         | 100 V | 4822 122 31237 |
| 536      | Cap. ceramic     | 33 pF       | 2 %         | 100 V | 5322 122 32072 |
| 537, 538 | Cap. ceramic     | 4.7 nF      | 10 %        | 100 V | 4822 122 31125 |
| 539      | Cap. ceramic     | 82 pF       | 2 %         | 100 V | 4822 122 31237 |
| 540      | Cap. ceramic     | 33 pF       | 2 %         | 100 V | 5322 122 32072 |
| 541, 542 | Cap. ceramic     | 4.7 nF      | 10 %        | 100 V | 4822 122 31125 |
| 543      | Cap. ceramic     | 82 pF       | 2 %         | 100 V | 4822 122 31237 |
| 544, 548 | Cap. ceramic     | 33 pF       | 2 %         | 100 V | 5322 122 32072 |
| 545, 546 | Cap. ceramic     | 4.7 nF      | 10 %        | 100 V | 4822 122 31125 |
| 547      | Cap. ceramic     | 82 pF       | 2 %         | 100 V | 4822 122 31237 |
| 549      | Cap. ceramic     | 22 nF       | + 20/- 90 % | 40 V  | 4822 122 30103 |
| 550, 551 | Cap. ceramic     | 4.7 nF      | 10 %        | 100 V | 4822 122 31125 |
| 553      | Cap. ceramic     | 82 pF       | 2 %         | 100 V | 4822 122 31237 |
| 554      | Cap. ceramic     | 22 nF       | + 20/- 90 % | 40 V  | 4822 122 30103 |
| 555, 556 | Cap. ceramic     | 4.7 nF      | 10 %        | 100 V | 4822 122 31125 |
| 558      | Cap. ceramic     | 22 nF       | + 20/- 90 % | 40 V  | 4822 122 30103 |
| 559      | Cap. ceramic     | 22 pF       | 2 %         | 100 V | 5322 122 32143 |
| 560, 562 | Cap. ceramic     | 180 pF      | 2 %         | 100 V | 5322 122 31907 |
| 561      | Cap. ceramic     | 10 pF       | 2 %         | 100 V | 4822 122 32185 |
| 563      | Cap. solid alu.  | 6.8 $\mu$ F |             | 25 V  | 5322 124 14081 |
| 564, 566 | Cap. solid alu.  | 10 $\mu$ F  |             | 16 V  | 4822 124 21314 |
| 565, 567 | Cap. ceramic     | 22 nF       | + 20/- 90 % | 40 V  | 4822 122 30103 |
| 568      | Cap. ceramic     | 47 pF       | 2 %         | 100 V | 4822 122 31072 |
| 569      | Cap. ceramic     | 4.7 nF      | 10 %        | 100 V | 4822 122 31125 |
| 570      | Cap. ceramic     | 12 pF       | 2 %         | 100 V | 4822 122 31056 |
| 571, 572 | Cap. ceramic     | 22 nF       | + 20/- 90 % | 40 V  | 4822 122 30103 |
| 573, 574 | Cap. ceramic     | 22 pF       | 2 %         | 100 V | 5322 122 32143 |
| 575, 576 | Cap. ceramic     | 470 nF      | 20 %        | 50 V  | 5322 122 33078 |
| 577      | Cap. ceramic     | 330 pF      | 2 %         | 100 V | 4822 122 31353 |
| 578, 579 | Cap. ceramic     | 100 nF      | 10 %        | 50 V  | 5322 122 32941 |
| 580      | Cap. ceramic     | 22 nF       | + 20/- 90 % | 40 V  | 4822 122 30103 |
| 581      | Cap. ceramic     | 22 pF       | 2 %         | 100 V | 5322 122 32143 |
| 582      | Cap. ceramic     | 12 pF       | 2 %         | 100 V | 4822 122 31056 |

| Pos. no.                | Description     | Ordering code   |        |        |                |  |
|-------------------------|-----------------|-----------------|--------|--------|----------------|--|
| RESISTORS / UNIT 2, DFS |                 |                 |        |        |                |  |
| 637                     | Res. metal film | 619 $\Omega$    | 0.1 %  | 0.25 W | 5322 116 80212 |  |
| 639, 646                | Res. metal film | 1.87 k $\Omega$ | 0.1 %  | 0.25 W | 5322 116 80215 |  |
| 642, 649                | Res. metal film | 4.64 k $\Omega$ | 0.1 %  | 0.25 W | 5322 116 80216 |  |
| 643, 650                | Res. metal film | 1.69 k $\Omega$ | 0.1 %  | 0.25 W | 5322 116 80214 |  |
| 644, 651                | Res. metal film | 619 $\Omega$    | 0.1 %  | 0.25 W | 5322 116 80212 |  |
| 653, 660                | Res. metal film | 1.87 k $\Omega$ | 0.1 %  | 0.25 W | 5322 116 80215 |  |
| 656, 663                | Res. metal film | 4.64 k $\Omega$ | 0.1 %  | 0.25 W | 5322 116 80216 |  |
| 657, 664                | Res. metal film | 1.69 k $\Omega$ | 0.1 %  | 0.25 W | 5322 116 80214 |  |
| 658, 665                | Res. metal film | 619 $\Omega$    | 0.1 %  | 0.25 W | 5322 116 80212 |  |
| 667                     | Res. metal film | 1.87 k $\Omega$ | 0.1 %  | 0.25 W | 5322 116 80215 |  |
| 670                     | Res. metal film | 4.64 k $\Omega$ | 0.1 %  | 0.25 W | 5322 116 80216 |  |
| 671                     | Res. metal film | 1.69 k $\Omega$ | 0.1 %  | 0.25 W | 5322 116 80214 |  |
| 672                     | Res. metal film | 619 $\Omega$    | 0.1 %  | 0.25 W | 5322 116 80212 |  |
| 673                     | Res. metal film | 11.5 k $\Omega$ | 0.1 %  | 0.25 W | 5322 116 51742 |  |
| 674                     | Res. metal film | 9.53 k $\Omega$ | 0.1 %  | 0.25 W | 5322 116 80207 |  |
| 676                     | Potm. trimmer   | 470 $\Omega$    | carb.  | 0.1 W  | 4822 100 10038 |  |
| 679                     | Res. metal film | 1.87 k $\Omega$ | 0.1 %  | 0.25 W | 5322 116 80215 |  |
| 682, 683                | Res. metal film | 4.64 k $\Omega$ | 0.1 %  | 0.25 W | 5322 116 80216 |  |
| 684, 685                | Res. metal film | 1.69 k $\Omega$ | 0.1 %  | 0.25 W | 5322 116 80214 |  |
| 686                     | Res. metal film | 11.5 k $\Omega$ | 0.1 %  | 0.25 W | 5322 116 51742 |  |
| 687                     | Res. metal film | 9.53 k $\Omega$ | 0.1 %  | 0.25 W | 5322 116 80207 |  |
| 689                     | Potm. trimmer   | 1 k $\Omega$    | carb.  | 0.1 W  | 4822 100 10037 |  |
| 693                     | Potm. trimmer   | 4.7 k $\Omega$  | CERMET | 0.5 W  | 5322 101 10509 |  |
| 701                     | Potm. trimmer   | 220 $\Omega$    | carb.  | 0.1 W  | 4822 100 10019 |  |
| CRYSTAL / UNIT 2, DFS   |                 |                 |        |        |                |  |
| 810                     | Crystal         | 8.59 MHz        |        |        | 5322 242 74407 |  |
| COILS / UNIT 2, DFS     |                 |                 |        |        |                |  |
| 802                     | Wide band choke |                 |        |        | 5322 158 10271 |  |
| 803                     | Choke           |                 |        |        | 5322 158 20458 |  |
| 804                     | Choke           |                 |        |        | 5322 158 20459 |  |

| Pos. no.                            | Description      |                   | Ordering code        |
|-------------------------------------|------------------|-------------------|----------------------|
| <b>UNIT 3, KEYBOARD DISPLAY</b>     |                  |                   |                      |
| <b>INTEGRATED CIRCUITS / UNIT 3</b> |                  |                   |                      |
| 351                                 | Integr. circuit  | HEF40498P         | 4822 209 10306       |
| 352                                 | Integr. circuit  | MM5450N           | 4822 209 10199       |
| 353                                 | Integr. circuit  | SAA3007           | 5322 209 72061       |
| <b>TRANSISTOR / UNIT 3</b>          |                  |                   |                      |
| 301                                 | Transistor       | 8D646             | 4822 130 41212       |
| <b>DIODE / UNIT 3</b>               |                  |                   |                      |
| 409, 410                            | Diode            | BAW62             | 4822 130 30613       |
| <b>LEDs, DISPLAYS / UNIT 3</b>      |                  |                   |                      |
| 401-404                             | LED              | CQY54A            | 4822 130 31128       |
| 405-408                             | Display          | LTM8628           | 5322 130 90375       |
| <b>CAPACITORS / UNIT 3</b>          |                  |                   |                      |
| 501                                 | Cap. electrolyt. | 220 $\mu$ H       | 16 V 4822 124 40196  |
| 502-504                             | Cap. ceramic     | 22 nF + 20/- 90 % | 40 V 4822 122 30103  |
| 505, 506                            | Cap. ceramic     | 100 pF 2 %        | 100 V 4822 122 31316 |
| 507, 508                            | Cap. ceramic     | 22 nF + 20/- 90 % | 40 V 4822 122 30103  |
| <b>SWITCHES / UNIT 3</b>            |                  |                   |                      |
| 801                                 | Key switch       | M75120001         | 5322 276 14338       |
| 802-818                             | Key switch       | M75120051         | 5322 276 14418       |
| 819, 820                            | Key switch       | M75120001         | 5322 276 14338       |
| 821-828                             | Key switch       | M75120051         | 5322 276 14418       |
| 829, 834                            | Key switch       | M75120001         | 5322 276 14338       |
| 830-833                             | Key switch       | M75120051         | 5322 276 14418       |
| 835-840                             | Key switch       | M75120051         | 5322 276 14418       |
| 841                                 | Key switch       | M75120001         | 5322 276 14338       |
| 842                                 | Key switch       | M75120051         | 5322 276 14418       |
| 843-858                             | Key switch       | M75120001         | 5322 276 14338       |
| <b>MISCELLANEOUS / UNIT 3</b>       |                  |                   |                      |
| 860                                 | Cer. resonator   | 455 kHz           | 5322 242 71606       |



## LACQUERED METAL FILM RESISTORS MR25

| style | resistance range | tol.<br>±% | series | temperature<br>coefficient<br>±ppm/°C | limiting<br>voltage (r.m.s.)<br>V | service code no.<br>5322 116 5....<br>followed by |
|-------|------------------|------------|--------|---------------------------------------|-----------------------------------|---------------------------------------------------|
| MR 25 | 4,99 Ω - 301 kΩ  | 1          | E96    | 50 *                                  | 250                               |                                                   |

\* For resistance values lower than 49,9 Ω: 100 ppm/°C.


|      |      |      |      |      |      |     |      |      |      |
|------|------|------|------|------|------|-----|------|------|------|
| 4,99 | 0568 | 16,5 | 4109 | 54,9 | 4445 | 182 | 4493 | 604  | 4528 |
| 5,11 | 4192 | 16,9 | 0627 | 56,2 | 4446 | 187 | 4494 | 619  | 4529 |
| 5,23 | 4113 | 17,4 | 4432 | 57,6 | 4447 | 191 | 4495 | 634  | 4531 |
| 5,36 | 4239 | 17,8 | 0418 | 59   | 4448 | 196 | 0676 | 649  | 4532 |
| 5,49 | 4102 | 18,2 | 4083 | 60,4 | 4449 | 200 | 4496 | 665  | 4533 |
| 5,62 | 4128 | 18,7 | 0895 | 61,9 | 4451 | 205 | 0669 | 681  | 4534 |
| 5,76 | 4413 | 19,1 | 4104 | 63,4 | 4375 | 210 | 4036 | 698  | 4037 |
| 5,90 | 1064 | 19,6 | 0473 | 64,9 | 4453 | 215 | 0457 | 715  | 0671 |
| 6,04 | 4114 | 20   | 1048 | 66,5 | 4454 | 221 | 4002 | 732  | 4535 |
| 6,19 | 1049 | 20,5 | 0678 | 68,1 | 4455 | 226 | 4497 | 750  | 4536 |
| 6,34 | 0862 | 21   | 4433 | 69,8 | 4456 | 232 | 4498 | 768  | 4537 |
| 6,49 | 4112 | 21,5 | 0677 | 71,5 | 4457 | 237 | 0679 | 787  | 4538 |
| 6,65 | 4414 | 22,1 | 0983 | 73,2 | 4458 | 243 | 0437 | 806  | 4539 |
| 6,81 | 4013 | 22,6 | 0491 | 75   | 4459 | 249 | 4499 | 825  | 4541 |
| 6,98 | 4103 | 23,2 | 4434 | 76,8 | 0494 | 255 | 4501 | 845  | 4542 |
| 7,15 | 4415 | 23,7 | 4014 | 78,7 | 0578 | 261 | 4502 | 866  | 4543 |
| 7,32 | 4416 | 24,3 | 4435 | 80,6 | 4461 | 267 | 4503 | 887  | 4544 |
| 7,50 | 4417 | 24,9 | 0903 | 82,5 | 4462 | 274 | 4504 | 909  | 4545 |
| 7,68 | 4418 | 25,5 | 4436 | 84,5 | 4463 | 280 | 4505 | 931  | 4546 |
| 7,87 | 4046 | 26,1 | 0876 | 86,6 | 4464 | 287 | 4506 | 953  | 4547 |
| 8,06 | 4419 | 26,7 | 4067 | 88,7 | 4465 | 294 | 4507 | 976  | 4548 |
| 8,25 | 4099 | 27,4 | 0493 | 90,9 | 4466 | 301 | 4508 | 1K   | 4549 |
| 8,45 | 4421 | 28   | 0623 | 93,1 | 4467 | 309 | 4509 | 1K02 | 4551 |
| 8,66 | 1051 | 28,7 | 4068 | 95,3 | 0569 | 316 | 4511 | 1K05 | 4552 |
| 8,87 | 4101 | 29,4 | 4084 | 97,6 | 4468 | 324 | 4512 | 1K07 | 4553 |
| 9,09 | 0863 | 30,1 | 0904 | 100  | 4469 | 332 | 4513 | 1K1  | 4554 |
| 9,31 | 4422 | 30,9 | 4437 | 102  | 4471 | 340 | 4514 | 1K13 | 4555 |
| 9,53 | 4258 | 31,6 | 4034 | 105  | 4472 | 348 | 4515 | 1K15 | 0415 |
| 9,76 | 4423 | 32,4 | 4105 | 107  | 4473 | 357 | 0603 | 1K18 | 4556 |
| 10   | 0452 | 33,2 | 0527 | 110  | 4474 | 365 | 4516 | 1K21 | 4557 |
| 10,2 | 4111 | 34   | 4438 | 113  | 4475 | 374 | 4517 | 1K24 | 4559 |
| 10,5 | 4071 | 34,8 | 4027 | 115  | 4476 | 383 | 4518 | 1K27 | 0555 |
| 10,7 | 4424 | 35,7 | 4439 | 118  | 4477 | 392 | 4006 | 1K3  | 0526 |
| 11   | 4059 | 36,5 | 0409 | 121  | 4426 | 402 | 4519 | 1K33 | 4561 |
| 11,3 | 4425 | 37,4 | 4158 | 124  | 4478 | 412 | 4521 | 1K37 | 0628 |
| 11,5 | 0838 | 38,3 | 0954 | 127  | 4479 | 422 | 0459 | 1K4  | 4562 |
| 11,8 | 0738 | 39,2 | 4087 | 130  | 4481 | 432 | 4522 | 1K43 | 4563 |
| 12,1 | 4069 | 40,2 | 0926 | 133  | 4482 | 442 | 0592 | 1K47 | 0636 |
| 12,4 | 4427 | 41,2 | 4108 | 137  | 4483 | 453 | 4523 | 1K5  | 4564 |
| 12,7 | 4261 | 42,2 | 1052 | 140  | 4484 | 464 | 0536 | 1K54 | 0586 |
| 13   | 4082 | 43,2 | 0519 | 143  | 4485 | 475 | 4007 | 1K58 | 0622 |
| 13,3 | 1047 | 44,2 | 0818 | 147  | 0766 | 487 | 0508 | 1K62 | 4565 |
| 13,7 | 4428 | 45,3 | 0795 | 150  | 4486 | 499 | 4524 | 1K65 | 4566 |
| 14   | 0839 | 46,4 | 0492 | 154  | 0506 | 511 | 4525 | 1K69 | 4567 |
| 14,3 | 4429 | 47,5 | 0952 | 158  | 4487 | 523 | 4526 | 1K74 | 0629 |
| 14,7 | 0412 | 48,7 | 0511 | 162  | 0417 | 536 | 0621 | 1K78 | 5015 |
| 15   | 0902 | 49,9 | 4441 | 165  | 4488 | 549 | 0732 | 1K82 | 4568 |
| 15,4 | 0925 | 51,1 | 4442 | 169  | 4489 | 562 | 4009 | 1K87 | 0728 |
| 15,8 | 0861 | 52,3 | 4443 | 174  | 4491 | 576 | 4527 | 1K91 | 4569 |
| 16,2 | 4431 | 53,6 | 4444 | 178  | 4492 | 590 | 0561 | 1K96 | 4571 |

|      |      |      |      |      |      |      |      |       |       |
|------|------|------|------|------|------|------|------|-------|-------|
| 2K   | 4572 | 6K65 | 4604 | 22K1 | 4003 | 73K2 | 0666 | 243K  | 4733  |
| 2K05 | 0664 | 6K81 | 4012 | 22K6 | 0481 | 75K  | 4686 | 249K  | 4734  |
| 2K1  | 4573 | 6K98 | 4605 | 23K2 | 4645 | 76K8 | 4687 | 255K  | 473 5 |
| 2K15 | 0767 | 7K15 | 4606 | 23K7 | 4646 | 78K7 | 0533 | 261K  | 4736  |
| 2K21 | 4574 | 7K32 | 4607 | 24K3 | 4647 | 80K6 | 4688 | 267K  | 4737  |
| 2K26 | 0675 | 7K5  | 4608 | 24K9 | 4648 | 82K5 | 4689 | 274K  | 4738  |
| 2K32 | 4575 | 7K68 | 4609 | 25K5 | 4649 | 84K5 | 4691 | 280K  | 4739  |
| 2K37 | 4576 | 7K87 | 0458 | 26K1 | 4651 | 86K6 | 4692 | 287K  | 4741  |
| 2K43 | 4004 | 8K06 | 4611 | 26K1 | 4652 | 88K7 | 4693 | 294K  | 4742  |
| 2K49 | 0581 | 8K25 | 4558 | 27K4 | 0559 | 90K9 | 4694 | 301K  | 4743  |
| 2K55 | 4577 | 8K45 | 4612 | 28K  | 0667 | 93K1 | 4297 | 316 K | 5268  |
| 2K61 | 0671 | 8K66 | 4613 | 28K7 | 4653 | 95K3 | 0567 | 332 K | 1184* |
| 2K67 | 4578 | 8K87 | 4614 | 29K4 | 4654 | 97K6 | 4695 | 348 K | 5499  |
| 2K74 | 0636 | 9K09 | 4615 | 30K1 | 4655 | 100K | 4696 | 365 K | 5641  |
| 2K8  | 4579 | 9K31 | 4616 | 30K9 | 4656 | 102K | 4697 | 374 K | 5457  |
| 2K87 | 0414 | 9K53 | 4617 | 31K6 | 4657 | 105K | 4698 | 383 K | 5335  |
| 2K94 | 4581 | 9K76 | 4618 | 32K4 | 4658 | 107K | 4699 | 402 K | 5283  |
| 3K01 | 0524 | 10K  | 4619 | 33K2 | 0482 | 110K | 4701 | 412 K | 5424  |
| 3K09 | 4582 | 10K2 | 4621 | 34K  | 4659 | 113K | 4702 | 422 K | 5247  |
| 3K16 | 0579 | 10K5 | 0731 | 34K8 | 4661 | 115K | 4279 | 442 K | 5458  |
| 3K24 | 4583 | 10K7 | 4622 | 35K7 | 4662 | 118K | 4703 | 464 K | 5207  |
| 3K32 | 4005 | 11K  | 4623 | 36K5 | 0726 | 121K | 4704 | 475 K | 1275  |
| 3K4  | 4584 | 11K3 | 0668 | 37K4 | 4663 | 124K | 4705 | 499 K | 5468  |
| 3K48 | 4585 | 11K5 | 4624 | 38K3 | 0483 | 127K | 4706 | 511 K | 5258  |
| 3K57 | 4586 | 11K8 | 4625 | 39K2 | 4664 | 130K | 4707 | 536 K | 4758  |
| 3K65 | 4587 | 12K1 | 0572 | 40K2 | 4665 | 133K | 4708 | 562 K | 1169  |
| 3K74 | 4588 | 12K4 | 4626 | 41K2 | 4666 | 137K | 4709 | 590 K | 5567  |
| 3K83 | 4589 | 12K7 | 0443 | 42K2 | 0474 | 140K | 4259 | 619 K | 5315  |
| 3K92 | 4591 | 13K  | 0522 | 43K2 | 4667 | 143K | 4711 | 649 K | 5331  |
| 4K02 | 4592 | 13K3 | 4627 | 44K2 | 4668 | 147K | 4712 | 681 K | 5284  |
| 4K12 | 4593 | 13K7 | 4628 | 45K3 | 4669 | 150K | 4713 | 750 K | 5532  |
| 4K22 | 0729 | 14K  | 4629 | 46K4 | 0557 | 154K | 4714 | 806 K | 1369  |
| 4K32 | 4594 | 14K3 | 4631 | 47K5 | 4671 | 158K | 4715 | 825 K | 1398  |
| 4K42 | 0556 | 14K7 | 4632 | 48K7 | 0442 | 162K | 4716 | 866 K | 1395  |
| 4K53 | 0631 | 15K  | 4001 | 49K9 | 0674 | 165K | 4717 | 909 K | 5533  |
| 4K64 | 0484 | 15K4 | 0479 | 51K1 | 0672 | 169K | 4718 | 953 K | 1368  |
| 4K75 | 4008 | 15K8 | 4633 | 52K3 | 4673 | 174K | 4719 | 1MAO  | 5535  |
| 4K87 | 0509 | 16K2 | 0593 | 53K6 | 4674 | 178K | 4721 |       |       |
| 4K99 | 0523 | 16K5 | 4634 | 54K9 | 4675 | 182K | 4722 |       |       |
| 5K11 | 4595 | 16K9 | 4635 | 56K2 | 4676 | 187K | 4723 |       |       |
| 5K23 | 4596 | 17K4 | 4636 | 57K6 | 4677 | 191K | 4724 |       |       |
| 5K36 | 4597 | 17K8 | 4637 | 59K  | 4678 | 196K | 4725 |       |       |
| 5K49 | 4598 | 18K2 | 4638 | 60K4 | 4679 | 200K | 4726 |       |       |
| 5K62 | 4011 | 18K7 | 0558 | 61K9 | 0872 | 205K | 4727 |       |       |
| 5K76 | 4599 | 19K1 | 4639 | 63K4 | 4681 | 210K | 4208 |       |       |
| 5K9  | 0583 | 19K6 | 4641 | 64K9 | 0514 | 215K | 4728 |       |       |
| 6K04 | 4601 | 20K  | 4642 | 66K5 | 4682 | 221K | 4038 |       |       |
| 6K19 | 0608 | 20K5 | 4643 | 68K1 | 4683 | 226K | 4729 |       |       |
| 6K34 | 4802 | 21K  | 4644 | 69K8 | 4684 | 232K | 4731 |       |       |
| 6K49 | 4603 | 21K5 | 0451 | 71K5 | 4685 | 237K | 4732 |       |       |

# Figures

## FIGURES 28 -- 44

- Fig. 28 Unit 2, adjusting elements
- Fig. 29 Unit 1, adjusting elements
- Fig. 30 Block diagram
- Fig. 31 Front view
- Fig. 32 Rear view
- Fig. 33 Overall circuit diagram
- Fig. 34 Unit 1, component lay-out
- Fig. 35 Power supply
- Fig. 36 Unit 1, pulse generator
- Fig. 37 Unit 1, PLL/VCO
- Fig. 38 Unit 1, output amplifier
- Fig. 39 Unit 1, modulator
- Fig. 40 Unit 2, component lay-out
- Fig. 41 Unit 2, CPU
- Fig. 42 Unit 3, (keyboard/display) component lay-out
- Fig. 43 Unit 3, keyboard display
- Fig. 44 Unit 2, digital frequency synthesis (DFS)



component side

Fig. 28  
Unit 2  
adjusting elements




Fig. 29  
Unit 1  
adjusting elements




Fig. 30 Block diagram




Fig. 31 Front view




Fig. 32 Rear view




Fig. 33 Overall circuit diagram















Fig. 37 Unit 1, PLL/VCO


# AMPLITUDE CONTROLLER

If one of the diodes 424 - 431 is defective, all these diodes must be replaced.  
Please order a set of 8 selected BA 482 diodes.


When changing one of the diodes 432 - 439 please check the dc-offset of the output amplifier (table check and adjustment steps 7 - 13, final check part 1).  
If the specifications are not met it can be necessary to replace also the second diode of this pair (432 - 433, 434 - 435, 436 - 437, 438 - 439).




## STEP ATTENUATOR



## DC GENERATOR












Fig. 39 Unit 1, modulator






Fig. 40 Unit 2, component lay-out






Fig. 42 Unit 3, Keyboard/display component lay-out





Fig. 43 Unit 3, keyboard display



S&F



Fig. 44  
Unit 2, digital frequency synthesis  
(DFS)



**CODING SYSTEM OF FAILURE REPORTING FOR QUALITY  
ASSESSMENT OF T & M INSTRUMENTS  
(excl. potentiometric recorders)**

The information contents of the coded failure description is necessary for our computerized processing of quality data.  
Since the reporting of repair and maintenance routines must be complete and exact, we give you an example of a correctly filled-out PHILIPS SERVICE Job sheet.

|         |                |                     |                    |
|---------|----------------|---------------------|--------------------|
| ①       | ②              | ③                   | ④                  |
| Country | Day Month Year | Typenumber /Version | Factory/Serial no. |
| 3 2     | 1 5 0 4 7 5    | O P M 3 2 6 0 0 2   | D O 0 0 7 8 3      |

**CODING FAILURE DESCRIPTION**

|                                                                                                                                                                                                                                      |                                                                                                                                                                                                                                                                                              |                                 |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------|---|---|---|---|---|---|---|--|--|--|--|--|--|--|--|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|--|--|--|--|--|--|--|--|--|--|--|--|
| ⑤                                                                                                                                                                                                                                    | ⑥                                                                                                                                                                                                                                                                                            | ⑦                               |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |  |  |  |  |
| Nature of call                                                                                                                                                                                                                       | Location                                                                                                                                                                                                                                                                                     | Component/sequence no. Category |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |  |  |  |  |
| <input type="checkbox"/> Installation<br><input type="checkbox"/> Pre sale repair<br><input type="checkbox"/> Preventive maintenance<br><input checked="" type="checkbox"/> Corrective maintenance<br><input type="checkbox"/> Other | <table border="1" style="width: 100px; height: 100px; text-align: center;"> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td>0</td><td>0</td><td>2</td><td>1</td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td></tr> </table> |                                 |   |   |   | 0 | 0 | 2 | 1 |  |  |  |  |  |  |  |  | <table border="1" style="width: 100px; height: 100px; text-align: center;"> <tr><td>T</td><td>S</td><td>0</td><td>6</td><td>0</td><td>7</td></tr> <tr><td>R</td><td>0</td><td>0</td><td>6</td><td>3</td><td>1</td></tr> <tr><td>9</td><td>9</td><td>0</td><td>0</td><td>0</td><td>1</td></tr> <tr><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td></tr> <tr><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td></tr> </table> <div style="display: flex; justify-content: space-between; width: 100px;"> <div style="width: 40px; text-align: center;">5<br/>2<br/>4</div> <div style="width: 40px; text-align: center;"> <input checked="" type="checkbox"/> Job completed<br/>           Working time ⑧<br/>           1 2 Hrs         </div> </div> | T | S | 0 | 6 | 0 | 7 | R | 0 | 0 | 6 | 3 | 1 | 9 | 9 | 0 | 0 | 0 | 1 |  |  |  |  |  |  |  |  |  |  |  |  |
|                                                                                                                                                                                                                                      |                                                                                                                                                                                                                                                                                              |                                 |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |  |  |  |  |
| 0                                                                                                                                                                                                                                    | 0                                                                                                                                                                                                                                                                                            | 2                               | 1 |   |   |   |   |   |   |  |  |  |  |  |  |  |  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |  |  |  |  |
|                                                                                                                                                                                                                                      |                                                                                                                                                                                                                                                                                              |                                 |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |  |  |  |  |
|                                                                                                                                                                                                                                      |                                                                                                                                                                                                                                                                                              |                                 |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |  |  |  |  |
| T                                                                                                                                                                                                                                    | S                                                                                                                                                                                                                                                                                            | 0                               | 6 | 0 | 7 |   |   |   |   |  |  |  |  |  |  |  |  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |  |  |  |  |
| R                                                                                                                                                                                                                                    | 0                                                                                                                                                                                                                                                                                            | 0                               | 6 | 3 | 1 |   |   |   |   |  |  |  |  |  |  |  |  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |  |  |  |  |
| 9                                                                                                                                                                                                                                    | 9                                                                                                                                                                                                                                                                                            | 0                               | 0 | 0 | 1 |   |   |   |   |  |  |  |  |  |  |  |  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |  |  |  |  |
|                                                                                                                                                                                                                                      |                                                                                                                                                                                                                                                                                              |                                 |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |  |  |  |  |
|                                                                                                                                                                                                                                      |                                                                                                                                                                                                                                                                                              |                                 |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |  |  |  |  |  |  |  |  |  |  |  |  |

Detailed description of the information to be entered in the various boxes:

① Country: 3 2 = Switzerland

② Day Month Year: 1 5 0 4 7 5 = 15 April 1975

③ Type number/Version: O P M 3 2 6 0 0 2 = Oscilloscope PM 3260, version 02 (in later oscilloscopes this number is placed in front of the serial no)

④ Factory/Serial number: D O 0 0 7 8 3 = DO 783 These data are mentioned on the type plate of the instrument

⑤ Nature of call: Enter a cross in the relevant box

⑥ Coded failure description

Location

|  |  |  |  |
|--|--|--|--|
|  |  |  |  |
|--|--|--|--|

These four boxes are used to isolate the problem area. Write the code of the part in which the fault occurs, e.g. unit no or mechanical item no of this part (refer to 'PARTS LISTS' in the manual).

Example: 0001 for Unit 1  
000A for Unit A  
0075 for item 75

If units are not numbered, do not fill in the four boxes; see Example Job sheet.

Component/sequence no.

|  |  |  |  |  |  |
|--|--|--|--|--|--|
|  |  |  |  |  |  |
|--|--|--|--|--|--|

These six boxes are intended to pinpoint the faulty component.  
A. Enter the component designation as used in the circuit diagram. If the designation is alfa-numeric, the letters must be written (starting from the left) in the two left-hand boxes and the figures must be written (in such a way that the last digit occupies the right-most box) in the four right-hand boxes.  
B. Parts not identified in the circuit diagram:

990000 Unknown/Not applicable  
990001 Cabinet or rack (text plate, emblem, grip, rail, graticule, etc.)  
990002 Knob (incl. dial knob, cap, etc.)  
990003 Probe (only if attached to instrument)  
990004 Leads and associated plugs  
990005 Holder (valve, transistor, fuse, board, etc.)  
990006 Complete unit (p.w. board, h.t. unit, etc.)  
990007 Accessory (only those without type number)  
990008 Documentation (manual, supplement, etc.)  
990009 Foreign object  
990099 Miscellaneous

Category

|  |
|--|
|  |
|--|

0 Unknown, not applicable (fault not present, intermittent or disappeared)  
1 Software error  
2 Readjustment  
3 Electrical repair (wiring, solder joint, etc.)  
4 Mechanical repair (polishing, filing, remachining, etc.)  
5 Replacement (of transistor, resistor, etc.)  
6 Cleaning and/or lubrication  
7 Operator error  
8 Missing items (on pre-sale test)  
9 Environmental requirements are not met

⑦ Job completed: Enter a cross when the job has been completed.

⑧ Working time: Enter the total number of working hours spent in connection with the job (excluding travelling, waiting time, etc.), using the last box for tenths of hours.

1 2 = 1,2 working hours (1 h 12 min.)

# SALES AND SERVICE ALL OVER THE WORLD

**Alger:** Bureau de Liaison Philips, 24 bis Rue Bougainville, El Mouradia, Alger, tel. 213-601405

**Antilles:** see Ned Antilles

**Argentina:** Philips Argentina S.A., Vedia 3892, Casilla de Correo 347, 1430 Buenos Aires, tel. 54-1-5414106/54-1-5417141/5422411

**Austria:** see Oesterreich

**Australia:** Philips Scientific & Industrial, 25-27 Paul Street, P.O. Box 119, North Ryde/NSW 2113, tel. 61-2-8888222  
Service Centre:  
PCS Service,  
2 Greenhills Avenue,  
Moorebank, P.O. Box 269,  
Liverpool/NSW 2170,  
tel. 61-2-6022000

**Bangladesh:** Philips Bangla Desh Ltd., 16/17 Kawan Bazar C/A, P.O. Box 62, Ramna, N.V. Dhaka, tel. 325081/5, 411976  
Service Centre:  
50 New Ekaton Road,  
Magbazar, Dhaka, tel. 403047

**Belgium/Belgie:** Philips & MBLE associated S.A., Scientific and Industrial Equipment Division, 80 Rue des Deux Gares, 1070 Bruxelles, tel. 32-2-5256111

**Bolivia:** E.P.T.A. Industrias Bolivianas Philips S.A., Calle Mercado no. 1046, Cajon Postal 2964, La Paz, tel. 341453/350029

**Brazil:** Philips do Brasil Ltda., Eno, Rua Carlos Berrini, 3009, Caixa Postal 8681, CEP 04571-Sao Paulo (S.P.), tel. 55-11-2411611  
Service Centre:  
Sistemas Profissionais,  
Rua Anton Philips 1,  
Caixa Postal 7018,  
07000 Guarulhos-S.P.,  
tel. 55-11-2090111

**Canada:** Philips Electronics Ltd., Test and Measurement Dept., 1001 Ellesmere Road, Scarborough (Ontario) M1P-2W7, tel. 1-416-292 82000

**Chile:** Philips Chilena S.A., Division Professional, Avenida Santa Maria 6603, Casilla 2687, Santiago de Chile, tel. 56-2-707700

**Colombia:** Industrias Philips de Colombia S.A., Calle 13 no. 51-39, Apartado Aereo 4282 Bogota, tel. 57-1-2600600

**Denmark:** Philips Industri og Handels A/S, Prags Boulevard 80, P.O. Box 1919, DK-2300 Copenhagen S, tel. 45-1-572222

**Deutschland (Bundesrepublik):** Philips GmbH, Unternehmensbereich Elektronik für Wissenschaft und Industrie, Miramstrasse 87, Postfach 310 320, 3500 Kassel-Bettenhausen, tel. 49-561-5010

**Ecuador:** Philips Ecuador C.A., Paez 118 y Avenida Patria, Casilla 343, Quito, tel. 593-2-546100/564601

**Egypt:** Philips Egypt Branch at Philips Middle East N.V., 10, Abdel Rahman El Rafel Street -Dokki-, Cairo, tel. 20-2-3490922/3490928/3490928/3492237

**Eire:** Philips Electrical (Ireland) Ltd., Newstead, Clonskeagh, Dublin 14, tel. 353-1-693355

**Espana:** Philips Iberica S.A.E., Martinez Villagers 2, Apartado 2065, Madrid 28027, tel. 34-1-4042200  
Service Centre:  
Euroservice S.A.,  
Calle de Albasanz 75, Madrid 28017,  
tel. 34-1-2345800/2347025/2347105

**Ethiopia:** Philips Ethiopia (Pvt. Ltd. Co.), Ras Abebe Aregay Avenue, P.O. Box 2565, Addis Ababa, tel. 448300/157441

**Finland:** see Suomi

**France:** S.A. Philips Industrielle et Commerciale, Division Science et Industrie, 105 Rue de Paris, B-P-82, 93 002 Bobigny Cedex, tel. 33-1-4830111

**Germany:** see Deutschland

**Hellas (Greece):** Philips S.A. Hellénique, 15, 25th March Street, P.O. Box 3153, Athens 10210, tel. 30-1-4894911

**Hong Kong:** Philips Hong Kong Ltd., 29/F Hopewell Centre, 17 Kennedy Road, G.P.O. Box 2108, Hong Kong, tel. 852-5-283296

**Ireland:** see Eire

**India:** Peico Electronics & Electricals Ltd., I&E Equipment, Shrivastav Estate, Block "A", Dr. Annie Besant Road, P.O. Box 6598, Worli, Bombay 400 018 (WB), tel. 91-22-4921500

**Indonesia:** P.T. Philips Development Corporation, Jalan Gatot Subroto Kav. 35/36, P.O. Box 785/KBY, Jakarta 12590, tel. 62-21-517900/5178197

**Iran:** Philips Iran Ltd., P.O. B. 11365-3891, Tehran, tel. 98-21-674136/675158

**Iraq:** Philips Midden Oosten V.B., Baghdad Branch, Hai Al Whida (district), Area No. 902, Street No. 12, Baghdad No. 141/10, P.O. Box 5749, Baghdad, tel. 7187181

**Island:** Heimilsteiki SF, Saetun 8, Reykjavik, tel. 24000

**Italia:** Philips S.p.A., Sezione I&E/T&M, Viale Elvezio 2, 20052 Monza (MI), tel. 39-39-36351

**Japan:** see Nippon

**Kenya:** Philips (Kenya) Ltd., 01 Kalou Road, Industrial Area, P.O. Box 30554, Nairobi, tel. 254-2-557999

**Lebanon:** Philips Middle East S.A.R.L., P.O. Box 11-670, Beyrouth, tel. 392320/1

**Malaysia:** Philips Malaysia Sendirian Berhad, Wisma Philips, No. 3, Jalan SS19/2A, 47500 Petaling Jaya, Selangor, G.P.O. B. 12183, 50788 Kuala Lumpur, tel. 60-3-7345511/7554234  
Service Centre:  
Lot 51, Jalan Universiti, Section 13, 46000 Petaling Jaya, tel. 60-3-7562144

**Mexico:** Telecomunicaciones y Sistemas Profesionales S.A. de C.V., Goldsmith Ave. 40, Col. Polanco, 11560 Mexico, D.F., tel. 52-5-5406875

**Morocco:** Philips Maroc S.A., 304-Boulevard Mohammed V, B.P. 10896, Bandouge, Casablanca 05, tel. 213-302092/303192/308051

**Nederland:** Philips Nederland B.V., Boschijk 525, Geboorteveld, 5600 PD Eindhoven, tel. 31-40-739333

**Ned. Antillen:** Philips Antillana N.V., Schottegatweg Oost 146, Postbus 3523, Willemstad, Curaçao, tel. 599-9-61527/612799 (service)

**New Zealand:** Philips New Zealand Ltd., Scientific and Industrial Equipment Division, 68-86 Jarvis Quay, G.P.O. Box 2097, Wellington C1, tel. 64-4-735735

**Nigeria:** Associated Electronic Products (Nigeria) Ltd., KM16, Ikorodu Road, Ojota, P.O. B. 1921, Lagos, tel. 234-1-900180/89

**Nippon:** NF Trading Co. Ltd., 3-20 Tsunashima Higashi 5 - Chome, Kokohu-ku, Yokohama -Sh-

**Norge (Norway):** Norsk A.S. Philips, Dept. Industry and Telecommunication, Sandstuveien 70, Postboks 1, Manglerud N 0612, Oslo 6, tel. 47-2-680200

**Oesterreich:** Oesterreichische Philips Industrie GmbH, Abteilung Industrie Elektronik, Triesterstrasse 64, Postfach 217, A 1100 Wien, tel. 43-22-645521  
Service Centre:  
Oesterreichische Philips Industrie GmbH, Keltengasse 120-122, A 1232 Wien, tel. 43-22-8662

**Pakistan:** Philips Electrical Co. of Pakistan Ltd., P.O. B. 7101, Karachi 3, tel. 92-21-725772

**Paraguay:** Philips del Paraguay S.A., Avenida Artigas 1519, Casilla de Correo 605, Asunción, tel. 995-21-291924/291934

**Peru:** Philips Peruana S.A., Av. Alfonso Ugarte 1268, Lima 5, Apartado Aereo 1841, Lima 100, tel. 51-14-328070

**Philippines:** Philips Industrial Development Inc., 2246 Pagong Tamo, Makati, Metro Manila, tel. 63-2-86951/86959

**Portugal:** Philips Portuguesa S.A.R.L., 1009 Lisboa Codex, Av. Eric Duarte Pacheco 6, 1000 Lisboa, tel. 351-1-683121/9  
Service Centre:  
Service Técnicos Profissionais, Outelora 7/Carnaxide, 2795 Linda-a-Velha, tel. 351-1-2180071

**Saudi Arabia:** Delegate Office of Philips Industries, P.O. Box 9844, Riyadh 11423, tel. 966-1-4777808

**Schweiz-Suisse-Svizzera:** Philips A.G., S&I Equipment, Allmendstrasse 140, Postfach 70, CH-8027 Zurich, tel. 41-1-4882211

**Singapore:** Philips Singapore Private Limited, Lorong 1, Toa Payoh, Singapore 1231, P.O. Box 340 - Toa Payoh Central Post Office, Singapore 9131, tel. 65-3502000 (N.O.)

**South Africa:** South African Philips (Pty) Ltd., 2 Herb Street, P.O. B. 7203, New Dorfontein, Johannesburg 2000, tel. 27-11-617911

**South Korea:** Philips Electronics (Korea) Ltd., 260-199 Itaewon-dong, Yongsan-ku, Philips house C.P.O. Box 3680, Seoul, Korea 140, tel. 82-2-794-5011/5

**Spain:** see España

**Sri Lanka:** Oy Philips AB, Kaivakatu 8, P.O. Box 255, SF-00101 Helsinki, tel. 358-0-17271  
Service Centre:  
Sinkiläntie 1-3, P.O. Box 11, SF-02630 Espoo, tel. 358-0-52571

**Sverige (Sweden):** Philips Försäljning AB, Div. industrielektronik, Tegeluddsvägen 1, S 115 84 Stockholm, tel. 46-8-7821000

**Syria:** Philips Moyer-Orient S.A.R.L., Rue Fardous 7, B.P. 2442, Damas, tel. 218605/221602/22803/221025

**Taiwan:** Philips Taiwan Ltd., 150, Tun Hua North Road, P.O. Box 22978, Taipei, tel. 886-2-712-0500

**Tanzania:** Philips (Tanzania) Ltd., T.O.F.L. Building (1<sup>st</sup> floor), Ohio/Upanga Road P.O. Box 20104, Dar es Salaam, tel. 29571/4

**Thailand:** Philips Electrical Co. of Thailand Ltd., 283 Silom Road P.O. Box 961, Bangkok 10500, tel. 66-2-233 6330/9-2355 665.8  
Service Centre:  
29/1 Sanpavud Road, Bangrak, Prakanong, Bangkok 10110, tel. 66-2-396-1639/393 8772-6/66-2-396-1437

**Tunisia:** S.T.I.E.T., 32 bis, Rue Ben Ghedrahem, Tunis, tel. 216-1-348666

**Türkiye:** Türk Philips Ticaret A.S., İnönü Caddesi 78/80, Posta Kutusu 50, 80074 Beyoglu, Istanbul, tel. 90-1-1435910

**United Arab Emirates:** Philips Middle East B.V., Dubai International Trade Centre, 11th floor, P.O. Box 9269, Dubai, tel. 971-4-37700

**United Kingdom:** Pye Unicam Ltd., York Street, Cambridge CB1-2PX, tel. 44-223-35886  
Service Centre:  
Pye Unicam Ltd., Service Division, Beddington Lane, Croydon CR9-4EN, tel. 44-1-6843870

**Uruguay:** Industrias Philips del Uruguay S.A., Avda Uruguay 1287, Casilla de Correo 294, Montevideo, tel. 915641/2/3/4-919009  
Service: 387777-387878-388484

**U.S.A.:** Philips Test and Measurement Department Inc., California: Garden Grove 92645, 12825 Valley View Street, Suite 9, tel. (714) 594-8741 / (714) 898-5000  
California: Milpitas 95035, 477 Valley Way, tel. (408) 946-8722  
Florida: Winter Park 32789, 1550 Lee Road, Suite 229, tel. (305) 628-1717  
Illinois: Itasca 60143, 500 Park Blvd., Suite 1170, tel. (312) 773-0616  
Massachusetts: Woburn 01801, 21 Olympia Avenue, tel. (617) 935-2972

**Minnesota:** Minneapolis 55420, 7851 Metro Parkway, Suite 302, tel. (612) 854-2426  
**New Jersey:** Mahwah 07430, 85 McKee Drive, tel. 1-201-5293000 (Toll-free 800-6317172)

**Venezuela:** Industrias Venezolanas Philips S.A., Apartado Aereo 1167, Caracas 1010-A, tel. 58-2-2037111

**Zaire:** S.A.E./s.a.r.l., 137, Boulevard du 30 juin, B.P. 16366, Kinshasa, tel. 31-887-31888-31921

**Zambia:** Philips Electrical Zambia Ltd., Mweneshi Road, P.O. B. 3178, Lusaka, tel. 218511/218701/218321

**Zimbabwe:** Philips Electrical (Pvt) Ltd., 62 Mutare Road, P.O. Box 994, Harare, tel. 47211/48031

**For information on change of address:** Philips Export B.V., Industrial & Electro-acoustic Systems Division, Test & Measurement, Building TQ III - 4, P.O. Box 218, 5600 MD Eindhoven - The Netherlands, tel. 31-40-788476